

ACTIVE CUBE

VABus/TCP

Communication module CM-VABus/TCP

Frequency inverter 230 V / 400 V



CONTENTS

1	GENERAL INFORMATION ABOUT THE DOCUMENTATION	7
1.1	This document	7
1.2	Warranty and liability	8
1.3	Obligation	8
1.4	Copyright	8
1.5	Storage	8
2	GENERAL SAFETY INSTRUCTIONS AND INFORMATION ON USE	9
2.1	Terminology	9
2.2	Designated use	10
2.3	Misuse	10
2.3.1	Explosion protection	10
2.4	Residual risks	11
2.5	Safety and warning signs at frequency inverter	11
2.6	Warning information and symbols used in the user manual	12
2.6.1	Hazard classes	12
2.6.2	Hazard symbols	12
2.6.3	Prohibition signs	12
2.6.4	Personal safety equipment	12
2.6.5	Recycling	13
2.6.6	Grounding symbol	13
2.6.7	ESD symbol	13
2.6.8	Information signs	13
2.6.9	Font style in documentation	13
2.7	Directives and guidelines to be adhered to by the operator	13
2.8	Operator's general plant documentation	13
2.9	Operator's/operating staff's responsibilities	14
2.9.1	Selection and qualification of staff	14
2.9.2	General work safety	14
2.10	Organizational measures	14
2.10.1	General	14
2.10.2	Use in combination with third-party products	14
2.10.3	Transport and Storage	15
2.10.4	Handling and installation	15
2.10.5	Electrical connections	15
2.10.6	Safe operation	15
2.10.7	Maintenance and service/troubleshooting	16
2.10.8	Final decommissioning	17

3	INTRODUCTION	18
3.1	Supported configurations	21
3.2	Initialization time	22
4	FIRST COMMISSIONING	22
5	ASSEMBLY/DISASSEMBLY OF COMMUNICATION MODULE	23
5.1	Assembly	23
5.2	Disassembly	24
6	VABUS/TCP INTERFACE	25
6.1	Communication modules	26
6.1.1	Installation instructions	26
6.2	Setup	27
6.3	TCP/IP address & subnet	27
6.3.1	Network without DHCP server:	27
6.3.2	Network with DHCP server:	27
6.4	TCP/IP configuration	28
6.4.1	TCP configurations tool	28
6.4.2	Parameter settings with VPlus	32
6.5	Operating behavior in the case of a communication error	34
7	PROTOCOL	35
7.1	Telegram types	36
7.1.1	Data types	36
7.1.2	Send Request / Enquiry Telegram	37
7.1.3	Setting Request / Select Telegram	38
7.1.4	System bus Node-ID	39
7.2	Telegram check	41
7.3	Timeout control	42
7.4	Resetting errors	42
8	PARAMETER ACCESS	43
8.1	Handling of datasets / cyclic writing of parameters	43
8.2	Handling index parameters / cyclic writing	44
8.2.1	Example: Writing of index parameters	45
8.2.2	Example: Reading of index parameters	45
9	EXAMPLE MESSAGES VABUS/TCP	46
9.1	Reading parameters	46
9.2	Writing parameters	47

10	MOTION CONTROL INTERFACE (MCI) / MOTION CONTROL OVERRIDE (MCO)	50
10.1	Motion Control Override	51
10.2	Functions of Motion Control Interface (MCI)	56
10.2.1	Reference system	56
10.2.2	Modes of operation	56
10.2.3	Current position and contouring errors	57
10.2.4	Target window	57
10.2.5	Position Controller	57
10.2.6	Homing	59
10.2.7	Move away from Hardware limit switches	59
11	CONTROL OF FREQUENCY INVERTER	60
11.1	Control via contacts/remote contacts	61
11.1.1	Device state machine	63
11.2	Control via state machine	64
11.2.1	Statemachine diagram	66
11.3	Configurations without positioning control	69
11.3.1	Behavior in the case of a quick stop	69
11.3.2	Behavior in the case of transition 5 (disable operation)	70
11.3.3	Reference value/actual value	71
11.3.4	Example sequence	72
11.4	Configurations with position control	73
11.4.1	Velocity mode [rpm]	74
11.4.2	Profile Velocity mode [u/s] (pv)	78
11.4.3	Profile position mode	83
11.4.4	Homing mode	91
11.4.5	Table travel record	94
11.4.6	Move away from limit switch mode	103
11.4.7	Electronic gear: Slave	107
12	ACTUAL VALUES	118
12.1	Actual values Motion Control Interface / Motion Control Override	118
13	PARAMETER LIST	119
13.1	Actual values (Menu "Actual")	119
13.2	Parameters (Menu "Para")	120
14	APPENDIX	123
14.1	List of control words	123
14.2	List of status words	124
14.3	Warning messages	125
14.4	Application warning messages	126
14.5	Error messages	127

14.6	Conversions	128
14.6.1	Speed [1/min] into frequency [Hz]	128
14.6.2	Frequency [Hz] into speed [1/min]	128
14.6.3	Speed in in user units per second [u/s] into frequency[Hz]	128
14.6.4	Frequency [Hz] into speed in user units per second [u/s]	128
14.6.5	Speed in user units per second [u/s] into speed [1/min]	128
14.6.6	Speed [1/min] into speed in user units per second [u/s]	128
14.7	ASCII table (0x00 – 0x7F)	129
INDEX		130

1 General Information about the Documentation

For better clarity, the documentation of the frequency inverter is structured according to the customer-specific requirements.

The present manual was created in the German language. The German manual is the original version. Other language versions are translations.

Quick Start Guide

The "Quick Start Guide" describes the basic steps required for mechanical and electrical installation of the frequency inverter. The guided commissioning supports you in the selection of necessary parameters and the configuration of the software of the frequency inverter.

User manual

The user manual documents the complete functionality of the frequency inverter. The parameters required for special purposes, for adjustment to the application and the numerous additional functions are described in detail.

Separate user manuals are supplied for optional components for the frequency inverter. These manuals complement the operating instructions and the "Quick Start Guide" for the frequency inverter.

Application manual

The application manual complements the documentation to ensure goal-directed installation and commissioning of the frequency inverter. Information on various topics in connection with the use of the frequency inverter is described in context with the specific application.

Installation instructions

The installation manual describes the installation and use of devices, complementing the "Quick Start Guide" and the user manual.

1.1 This document

This document describes the communication via the VABus/TCP protocol with frequency inverters of the *ACTIVE* Cube series of devices. Thanks to the modular hardware and software structure, the frequency inverters can be customized to meet the customer's specific requirements, including applications requiring high functionality and dynamism.



WARNING

Compliance with the documentation is required to ensure safe operation of the frequency inverter. BONFIGLIOLI VECTRON GmbH shall not be held liable for any damage caused by any non-compliance with the documentation.



In case any problems occur which are not covered by the documentation sufficiently, please contact the manufacturer.

1.2 Warranty and liability

BONFIGLIOLI VECTRON GmbH would like to point out that the contents of this user manual do not form part of any previous or existing agreement, assurance or legal relationship. Neither are they intended to supplement or replace such agreements, assurances or legal relationships. Any obligations of the manufacturer shall solely be based on the relevant purchase agreement which also includes the complete and solely valid warranty stipulations. These contractual warranty provisions are neither extended nor limited by the specifications contained in this documentation.

The manufacturer reserves the right to correct or amend the specifications, product information and omissions in these operating instructions without notice. The manufacturer shall not be liable for any damage, injuries or costs which may be caused for the aforementioned reasons.

Furthermore, BONFIGLIOLI VECTRON GmbH excludes any warranty/liability claims for any personal and/or material damage if such damage is due to one or more of the following causes:

- inappropriate use of the frequency inverter,
- non-compliance with the instructions, warnings and prohibitions contained in the documentation,
- unauthorized modifications of the frequency inverter,
- insufficient monitoring of parts of the machine/plant which are subject to wear,
- repair work at the machine/plant not carried out properly or in time,
- catastrophes by external impact and force majeure.

1.3 Obligation

This user manual must be read before commissioning and complied with. Anybody entrusted with tasks in connection with the

- transport,
- assembly,
- installation of the frequency inverter and
- operation of the frequency inverter

must have read and understood the user manual and, in particular, the safety instructions in order to prevent personal and material losses.

1.4 Copyright

In accordance with applicable law against unfair competition, this user manual is a certificate. Any copyrights relating to it shall remain with

BONFIGLIOLI VECTRON GmbH
Europark Fichtenhain B6
47807 Krefeld
Germany

This user manual is intended for the operator of the frequency inverter. Any disclosure or copying of this document, exploitation and communication of its contents (as hardcopy or electronically) shall be forbidden, unless permitted expressly.

Any non-compliance will constitute an offense against the copyright law dated 09 September 1965, the law against unfair competition and the Civil Code and may result in claims for damages. All rights relating to patent, utility model or design registration reserved.

1.5 Storage

The documentation form an integral part of the frequency inverter. It must be stored such that it is accessible to operating staff at all times. If the frequency inverter is sold on to other users, then this user manual must also be handed over.

2 General safety instructions and information on use

The chapter "General safety instructions and information on use" contains general safety instructions for the Operator and the Operating Staff. At the beginning of certain main chapters, some safety instructions are included which apply to all work described in the relevant chapter. Special work-specific safety instructions are provided before each safety-relevant work step.

2.1 Terminology

According to the documentation, different activities must be performed by certain persons with certain qualifications.

The groups of persons with the required qualification are defined as follows:

Operator

This is the entrepreneur/company who/which operates the frequency inverter and uses it as per the specifications or has it operated by qualified and instructed staff.

Operating staff

The term Operating Staff covers persons instructed by the Operator of the frequency inverter and assigned the task of operating the frequency inverter.

Skilled Personnel

The term **Skilled Personnel** covers staff that are assigned special tasks by the Operator of the frequency inverter, e.g. installation, maintenance and service/repair and troubleshooting. Based on their qualification and/or know-how, **Skilled Personnel** must be capable of identifying defects and assessing functions.

Qualified electrician

The term Qualified Electrician covers qualified and trained staff that have special technical know-how and experience with electrical installations. In addition, Qualified Electricians must be familiar with the applicable standards and regulations, they must be able to assess the assigned tasks properly and identify and eliminate potential hazards.

Instructed person

The term Instructed Person covers staff that are instructed and trained about/in the assigned tasks and the potential hazards that might result from inappropriate behavior. In addition, instructed persons must have been instructed in the required protection provisions, protective measures, the applicable directives, accident prevention regulations as well as the operating conditions and have their qualification verified.

Expert

The term Expert covers qualified and trained staff that have special technical know-how and experience relating to the frequency inverter. Experts must be familiar with the applicable government work safety directives, accident prevention regulations, guidelines and generally accepted rules of technology in order to assess the operationally safe condition of the frequency inverter.

2.2 Designated use

The frequency inverter is designed according to the state of the art and recognized safety regulations.

The frequency inverters are electrical drive components intended for installation in industrial plants or machines. Commissioning and start of operation is not allowed until it has been verified that the machine meets the requirements of the EC Machinery Directive 2006/42/EC and DIN EN 60204-1.

The frequency inverters meet the requirements of the low voltage directive 2006/95/EEC and DIN EN 61800-5-1. CE-labeling is based on these standards. Responsibility for compliance with the EMC Directive 2004/108/EC lies with the operator. Frequency inverters are only available at specialized dealers and are exclusively intended for commercial use as per EN 61000-3-2.

No capacitive loads may be connected to the frequency inverter.

The technical data, connection specifications and information on ambient conditions are indicated on the rating plate and in the documentation and must be complied with at all times.

2.3 Misuse

Any use other than that described in "Designated use" shall not be permissible and shall be considered as misuse.

For, example, the machine/plant must not be operated

- by uninstructed staff,
- while it is not in perfect condition,
- without protection enclosure (e.g. covers),
- without safety equipment or with safety equipment deactivated.

The manufacturer shall not be held liable for any damage resulting from such misuse. The plant operator shall bear the sole risk.

2.3.1 Explosion protection

The frequency inverter is an IP 20 protection class device. For this reason, use of the device in explosive atmospheres is not permitted.

2.4 Residual risks

Residual risks are special hazards involved in handling of the frequency inverter which cannot be eliminated despite the safety-compliant design of the device. Remaining hazards are not obvious and can be a source of possible injury or health damage.

Typical residual hazards include:

Electrical hazard

Danger of contact with energized components due to a defect, opened covers or enclosures or improper working on electrical equipment.

Danger of contact with energized components in frequency inverter if no external disconnection device was installed by the operator.

Electrostatic charging

Touching electronic components bears the risk of electrostatic discharges.

Thermal hazards

Risk of accidents by hot machine/plant surfaces, e.g. heat sink, transformer, fuse or sine filter.

Charged capacitors in DC link

The DC link may have dangerous voltage levels even up to three minutes after shutdown.

Danger of equipment falling down/over, e.g. during transport

Center of gravity is not the middle of the electric cabinet modules.

2.5 Safety and warning signs at frequency inverter

- Comply with all safety instructions and danger information provided on the frequency inverter.
- Safety information and warnings on the frequency inverter must not be removed.

2.6 Warning information and symbols used in the user manual

2.6.1 Hazard classes

The following hazard identifications and symbols are used to mark particularly important information:



⚠ DANGER

Identification of immediate threat holding a **high** risk of death or serious injury if not avoided.



⚠ WARNING

Identification of immediate threat holding a **medium** risk of death or serious injury if not avoided.







⚠ CAUTION

Identification of immediate threat holding a **low** risk of minor or moderate physical injury if not avoided.


NOTE

Identification of a threat holding a risk of material damage if not avoided.


2.6.2 Hazard symbols

Symbol	Meaning	Symbol	Meaning
	General hazard		Suspended load
	Electrical voltage		Hot surfaces


2.6.3 Prohibition signs

Symbol	Meaning
	No switching; it is forbidden to switch the machine/plant, assembly on


2.6.4 Personal safety equipment

Symbol	Meaning
	Wear body protection


2.6.5 Recycling

Symbol	Meaning
	Recycling, to avoid waste, collect all materials for reuse


2.6.6 Grounding symbol

Symbol	Meaning
	Ground connection

2.6.7 ESD symbol

Symbol	Meaning
	ESD: Electrostatic Discharge (can damage components and assemblies)

2.6.8 Information signs

Symbol	Meaning
	Tips and information making using the frequency inverter easier.

2.6.9 Font style in documentation

Example	Font style	Use
1234	bold	Representation of parameter numbers
<i>Parameter</i>	italic, Font Times New Roman	Representation of parameter names
P.1234	bold	Representation of parameter numbers without name, e.g. in formulas
Q.1234	bold	Representation of source numbers

2.7 Directives and guidelines to be adhered to by the operator

The operator must follow the following directives and regulations:

- Ensure that the applicable workplace-related accident prevention regulations as well as other applicable national regulation are accessible to the staff.
- An authorized person must ensure, before using the frequency inverter, that the device is used in compliance with its designated use and that all safety requirements are met.
- Additionally, comply with the applicable laws, regulations and directives of the country in which the frequency inverter is used.

Any additional guidelines and directives that may be required additionally shall be defined by the operator of the machine/plant considering the operating environment.

2.8 Operator's general plant documentation

- In addition to the user manual, the operator should issue separate internal operating instructions for the frequency inverter. The user manual of the frequency inverter must be included in the user manual of the whole plant.

2.9 Operator's/operating staff's responsibilities

2.9.1 Selection and qualification of staff

- Any work on the frequency inverter may only be carried out by qualified technical staff. The staff must not be under the influence of any drugs. Note the minimum age required by law. Define the staff's responsibility in connection with all work on the frequency inverter clearly.
- Work on the electrical components may only be performed by a qualified electrician according to the applicable rules of electrical engineering.
- The operating staff must be trained for the relevant work to be performed.

2.9.2 General work safety

- In addition to the user manual of the machine/plant, any applicable legal or other regulations relating to accident prevention and environmental protection must be complied with. The staff must be instructed accordingly.
Such regulations and/or requirements may include, for example, handling of hazardous media and materials or provision/use of personal protective equipment.
- In addition to this user manual, issue any additional directives that may be required to meet specific operating requirements, including supervision and reporting requirements, e.g. directives relating to work organization, workflow and employed staff.
- Unless approved of expressly by the manufacturer, do not modify the frequency inverter in any way, including addition of attachments or retrofits.
- Only use the frequency inverter if the rated connection and setup values specified by the manufacturer are met.
- Provide appropriate tools as may be required for performing all work on the frequency inverter properly.

2.10 Organizational measures

2.10.1 General

- Train your staff in the handling and use of the frequency inverter and the machine/plant as well as the risks involved.
- Use of any individual parts or components of the frequency inverter in other parts of the operator's machine/plant is prohibited.
- Optional components for the frequency inverter must be used in accordance with their designated use and in compliance with the relevant documentation.

2.10.2 Use in combination with third-party products

- Please note that BONFIGLIOLI VECTRON GmbH will not accept any responsibility for compatibility with third-party products (e.g. motors, cables or filters).
- In order to enable optimum system compatibility, BONFIGLIOLI VECTRON GmbH offers components facilitating commissioning and providing optimum synchronization of the machine/plant parts in operation.
- If you use the frequency inverter in combination with third-party products, you do this at your own risk.

2.10.3 Transport and Storage

- The frequency inverters must be transported and stored in an appropriate way. During transport and storage the devices must remain in their original packaging.
- The units may only be stored in dry rooms which are protected against dust and moisture and are exposed to small temperature deviations only. The requirements of DIN EN 60721-3-1 for storage, DIN EN 60721-3-2 for transport and labeling on the packaging must be met.
- The duration of storage without connection to the permissible nominal voltage may not exceed one year.

2.10.4 Handling and installation

- Do not commission any damaged or destroyed components.
- Prevent any mechanical overloading of the frequency inverter. Do not bend any components and never change the isolation distances.
- Do not touch any electronic construction elements and contacts. The frequency inverter is equipped with components which are sensitive to electrostatic energy and can be damaged if handled improperly. Any use of damaged or destroyed components will endanger the machine/plant safety and shall be considered as a non-compliance with the applicable standards.
- Only install the frequency inverter in a suitable operating environment. The frequency inverter is exclusively designed for installation in industrial environments.
- If seals are removed from the case, this can result in the warranty becoming null and void.

2.10.5 Electrical connections

- The five safety rules must be complied with.
- Never touch live terminals. The DC link may have dangerous voltage levels even up to three minutes after shutdown.
- When performing any work on/with the frequency inverter, always comply with the applicable national and international regulations/laws on work on electrical equipment/plants of the country in which the frequency inverter is used.
- The cables connected to the frequency inverters may not be subjected to high-voltage insulation tests unless appropriate circuitry measures are taken before.
- Only connect the frequency inverter to suitable supply mains.

2.10.5.1 The five safety rules

When working on/in electrical plants, always follow the five safety rules:

1. Isolate
2. Take appropriate measures to prevent re-connection
3. Check isolation
4. Earth and short-circuit
5. Cover or shield neighboring live parts.

2.10.6 Safe operation

- During operation of the frequency inverter, always comply with the applicable national and international regulations/laws on work on electrical equipment/plants.
- Before commissioning and the start of the operation, make sure to fix all covers and check the terminals. Check the additional monitoring and protective devices according to the applicable national and international safety directives.
- During operation, never open the machine/plant
- Do not connect/disconnect any components/equipment during operation.
- The machine/plant holds high voltage levels during operation, is equipped with rotating parts (fan) and has hot surfaces. Any unauthorized removal of covers, improper use, wrong installation or operation may result in serious injuries or material damage.

- Some components, e.g. the heat sink or brake resistor, may be hot even some time after the machine/plant was shut down. Don't touch any surfaces directly after shutdown. Wear safety gloves where necessary.
- The frequency inverter may hold dangerous voltage levels until the capacitor in the DC link is discharged. Wait for at least 3 minutes after shutdown before starting electrical or mechanical work on the frequency inverter. Even after this waiting time, make sure that the equipment is deenergized in accordance with the safety rules before starting the work.
- In order to avoid accidents or damage, only qualified staff and electricians may carry out the work such as installation, commissioning or setup.
- In the case of a defect of terminals and/or cables, immediately disconnect the frequency inverter from mains supply.
- Persons not familiar with the operation of frequency inverters must not have access to the frequency inverter. Do not bypass nor decommission any protective facilities.
- The frequency inverter may be connected to power supply every 60 s. This must be considered when operating a mains contactor in jog operation mode. For commissioning or after an emergency stop, a non-recurrent, direct restart is permissible.
- After a failure and restoration of the power supply, the motor may start unexpectedly if the Auto-Start function is activated.
If staff are endangered, a restart of the motor must be prevented by means of external circuitry.
- Before commissioning and the start of the operation, make sure to fix all covers and check the terminals. Check the additional monitoring and protective devices according to EN 60204 and applicable safety directives (e.g. Working Machines Act or Accident Prevention Directives).

2.10.7 Maintenance and service/troubleshooting

- Visually inspect the frequency inverter when carrying out the required maintenance work and inspections at the machine/plant.
- Perform the maintenance work and inspections prescribed for the machine carefully, including the specifications on parts/equipment replacement.
- Work on the electrical components may only be performed by a qualified electrician according to the applicable rules of electrical engineering. Only use original spare parts.
- Unauthorized opening and improper interventions in the machine/plant can lead to personal injury or material damage. Repairs on the frequency inverters may only be carried out by the manufacturer or persons authorized by the manufacturer. Check protective equipment regularly.
- Before performing any maintenance work, the machine/plant must be disconnected from mains supply and secured against restarting. The five safety rules must be complied with.

2.10.8 Final decommissioning

Unless separate return or disposal agreements were made, recycle the disassembled frequency inverter components:

- Scrap metal materials
- Recycle plastic elements
- Sort and dispose of other component materials



Electric scrap, electronic components, lubricants and other utility materials must be treated as special waste and may only be disposed of by specialized companies.



Always comply with any applicable national disposal regulations as regards environmentally compatible disposal of the frequency inverter. For more details, contact the competent local authorities.

3 Introduction

The present document describes the VABus/TCP protocol for the CM-VABus/TCP and CM-VABus/TCP-2P (switch function integrated) communication modules. After connecting VABus/TCP to the PLC, you can use an additional logic connection from VABus/TCP to the VPlus software running on a terminal connected via an Ethernet network.

For VABus/TCP connection, the frequency inverter must be equipped with the CM-VABus/TCP or CM-VABus/TCP-2P communication module.

The CM-VABus/TCP and CM-VABus/TCP-2P communication modules are separate components and must be attached to the frequency inverter. This is described in chapter 5.1 "Assembly".

VABus/TCP communication (as described in this manual) requires software version 5.3.0 or higher.



This manual only describes the CM-VABus/TCP and CM-VABus/TCP-2P communication modules. This manual is not to be understood as providing general/basic information on Ethernet interfaces or frequency inverters. General/basic knowledge of the methods and function of VABus/TCP interfaces and VABus/TCP protocol are a prerequisite for understanding and implementing the instructions provided by this document.



In some chapters of these instructions, setting and display options via the PC software VPlus are described as an alternative to the control unit. In this case, VPlus can use

- CM-Modbus/TCP or CM-Modbus/TCP-2P module **or**
- the serial interface

for communication with the frequency inverter.



The module enables using VABus/TCP via a PLC and VPlus via the VABus/TCP protocol at the same time.



WARNING

With CM-VABus/TCP or CM-VABus/TCP-2P, controllers can access **all** parameters of the frequency inverter.

Changing parameters the function of which is unknown can result in malfunction of the frequency inverter and dangerous situations in the plant.


Ethernet properties:

- 10/100 MB (10Base-T/100Base-T)
- Automatic identification (Autonegotiation)
- MDI/MDIX

Ports:

The module supports two logic TCP/IP ports for VABus/TCP communication. Each port can be used for establishing **one** logic connection:

- Port #17220: Connection for PLC communication
- Port VPlus: Connection for VPlus



When a PLC starts communicating with a frequency inverter, it creates a TCP/IP source port to send data to target port #17220 of the frequency inverter. The response of the frequency inverter is sent by 17220 to this port of the PLC.

VPlus is the software for configuration and maintenance of BONFIGLIOLI VECTRON frequency inverters. It can connect with a frequency inverter while it is communicating with a PLC. VPlus can establish connections to any type of industrial Ethernet CM modules.


Module variants:

There are two VABus/TCP variants.

CM-VABus/TCP provides a physical interface for communication via VABus/TCP. A star-type network topology can be used. An external switch is the star point.

CM-VABus/TCP-2P provides two physical interfaces for communication via VABus/TCP. The following network topologies are possible:

- Star-type (like in CM-VABus/TCP)
- Line



- [1] PLC
- [2] PC for commissioning or diagnosis (connected temporarily or permanently)
- [3] ACU with CM-VABus/TCP or CM-VABus/TCP-2P (2nd port not connected)
- [4] ACU with CM-VABus/TCP-2P

3.1 Supported configurations

ACTIVE Cube frequency inverters support various types of control and reference point input

- Standard (without positioning functions)
- Positioning via contacts (or remote contacts)
- Positioning via Motion Control Interface (MCI) via Field Bus

A configuration with position control is selected when parameter *Configuration 30* = x40 (e.g. 240) is set. In order to use the full functionality of the Motion Control Interfaces, parameter *Local/Remote 412* = „1-Control via statemachine must be set additionally.

The operating behavior of the frequency inverter varies in the configuration groups, considering *control word/status word* and *modes of operation*.

Standard:

Required settings: *Configuration 30* ≠ x40
Local/Remote 412 = (remote) contacts

- ➔ Control (start, stop, frequency changeover, etc.) is typically performed through
 - digital contacts.
 - Remote contacts via field bus.
- ➔ Reference values depend on the selected configuration. Typical:
 - Reference speed/reference frequency:
 - Analog input.
 - Fixed values from parameters.
 - *Override Target Velocity vl [rpm] 1459* (target speed).
 - Reference percentage for technology controller or torque control
 - Analog input.
 - Fixed values from parameters.

See Chapter 11.3 “Configurations without positioning control” for control without positioning functions.

Positioning via contacts (or remote contacts)

Required settings: *Configuration 30* = x40
Local/Remote 412 = (remote) contacts

- ➔ Control (start, stop, target position changeover, etc.) is typically performed through
 - digital contacts.
 - Remote contacts via field bus.
- ➔ Reference values depend on the selected configuration. Typical:
 - Reference speed/ reference frequency.
 - Reference target position.

Also refer to application manual “Positioning”.

MCI (Motion Control Interface – Positioning via Field Bus):



In VABus/TCP communication, MCI is not available. You can use Motion Control Override (MCO) instead.

Required settings: *Configuration 30* = x40
Local/Remote 412 = 1 – Statemachine

- ➔ Control (start, stop, change of mode, etc.) is performed via *Control word 410*.
- ➔ Reference values result from the selected *Override Modes Of Operation 1454*.

Typical:

- Speed reference via *Override Target Velocity vl [rpm] 1459* (target speed).
- Target position via *Override target position 1455*.

For information on how to use the Motion Control Interface, refer to Chapters 10 “Motion Control Interface (MCI) / Motion Control Override (MCO)” and 11.4 “Configurations with position control”.

3.2 Initialization time

When the frequency inverter is turned on, the communication module must be initialized in addition to the frequency inverter. The initialization can take up to 20 seconds.



Wait until the initialization phase is complete before starting the communication (RUN LED).

4 First commissioning

For first commissioning, you should be familiar with the followings steps and the described functions:

- Installation of module Chapter 5.1
- Selection of device control *Local/Remote* **412** Chapter 11
- Commissioning of device functions via PLC
 - Motion Control Override Chapter 10.1
 - Fault Reaction Chapter 6.5
 - Fault reset Chapter 7.4
- Setting reference values:
 - Reference speed in speed-controlled configuration x10, x11, x15, x16, x30, x60 Chapter 11.3
 - Reference in position configuration x40 Chapter 10 and 11.4
 - Velocity Mode Chapter 11.4.1
 - Profile Velocity Mode Chapter 11.4.2
 - Profile Position Mode Chapter 11.4.3
 - Homing Mode Chapter 11.4.4
 - Table Travel record Mode Chapter 11.4.5
 - Move away from Limit Switch Mode Chapter 11.4.6
 - Electronic Gear: Slave Mode Chapter 11.4.7
 - Mode change Chapter 10
- Diagnosis: Chapter 13.1 and 14.1

5 Assembly/disassembly of communication module

5.1 Assembly

The CM-VABus/TCP and CM-VABus/TCP-2P communication modules are pre-assembled in a case and are ready for installation. In addition, a PE-spring is supplied for PE-connection (shield).




CAUTION

Danger of destruction of frequency inverter and/or communication module


- Before installation of the communication module, the frequency inverter must be disconnected from power supply. Installation is not permissible while the unit is energized.
- Do not touch the PCB visible on the back of the module, otherwise components may be damaged.

Work steps:

- Disconnect the frequency inverter from mains voltage and protect it against being energized unintentionally.
- Remove covers **(1)** and **(2)** of the frequency inverter. Slot B **(4)** for the communication module is now accessible.




- Mount the supplied PE spring **(5)** using the M4 screw **(6)** in the unit. The spring must be aligned centrally.
- Insert the communication module in slot B **(4)** until it engages audibly.
- Fix the communication module and PE spring **(5)** using the M2-screw provided at the module.



- In the upper cover **(1)**, break out the pre-punched cutout **(3)** for the plug X310 **(8)**.
- Mount the two covers **(1)** and **(2)**.

5.2 Disassembly

- Disconnect the frequency inverter from power supply and protect it against being energized unintentionally.
- Remove covers **(1)** and **(2)** of the frequency inverter, see chapter 5.1 "Assembly".





- Loosen the M2 screw at the communication module.
- Unplug the communication module from Slot B **(4)** by unlocking the locking hooks **(9)** on the right and left side of the module from the case of the frequency inverter using a small screwdriver.
- The locking hooks **(9)** are located at the place where the locking hooks **(10)** for the upper cover **(1)** project from the case of the frequency inverter.
 - To do this, insert the screwdriver in the gap between the case of the module and the frequency inverter carefully and push the locking hook inwards in the direction of the arrow (\leftarrow). As soon as the right side is unlocked, pull out the module a bit on the right side and hold it.
 - Hold the module on the right side while unlocking the locking hook on the left side in the same way (\rightarrow).
 - Pull the module out of the slot by gently pulling on the right and left side alternately.
- Disassemble the PE spring **(5)**, see Chapter 5.1 "Assembly".
- Mount the two covers **(1)** and **(2)**, see Chapter 5.1 "Assembly".

6 VABus/TCP interface

The frequency inverter can be controlled by a PLC or another master device via an Ethernet interfaces using the VABus/TCP protocol.

When a VABus/TCP or VABus/TCP-2P communication module is used, you can also access the frequency inverter using the VPlus software via Ethernet. VPlus can be used in parallel with a PLC with VABus/TCP communication.



This document does not provide basic information about Ethernet interfaces. Basic knowledge of Ethernet is required. This document describes the special properties of the VABus/TCP protocol.

In some sections, setting and display options via the PC software VPlus are described as an alternative to the control unit. In this case, VPlus communicates with the frequency inverter via a serial interface or a direct Ethernet connection.



WARNING

With VABus/TCP communication, controllers can access **all** parameters of the frequency inverter.

Changing parameters the function of which is unknown can result in malfunction of the frequency inverter and dangerous situations in the plant.

⚠ CAUTION




When values are to be written cyclically at a high repetition rate, no entries shall be made in the EEPROM, as this only allows a limited number of write cycles (approx. 1 million cycles). If the number of permissible write cycles is exceeded, the EEPROM will be damaged. See chapter 8.1 "Handling of datasets / cyclic writing of parameters".

6.1 Communication modules

CM-VABus/TCP


The CM-VABus/TCP communication module features an active RJ45 port.



CM-VABus/TCP

CM-VABus/TCP-2P

The CM-VABus/TCP-2P communication module features two active RJ45 ports with integrated switching function. This enables easy linking (daisy chain) of frequency inverters which are connected to a PLC.



CM-VABus/TCP-2P

6.1.1 Installation instructions

The VABus/TCP module is connected to the PLC or other devices using standard CAT cables and RJ45 connectors:

Ethernet standard: IEEE 802.3, 100Base-TX (fast Ethernet)

Cable type: S/FTP (cable with braided shield, (ISO/IEC 11801 or EN 50173, CAT5e Straight Through or Cross Over)

6.2 Setup

By default, the parameters of the CM-VABus/TCP and CM-VABus/TCP-2P communication modules are set up as follows:

Parameters		Settings
No.	Description	Factory setting
388	<i>Bus Error Behaviour</i>	1
1432	<i>IP-Address</i>	172.22.1.25
1433	<i>Netmask</i>	255.255.255.0
1434	<i>Gateway</i>	0.0.0.0
1435	<i>DNS Server</i>	0.0.0.0
1436	<i>DHCP Option</i>	0
1437	<i>IP Command</i>	-
1440	<i>Email Function</i>	0
1441	<i>Email Text (Body)</i>	-

The parameter settings must be adapted to the actual application.

6.3 TCP/IP address & subnet

For proper identification, each frequency inverter is assigned a TCP/IP address which must be unique in the system.

6.3.1 Network without DHCP server:

The address is set via parameter *IP-Address* **1432**. In addition, the subnet mask-*Netmask* **1433** must be entered properly for the local network.

Parameters		Settings		
No.	Description	Min.	Max.	Factory setting
1432	IP address	0.0.0.0	255.255.255.255	172.22.1.25
1433	Netmask	0.0.0.0	255.255.255.255	255.255.255.0

6.3.2 Network with DHCP server:

When a DHCP server is used, manual network configuration is not required. Set *DHCP Option* **1436** to "1-Enabled" if you wish to use the DHCP function.

DHCP Option 1436	Function
0 - Disabled	Module must be configured manually, no DHCP server is used. (Factory setting) .
1 - Enabled	The settings are made by a DHCP server.

6.4 TCP/IP configuration

In order to establish connection with a frequency inverter featuring a CM-VABus/TCP module, you will have to configure IP settings for the CM-VABus/TCP module.

TCP/IP configuration can be performed in different ways.


- TCP/IP configuration program, see Chapter 6.4.1 “TCP configurations tool”.
- Parameter settings with VPlus via service port of frequency inverter (KP232), see Chapter 6.4.2.1 “Basic IP settings”.
- Control panel.

6.4.1 TCP configurations tool


There are different ways to start the “TCP configuration tool”:

- In the “Inverter Manger” window click on the “Start TCP configuration tool”.
- Double-click on the desktop icon “Vectron Network Configuration” (stand-alone application).

Once the application has started, a window will appear where you can select the Ethernet adapter via which the frequency inverter is connected:




- Select the Ethernet adapter and click on “Ok”.




Once the Ethernet adapter has been selected, the configuration program is ready to search for available frequency inverters.

With the “Timeout” setting, you define how long the TCP configuration tool will wait for responses from the frequency inverter.



- In the "Timeout" field, enter the required time and click on "Search".
The search is started. Upon completion of the search all frequency inverters found will be listed in the left area of the window.
- Click on the frequency inverter to be configured.



The right part of the window shows information on the device and input fields for various settings.

Information about network adapter:

Network adapter:	Name of selected network adapter.
IP address:	IP address of network adapter.

Device information:

Device name:	Device name from frequency inverter parameter <i>User name</i> 29 .
Device type:	Type of frequency inverter.
CM type:	Type of CM module, i.e.: CM – VABus/TCP.
Module status:	Current status of CM module, e.g. “Connected to PLC”.
MAC address:	MAC address of CM module.

Device settings

IP address:	Current IP address of device.
Subnet mask:	Current subnet mask.
Standard gateway:	Address of standard gateway.
DNS Server:	Address of current DNS server.
Host Name:	Name of host.
DHCP activated:	Use of DHCP (yes/no).

- Enter the device settings required for your application. In order to apply the settings to the device, click on “Write IP settings”.

NOTE

Before clicking on "Write IP settings", make sure that you are connected with the right frequency inverter. To check this, click on the "Wink" button. The connected frequency inverter will flash for 10 seconds.

At the frequency inverter, you can activate a function which will send an e-mail in case of an error. In addition, a short text can be entered and saved as the e-mail text. The required settings can only be made via VPlus. VPlus will access the frequency inverter via a local service port (KP232) or an Ethernet connection.

To configure the e-mail function, please refer to Chapter 6.4.2.2 "Email".

To send an e-mail message, the frequency inverter needs various information. It must have its own e-mail address from where the e-mail message is sent. For e-mail transmission, identification by the SMTP server (user name and password) is required. The recipient of the e-mail message must be known.

In addition, the local network must be connected to the Internet, i.e. Gateway and DNS server must be entered correctly. If you have any questions or problems, please contact your local system administrator.

SMTP settings (examples):

SMTP server:	<i>smtp.provider.com</i>
"From" address:	<i>inverter.drive1@company.com</i>
User name:	<i>drive1@company.com</i>
Password:	<i>password</i>
Re-enter password	<i>password</i>
"To" address	<i>service.drives@company.com</i>

SMTP settings saved before can be viewed by clicking on the "Read SMTP settings". The password will **not** be displayed.

SMTP settings are applied to the module by clicking on the "Write SMTP settings". When the SMTP settings are written, you will be prompted to enter a password. The two input fields "Password" and "Re-enter password" must contain the same character sequence. If no entry is made or the contents of the two input fields are different, an error message will be displayed.

NOTE

- All **device settings** are saved in the module **and** in the non-permanent memory of the frequency inverter. Switching of modules from one frequency inverter to another does not have an effect on the IP settings of the frequency inverter. A PLC will remain connected with the right frequency inverter after switching of the module.
- **SMTP settings** are saved in the module only. Switching of modules from one frequency inverter to another will result in malfunction:
 - No e-mail messages will be sent in case of an error.
 - Wrong recipient.
 - Wrong e-mail text.




For documentation, all settings can be saved in a file (type = *.eop).

6.4.2 Parameter settings with VPlus

6.4.2.1 Basic IP settings

IP settings can be made via the KP232 interface adapter.

Various parameters are available for module information and IP settings.



Parameter *Module Info 1431* shows basic module data:

MAC-ID: unambiguous MAC-ID
 Sno: Serial number
 HW: Hardware version
 SW: Software version

For IP setting, five parameters are available.

Parameters	
No.	Description
1432	<i>IP address</i>
1433	<i>Netmask</i>
1434	<i>Gateway</i>
1435	<i>DNS Server</i>
1436	<i>DHCP Option</i>

They define the IP settings and/or use of DHCP. When the DHCP option is activated, the IP settings will be made by the DHCP server when the module is started.

Each setting comprises four values. Please contact your IT administrator for permissible values. The four values of the parameters are assigned on the display to four datasets ("Data Set 1" to "Data Set 4"). However, they **do not** depend on changes of these data sets directly. The datasets are only provided for clear representation of the values.


- To make IP stings, click on the first entry (e.g. Parameter **1432** *IP-Address* "Data Set 1").
- Enter the required value and go to the next input field by pressing the "TAB" button.



The new settings will be saved in a buffer memory, but not transmitted to the module. On the network side, they will not be active.

In the case of incorrect entries, the values can be overwritten. Old values can be restored via parameter **1437 IP-Command** = "1 – Reload IP-Settings".

The "R/W" activates the "Update all parameters in current window regularly" function:



NOTE

Before applying the new IP settings to the module, make sure that the "R/W" button is activated.

- Apply the new IP settings to the module via parameter **1437 IP-Command** = "0 – Apply".



The module will reject non-permissible IP settings and will restore the last permissible settings automatically. After execution of the "Apply" command, all IP settings will be reset and the new settings will be overwritten by the old settings.

6.4.2.2 Email

When an error occurs in the frequency inverter, an e-mail message can be sent automatically to report the incident to the Service department, for example. To activate the e-mail function and define the e-mail text, two parameters are used:

Parameters	
No.	Description
1440	<i>Email Function</i>
1441	<i>Email Text (Body)</i>

The contents of the e-mail message is pre-defined. The reference heading is given and cannot be edited.

Reference: Frequency inverter type, frequency inverter name (from parameter **29 User name**), IP address, error number

E-mail text: Optional text (max. 40 characters), defined in parameter **1441 Email Text (Body)**.

Example:

Reference: ACU Main Drive machine no. 5, 172.22.5.145, F0400
Please contact Mr. Doe, extension 2121.

6.5 Operating behavior in the case of a communication error

The operating behavior in the case of errors in VABus/TCP communication can be parameterized. The required behavior can be set up via *Bus Error Behaviour 388*.

<i>Bus Error Behaviour 388</i>	Function
0 - no response	Operating point is maintained.
1 - Error	"Fault" status will be activated immediately. Factory setting.
2 - Stop	Control command "Disable voltage" and switch to "switch on disabled" status.
3 - Quick stop	Control command "Quick stop" and switch to "switch on disabled" status.
4 - Shutdown + Error	Control command "Disable operation" and switch to "Error" status once the drive has been shut down.
5 - Quick stop + Error	Control command "Quick stop" and switch to "Error" status once the drive has been shut down.



The parameter settings *Bus fault behavior 388* = 2...5 are evaluated depending on parameter *Local/Remote 412*.

For evaluation of settings 2...5, parameter *Local/Remote 412* must be set to value "1 - Control via statemachine".

7 Protocol

The VABus protocol was originally developed for the serial interface (RS232/RS485) and adapted to the CM-VABus/TCP module. The VABus/TCP protocol uses the TCP/IP protocol. The VABus data is integrated in the data block of the TCP/IP protocol. VABus/TCP and VABus use a similar structure. The handshake procedures and the data representation are different. VABus uses HEX-ASCII data, while VABus/TCP uses binary data. The protocol structure of VABus/TCP aims at fast processing and minimum protocol overhead.

→ Read/write commands and VABus/TCP data are integrated in the TCP/IP data range.

The VABus and VABus/TCP protocol enable operation as a pure Master/Slave system. A PC, a PLC or any type of computer system is the bus Master.

Two types of requests are used:

Send request (inquiry telegram) for the request for reading parameters in the frequency inverter by the bus Master.

Positioning request (select telegram) for handing over parameter values or parameter settings to the frequency inverter by the bus Master.

Send/positioning requests and send/positioning responses use defined data structures which are arranged in frames. Each frame comprises a header byte and different numbers of bytes containing information for parameter access.

The header byte is divided in 8 control bits, only bits 6 and 7 are used. Bits 0 to 5 are not used and must have value "0". If one or more of these bits has/have value "1", the error message "syntax error in received telegram" will be returned as the response.

7.1 Telegram types

7.1.1 Data types

The number of data bytes depends on the type of the corresponding parameter. A maximum of 99 data bytes can be transferred.

Data Types Used				
Data type abb.	Type	Number of data types "w"	Value	Bit number
uint	unsigned Integer	04	0 ... 65535	16
Int	Integer	04	-32768 ... +37767	16
Long	Long	08	$-2^{31} \dots +2^{31}-1$	32
String	string of characters	variable, up to 99	-	variable



Parameter values with decimal places are transferred without decimal point. Depending on the number of decimal places, the values are multiplied by 10, 100 or 1000. The number of decimal places for the corresponding parameters is set in the frequency. In this way it is made sure that the sent parameter values are processed correctly.

Example: Frequency value with data type long:

Value to be transferred = 100.25. The numerical value transmitted in the telegram is 10025, which corresponds to 0x2729 in HEX format. Since the data type is **long**, 8 data bytes are transferred ("wwwwww").

➔ **00002729**

Example: Current value with data type Int:

The value to be transmitted is 10.3 A. The numerical value transmitted in the telegram is 103, which corresponds to 0x67 in HEX format. Since the data type is **int**, 4 data bytes are transferred ("www").

➔ **0067**

7.1.2 Send Request / Enquiry Telegram

Send request PLC → frequency inverter:

Byte	0			1	2	3	4	5
	Header			NoB	SYS	DS	P.-No.	
	7	6	5...0				LSB	MSB
	R/W	0	0	4	nn	nn	nnnn	

Header: Bit 7 **R/W** **0 = Send request**

NoB: Byte number Number of relevant bytes ([Byte 2] – [Byte 5])
NoB will always be "4" for send requests.

SYS: Addresses frequency inverters which are connected to a TCP/IP module via CAN System Bus.
SYS = 0 for direct addressing of frequency inverter in Ethernet connection (SYS = 0...63)

DS: Data set number of parameter (0, 1 ... 4)

P. No.: Parameter number (0 ... 1599)

Send response frequency inverter → PLC:

Byte	0			1	2	3	4	5	6	7	8	9	...	n							
	Header			NoB	SYS	DS	P.-No.		data												
	7	6	5...0				LSB	MSB	uint/int data												
	R/W	E	0	nn	nn	nn	nnnn		LSB	MSB											
														long data							
														LSB			MSB				
														string data							
							first character							last character							

Header: Bit 7 **R/W** **0 = Send response**

Bit 6 **E** 0 = no error
1 = error
if (E == 1) → byte 6+7 contains error code (→ NoB = 6)

NoB: Byte number Number of relevant bytes

SYS: returns value SYS from the request frame

DS: returns dataset number from the request frame

P. No.: returns parameter number from the request frame

data: requested parameter value, byte number depending on data type

If no response from the frequency inverter is received within a given response time (see chapter 7.3, "Timeout control"), or if the frequency inverter returns incorrect data, the inquiry telegram is repeated three times (maximum of three transmissions possible).

NAK signals an error. An error may have different causes. Errors may be caused by incorrect data or an incorrect string.

7.1.3 Setting Request / Select Telegram

Via the select telegram, the data are sent to the frequency inverter.

Positioning request PLC → frequency inverter:

Byte	0			1	2	3	4	5	6	7	8	9	...	n			
	Header			NoB	SYS	DS	P.-No.		data								
	7	6	5...0				LSB	MSB	uint/int data								
	R/W	0	0	nn	nn	nn	nnnn		LSB	MSB							
												long data					
												LSB			MSB		
												string data					
												first character				last character	

Header: Bit 7 **R/W** **1 = Setting request**

NoB: Byte number **Number of relevant bytes**
([Byte 2] ... [Byte 5] + Number of data bytes)

SYS: Addresses frequency inverters which are connected to a TCP/IP module via CAN System Bus.
SYS = 0 for direct addressing of frequency inverter in Ethernet connection

DS: Data set number of parameter (0,1 ..., 4, 5, 6 ... 9)

P. No.: Parameter number (0 ... 1599)

data: parameter value to be written, byte number depending on data type

Setting response frequency inverter → PLC:

Byte	0			1	2	3	4	5	6	7	8	9	...	n			
	Header			NoB	SYS	DS	P.-No.		data								
	7	6	5...0				LSB	MSB	uint/int data								
	R/W	E	0	nn	nn	nn	nnnn		LSB	MSB							
												long data					
												LSB			MSB		
												string data					
												first character				last character	

Header: Bit 7 **R/W** **1 = Setting response**

Bit 6 **E** **0 = no error**
1 = error
if (E == 1) → byte 6+7 contains error code (→ NoB = 6)

NoB: Byte number **Number of relevant bytes**
([Byte 2] ... [Byte 5] + number of data bytes)

SYS: returns value SYS from the request frame

DS: returns dataset number from the request frame

P. No.: returns parameter number from the request frame

data: returns written parameter value, byte number depending on data type

7.1.4 System bus Node-ID


The System Bus *Node-ID* 900 is required for addressing networked inverters. If there is no System Bus, or if the System Bus master is addressed, the SYS character is always filled with the zero character (**0x30**). The *Node-ID* **900** has values ranging from 0 to 63.

<i>Node-ID</i> 900	Function	SYS character
-1	No System Bus at inverter.	"-1" = 0xFFFF
0	The inverter is the System Bus master.	"0" = 0x30
1 ... 63	The inverter is the System Bus slave with the specified ID.	0x41 .. 0x7F

If the *Node-ID* **900** is not zero, the SYS character is determined as follows:

$$\text{SYS character} = (\text{char})(\text{SysNode-ID Nr} + 0x40)$$

For example, *Node-ID* **900** of **7** will result in character 0x47 = "**G**". Refer to System Bus description.



System Bus requires a corresponding EM module, e.g. EM-SYS, EM-RES-01, EM-IO-01, EM-ENC-01, EM-ABS-01. The term "System Bus" in the illustration is a placeholder for the relevant module.



The procedure shown in the illustration will work in the following Field Buses:

- VABus
- VABus/TCP

Instead of the PLC, you can use a standard PC with an appropriate interface.

The addresses in a System Bus branch must be assigned unambiguously. Since several System Bus branches can be operated independently due to the different Ethernet clients, identical System Bus addresses are possible in the network. The distinction is made based on the different Ethernet addresses.

In the case of VABus, the network address is a serial address ranging from 1 to 127.

In the case of VABus/TCP, the network address is an IP address in the format `aaa.bbb.ccc.ddd`, with each block of numbers ranging from 0 to 255.

7.2 Telegram check

The frequency inverter and the bus Master check the telegrams for correctness. Depending on the type of telegram, the corresponding reaction takes place. The telegrams are checked for correct syntax, address and text part (content, checksum).

In case the telegram contains errors, the frequency inverter either returns NAK or it does not respond at all. The possible causes are listed below:

no response wrong telegram structure
 wrong control character
 wrong address
 telegram addressed to address 32 (Broadcast); in this case, the frequency inverter does not reply.

If an error occurs during parameter access, the frequency inverter will return an error message (Bit E = "1" in read/write response). Bytes 6 and 7 contain the error code.

VABus SST-Error-Register 11

Error no.	Meaning
0	no error
1	Non-permissible parameter value.
2	Non-permissible dataset
3	parameter not readable (write-only)
4	parameter not writable (read-only)
5	EEPROM read error
6	EEPROM write error
7	EEPROM checksum error
8	Parameter cannot be written while drive is running
9	Values of data sets are different
10	not available
11	unknown parameter
12	not available
13	Syntax error in received telegram
14	data type of parameter does not correspond to the number of bytes in the telegram
15	unknown error
20	selected System Bus node not available
30	Syntax error in received telegram

7.3 Timeout control

After first data exchange via the PLC Port #17220, a timeout check will be activated. If no data is exchanged for more than 10 seconds, the frequency will respond in the way set in parameter *Bus Error Behaviour 388*. and switch to fault status with error message F2714 "Communication Loss to PLC".

<i>Bus Error Behaviour 388</i>	Function
0 - no response	Operating point is maintained.
1 - Error	"Fault" status will be activated immediately. Factory setting.
2 - Stop	Control command "Disable voltage" and switch to "switch on disabled" status.
3 - Quick stop	Control command "Quick stop" and switch to "switch on disabled" status.
4 - Shutdown + Error	Control command "Disable operation" and switch to "Error" status once the drive has been shut down.
5 - Quick stop + Error	Control command "Quick stop" and switch to "Error" status once the drive has been shut down.



The parameter settings *Bus Error Behaviour 388* = 2...5 are evaluated depending on parameter *Local/Remote 412*.

For evaluation of settings 2...5, parameter *Local/Remote 412* must be set to value "1 - Control via statemachine".

7.4 Resetting errors

Depending on the settings and operating state of the device, errors can be reset in different ways:

- In controller via Parameter *Local/Remote 412* = 1 - Statemachine:
Set bit 7 *Control word 410* = 0x8000.
- By pressing the stop button of the control panel:
Resetting by pressing the STOP button is only possible if Parameter *Local/Remote 412* permits control via the control panel.
- Via parameter *Error acknowledgment 103* which is assigned a logic signal or a digital input
A reset via a digital signal can only be carried out when parameter *Local/Remote 412* permits this or when an input with the addition (hardware) is selected in the case of physical inputs.



Some errors will occur again after an error reset. In such cases, it may be necessary to take certain measures (e.g. moving from a limit switch in the non-disabled direction).

8 Parameter access

8.1 Handling of datasets / cyclic writing of parameters

The parameter values are accessed based on the parameter number and the required dataset. There are parameters the values of which are present once (dataset 0) as well as parameters the values of which are present four times (dataset 1...4). These are used for dataset switching.

If parameters which are present four times in the datasets are set to Dataset = 0, the four datasets are set to the same transmitted value. A read access with data set = 0 to such parameters is only successful if all four data sets are set to the same value. If this is not the case, an error will be signaled.

NOTE

The values are entered automatically in the EEPROM of the controller. When values are to be written cyclically, no entries shall be made in the EEPROM, as this only allows a limited number of write cycles (approx. 1 million cycles). When the number of permissible write cycles is exceeded, the EEPROM will be destroyed.

In order to avoid this, data which is written cyclically can be entered in the RAM exclusively without a writing cycle on the EEPROM. Such data will be lost in the case of a power failure and have to be written again after Power off/on.

This mechanism is started when the target dataset is increased by five when specifying the dataset.

Writing on virtual dataset in RAM

Parameters	EEPROM	RAM
Dataset 0	0	5
Dataset 1	1	6
Dataset 2	2	7
Dataset 3	3	8
Dataset 4	4	9

8.2 Handling index parameters / cyclic writing

Index parameters are used for various ACU functions. Here, 16 or 32 indexes are used instead of the 4 data sets. For each function, the individual indexes are addressed separately via an index access parameter. Via the indexing parameter, you can select if the data is to be written to EEPROM or RAM.

Function	Parameters	Index range		Indexing parameters
		Write EEPROM and read	Write RAM	
Positioning	1202 <i>Target position / distance</i> 1203 <i>Speed</i> 1204 <i>Acceleration</i> 1205 <i>Ramp Rise time</i> 1206 <i>Deceleration</i> 1207 <i>Ramp Fall time</i> 1208 <i>Motion mode</i> 1209 <i>Touch-Probe Window</i> 1210 <i>Touch-Probe-Error: Next Motion Block</i> 1211 <i>No. of Repetitions</i> 1212 <i>Delay</i> 1213 <i>Delay: Next Motion Block</i> 1214 <i>Event 1</i> 1215 <i>Event 1: Next Motion Block</i> 1216 <i>Event 2</i> 1217 <i>Event 2: Next motion block</i> 1218 <i>Digital signal 1</i> 1219 <i>Digital signal 2</i> 1247 <i>Digital signal 3</i> 1248 <i>Digital signal 4</i> 1260 <i>Interrupt-Event 1</i> 1261 <i>Int.-Event 1: Eval.-Mode</i> 1262 <i>Int. event 1: Next motion block</i> 1263 <i>Interrupt-Event 2</i> 1264 <i>Int.-Event 2: Eval.-Mode</i> 1265 <i>Int. event 2: Next motion block</i>	0 ¹⁾ ; 1...32	33 ¹⁾ ; 34...65	1200 Write 1201 Read
PLC function (Function Table)	1343 <i>FT-Instruction</i> 1344 <i>FT-Input 1</i> 1345 <i>FT-Input 2</i> 1346 <i>FT-Input 3</i> 1347 <i>FT-Input 4</i> 1348 <i>FT-Parameter 1</i> 1349 <i>FT-Parameter 2</i> 1350 <i>FT-Target Output 1</i> 1351 <i>FT-Target Output 2</i> 1352 <i>FT-Commentary</i>	0 ¹⁾ ; 1...32	33 ¹⁾ ; 34...65	1341 Write 1342 Read
Multiplexer	1252 <i>Mux Input</i>	0 ¹⁾ ; 1...16	17 ¹⁾ ; 18...33	1250 Write 1251 Read
CANopen [®] multiplexer	1422 <i>CANopen Mux Input</i>	0 ¹⁾ ; 1...16	17 ¹⁾ ; 18...33	1420 Write 1421 Read

1) When the indexing parameter = 0, all indexes will be written upon parameter access in EEPROM. 17 (for 16 indexes) or 33 (for 32 indexes) will write all indexes in RAM.



The values are entered automatically in the EEPROM of the controller. However, only a limited number of write cycles is permissible for the EEPROM (approx. 1 million cycles). When this number is exceeded, the EEPROM will be destroyed.

- Values which are written cyclically at a high repetition rate should be written to the RAM and not the EEPROM.

In the RAM, the data is not protected against loss of power. Once power supply is disrupted, the data must be written again.

8.2.1 Example: Writing of index parameters

Typically, index parameters are written regularly during commissioning of in simple positioning applications.

Writing of Parameter *Target position/distance* **1202** (Type double word), in Index 1 in RAM (→ Index 34 for write access) with parameter value 30000.

Index = 1200 + 0x2000 = 0x24B0, value (int) = 34 = 0x0022

Index = 1202 + 0x2000 = 0x24B2, value (long) = 30000 = 0x0000 7530



If various parameters of an index are to be edited, it will be sufficient to set index access via parameter **1200** once at the beginning.

8.2.2 Example: Reading of index parameters

In order to read an index parameter, you will have to set the indexing parameter to the relevant index first, then you can read the parameter.

Reading of Parameter *Target position/distance* **1202** (type long), in Index 1 with parameter value 123000.

Index = 1201 + 0x2000 = 0x24B1, value (int) = 1 = 0x0001

Index = 1202 + 0x2000 = 0x24B2, value (long) = 123000 = 0x0001 E078



If various parameters of an index are to be read, it will be sufficient to set index access via **1201** once at the beginning.

9 Example messages VABus/TCP

This chapter describes some examples of telegrams for VABus/TCP.

9.1 Reading parameters

Example 1:

Reading of parameter *Rated speed* **372** (0x0174) in dataset2.

Request: Master → frequency inverter

Byte	...	0	1	2	3	4	5	
	TCP/IP Header	Header			NoB	SYS	DS	P.-No.
	> 40 Bytes	7	6	5...0			LSB	MSB
		0	0	0	04	00	02	74 01

Response: Frequency inverter → Master

Byte	...	0	1	2	3	4	5	6	7	
	TCP/IP Header	Header			NoB	SYS	DS	P.-No.		
	> 40 Bytes	7	6	5...0				LSB	MSB	data
		0	0	0	06	00	02	74 01	6E	05

The sent hexadecimal value is 0x056E = Decimal 1390. Parameter *Rated speed* **372** has no decimal places. Thus, the rated speed is 1390 min⁻¹.

Example 2:

Reading of parameter *Fixed frequency 2* **481** (0x01E1) in dataset 1.

Request: Master → frequency inverter

Byte	...	0	1	2	3	4	5	
	TCP/IP Header	Header			NoB	SYS	DS	P.-No.
	> 40 Bytes	7	6	5...0			LSB	MSB
		0	0	0	04	00	01	E1 01

Response: Frequency inverter → Master

Byte	...	0	1	2	3	4	5	6	7	8	9	
	TCP/IP Header	Header			NoB	SYS	DS	P.-No.		data		
	> 40 Bytes	7	6	5...0				LSB	MSB	long data		
		0	0	0	08	00	01	E1 01	E8	03	00	00

The sent hexadecimal value is 0x03E8 = Decimal 1000. Parameter *Fixed frequency 2* **481** has two decimal places. Thus, the frequency is 10.00 Hz.

Example 3:

Reading of parameter *Inverter software version* **12** (0x000c) in dataset 0.

Request: Master → frequency inverter

Byte	...	0			1	2	3	4	5
	TCP/IP Header	Header			NoB	SYS	DS	P.-No.	
	> 40 Bytes	7	6	5...0				LSB	MSB
		0	0	0	04	00	00	0c 00	

Response: Frequency inverter → Master

Byte	...	0			1	2	3	4	5	6	7	8	9	10	11	12	13	14	
	TCP/IP Header	Header			NoB	SYS	DS	P.-No.		data									
	> 40 Bytes	7	6	5...0				LSB	MSB	String data (hexadecimal and string)									
		0	0	0	0D	00	00	01	E1	35	2E	33	2E	32	20	53	54	4F	
										5	.	3	.	2		S	T	O	

The sent hexadecimal value is ASCII encoded. In the example, the ASCII string is green. For conversion between hexadecimal and ASCII value, refer to the relevant table in the appendix.

9.2 Writing parameters

Example 1:

Writing of parameter *Rated mech. power* **376** (0x0178) in dataset 4.

The rated mechanical power is to be set to 1.5 kW. Parameter *Rated mech. Power* **376** has one decimal place. Thus the value to be sent is 15 = 0x000F.

Request: Master → frequency inverter

Byte	...	0			1	2	3	4	5	6	7
	TCP/IP Header	Header			NoB	SYS	DS	P.-No.		data	
	> 40 Bytes	7	6	5...0				LSB	MSB	uint/int data LSB MSB	
		1	0	0	06	00	04	78 01		0F	00

Response: Frequency inverter → Master

Byte	...	0			1	2	3	4	5	6	7
	TCP/IP Header	Header			NoB	SYS	DS	P.-No.		data	
	> 40 Bytes	7	6	5...0				LSB	MSB	uint/int data LSB MSB	
		1	0	0	06	00	04	78 01		0F	00

The response is the reflected signal of the request message.

Example 2:

Writing of non-permissible value 0 in parameter *Rated mech. power* **376** (0x0178) in dataset 2.

Request: Master → frequency inverter

Byte	...	0	1	2	3	4	5	6	7	
	TCP/IP Header	Header			NoB	SYS	DS	P.-No.		data
	> 40 Bytes	7	6	5...0				LSB	MSB	uint/int data LSB MSB
		1	0	0	06	00	04	78 01		00 00

Error response: Frequency inverter → Master

Byte	...	0	1	2	3	4	5	6	7	
	TCP/IP Header	Header			NoB	SYS	DS	P.-No.		data
	> 40 Bytes	7	6	5...0				LSB	MSB	uint/int data LSB MSB
		1	1	0	06	00	04	78 01		01 00

Example 3:

Writing of parameter *Fixed frequency 3* **482** (0x01E2) in dataset 9 (= RAM for dataset 4) of frequency inverter.

The fixed frequency is to be set to 44.50 Hz. Parameter *Fixed frequency 3* **482** has two decimal places. Thus the value to be sent is 4450 = 0x00001162.

Request: Master → frequency inverter

Byte	...	0	1	2	3	4	5	6	7	8	9
	TCP/IP Header	Header			NoB	SYS	DS	P.-No.		data	
	> 40 Bytes	7	6	5...0				LSB	MSB	long data LSB MSB	
		1	0	0	08	00	09	E2 01		62	11 00 00

Response: Frequency inverter → Master

Byte	...	0	1	2	3	4	5	6	7	8	9
	TCP/IP Header	Header			NoB	SYS	DS	P.-No.		data	
	> 40 Bytes	7	6	5...0				LSB	MSB	long data LSB MSB	
		1	0	0	08	00	09	E2 01		62	11 00 00

The response is the reflected signal of the request message.

Example 4:

Writing of parameter *Fixed frequency 3 482* (0x01E2) in dataset 9 (= RAM for dataset 4) of frequency inverter.

The frequency is to be set to 2000.00 Hz (non-permissible value). Parameter *Fixed frequency 3 482* has two decimal places. Thus the value to be sent is 20000 = 0x00030D40.

Request: Master → frequency inverter

Byte	...	0			1	2	3	4	5	6	7	8	9
	TCP/IP Header	Header			NoB	SYS	DS	P.-No.		data			
	> 40 Bytes	7	6	5...0				LSB	MSB	long data			
		1	0	0	08	00	09	E2 01		40	0D	03	00

Error response: Frequency inverter → Master

Byte	...	0			1	2	3	4	5	6	7
	TCP/IP Header	Header			NoB	SYS	DS	P.-No.		data	
	> 40 Bytes	7	6	5...0				LSB	MSB	uint/int data	
		1	1	0	06	00	09	E2 01		01	00



For explanations of error codes, see 7.2 "Telegram check".

10 Motion Control Interface (MCI) / Motion Control Override (MCO)

The Motion Control Interface (MCI) is a defined interface of the ACU device for positioning control via Field Bus. Typically, this interface is used by field bus systems such as CANopen[®]. With the Motion Control Interface, the user can carry out a positioning operation via a field bus using a positioning profile typically including the target position, speed, acceleration, deceleration, quick stop and mode-specific information.



In the case of VABus/TCP communication, MCI cannot be used directly. Instead, positioning is performed via MCO (Motion Control Override), see Chapter 10.1 “Motion Control Override”.

The Motion Control Interface uses parameter *Override Modes Of Operation* **1454** for switching between the different modes.

The supported modes as per CANopen[®] Standard DS402 are:

- 1 – Profile Position mode
- 2 – Velocity mode [rpm]
- 3 – Profile Velocity mode [u/s]
- 6 – Homing
- 7 – Interpolated mode (not available when MCO is used)
- 8 – Cyclic sync position mode (not available when MCO is used)
- 9 – Cyclic sync velocity mode (not available when MCO is used)

Bonfiglioli Vectron specific mode

- -1 (or 0xFF) – Table Travel record mode
- -2 (or 0xFE) – Move Away from Limit Switch
- -3 (or 0xFD) – Electronic Gear: Slave (electronic gear as slave)

The mode of operation can be switched in any operating state.



It is recommended that running movements be stopped by the PLC first, then, switch the mode of operation using *Override Modes Of Operation* **1454** and restart in the new mode.

In order to use the Motion Control Interface, *Local/Remote* **412** = “1 - Control via statemachine” must be set. In configurations without positioning control (*Configuration* **30** ≠ x40), only velocity mode is available.

For a description of the positioning parameters, please refer to the “Application manual - Positioning”.

10.1 Motion Control Override

The Motion Control Override feature can be used for specifying a travel profile via serial communication (VABus or Modbus as well as VABus/TCP or Modbus/TCP). This enables testing a travel profile in the VPlus user software for Windows when the controller has not been programmed completely yet. This function can also be used as a simulation mode.



The Function Motion Control Override does not support the following modes:

- Interpolated Mode.
- Cyclic Synchronous Position Mode
- Cyclic Synchronous Velocity Mode

Parameters		Settings		
No.	Description	Min.	Max.	Factory setting
1454	<i>Override Modes Of Operation</i>	Selection		0
1455	<i>Override Target Position</i>	$-2^{31}-1 \dots 2^{31}-1$ u		-1 u
1456	<i>Override Profile Velocity</i>	$-1 \dots 2^{31}-1$ u/s		-1 u/s
1457	<i>Override Acceleration</i>	$-1 \dots 2^{31}-1$ u/s ²		-1 u/s ²
1458	<i>Override Deceleration</i>	$-1 \dots 2^{31}-1$ u/s ²		-1 u/s ²
1459	<i>Override Target Velocity vl [rpm]</i>	-32768...32767 rpm		-1 rpm
1460	<i>Override Target Velocity pv [u/s]</i>	$-2^{31}-1 \dots 2^{31}-1$ u/s		-1 u/s

Based on the default settings of the Motion Control Interface (parameters **1292...1297**), the override parameters and CANopen[®] objects are used as follows:

1454 <i>Override Modes Of Operation</i>	or	0x6060 Modes of Operation
1455 <i>Override Target Position</i>	or	0x607A Target Position
1456 <i>Override Profile Velocity</i>	or	0x6081 Profile Velocity
1457 <i>Override Acceleration</i>	or	0x6083 Profile Acceleration
1458 <i>Override Deceleration</i>	or	0x6084 Profile Deceleration
1459 <i>Override Target Velocity vl [rpm]</i>	or	0x6042 Target Velocity
1460 <i>Override Target Velocity pv [u/s]</i>	or	0x60FF Target Velocity

With the default settings "-1" in parameters **1455...1460** and "0" in parameter *Override Modes Of Operation* **1454** the values of the Motion Control from the links of parameters **1292...1297** are used. If the parameter settings deviate from the factory settings, the value of the relevant parameter will be used. It is possible to define certain ranges of the trajectory via the override function and other values via the Motion Control Interface.



Target position "-1 u" cannot be approached because *Override Target Position* **1455** = -1 deactivates the override feature.

Depending on the selected mode of operation, various objects and parameters are used. The various objects and parameters must be set specifically for the different modes of operation.

Use of "Deceleration" and "Quick Stop" depends on the modes of operation, control commands and behavior in the case of communication errors (see *Bus Error Behaviour* **388**).

The following tables show the available modes of Operation using the Motion Control Override.

Mode	Homing	Velocity Mode	Profile Velocity Mode
1454 <i>Override Modes Of Operation</i>	6	2	3
Target position			
Speed	1132 & 1133 <i>Fast speed / Creep speed</i>	1459 <i>Override Target Velocity vl [rpm]</i>	1460 <i>Override Target Velocity pv [u/s]</i>
Limitation ³⁾	418 <i>Minimum frequency</i> 419 <i>Maximum Frequency</i>	418 <i>Minimum frequency</i> 419 <i>Maximum Frequency</i>	418 <i>Minimum frequency</i> 419 <i>Maximum Frequency</i>
Acceleration	1134 <i>Acceleration</i>	420 <i>Acceleration (clockwise)</i> 422 <i>Acceleration anti-clockwise</i>	1457 <i>Override Acceleration</i>
Deceleration	1134 <i>Acceleration</i>	421 <i>Deceleration (clockwise)</i> 423 <i>Deceleration anti-clockwise</i>	1458 <i>Override Deceleration</i>
Emergency stop ²⁾ Quick Stop	1179 <i>Emergency stop ramp</i>	424 <i>Emergency stop clockwise</i> 425 <i>Emergency stop anticlockwise</i>	1179 <i>Emergency stop ramp</i>
Homing Method	1130 <i>Homing type</i>		
Fahrsatz (Motion Block)			

- 1) The limitation results from *Minimum frequency 418* and *Maximum Frequency 419*. Through *Limitation 1118* of the position controller in Configuration x40, an increase above the Maximum Frequency can occur, because the output of the position controller is added to the Maximum Frequency.
- 2) Emergency stop or Deceleration is used depending on the stopping behavior *Mode of operation 630* or the behavior in the case of communication errors *Bus Error Behaviour 388*.


Mode	Profile Positioning mode
1454 <i>Override Modes Of Operation</i>	1
Target position	1455 <i>Override Target Position</i>
Speed	1456 <i>Override Profile Velocity</i>
Limitation ³⁾	418 <i>Minimum frequency</i> 419 <i>Maximum Frequency</i>
Acceleration	1456 <i>Override Acceleration</i>
Deceleration	1458 <i>Override Deceleration</i>
Emergency stop ⁴⁾ Quick Stop	1179 <i>Emergency stop ramp</i>

- 1) The limitation results from *Minimum frequency* **418** and *Maximum Frequency* **419**. Through *Limitation* **1118** of the position controller in Configuration x40, an increase above the Maximum Frequency can occur, because the output of the position controller is added to the Maximum Frequency.
- 2) Emergency stop or Deceleration is used depending on the stopping behavior *Mode of operation* **630** or the behavior in the case of communication errors *Bus Error Behaviour* **388**.

Mode	Table travel record mode	Move away from limit switch	Electronic gear - Slave
1454 <i>Override Modes Of Operation</i>	255	254	253
Target position	1202 <i>Target position</i>		
Speed	1203 <i>Speed</i>	1132 <i>Fast speed</i> 1133 <i>Creep speed</i>	1460 <i>Override Target Velocity pv [u/s]</i>
Limitation ³⁾	418 <i>Minimum frequency</i> 419 <i>Maximum Frequency</i>	418 <i>Minimum frequency</i> 419 <i>Maximum Frequency</i>	418 <i>Minimum frequency</i> 419 <i>Maximum Frequency</i>
Acceleration	1204 <i>Acceleration</i>	1134 <i>Acceleration</i>	1457 <i>Override Acceleration</i>
Deceleration	1205 <i>Deceleration</i>	1134 <i>Acceleration</i>	1458 <i>Override Deceleration</i>
Emergency stop ⁴⁾ Quick Stop	1179 <i>Emergency stop ramp</i>	1179 <i>Emergency stop ramp</i>	1179 <i>Emergency stop ramp</i>
Motion block	Selected via control word		
Gear factor			1123 <i>Gear factor Numerator</i> 1124 <i>Gear factor denominator</i>
Phasing ⁵⁾			1125 <i>Phasing: Offset</i> 1126 <i>Phasing: Speed</i> 1127 <i>Phasing: Acceleration</i>

- 1) The limitation results from *Minimum frequency 418* and *Maximum Frequency 419*. Through *Limitation 1118* of the position controller in Configuration x40, an increase above the Maximum Frequency can occur, because the output of the position controller is added to the Maximum Frequency.
- 2) Emergency stop or Deceleration is used depending on the stopping behavior *Mode of operation 630* or the behavior in the case of communication errors *Bus Error Behaviour 388*.

Relationships between objects, parameters and conversions



Velocity [vl] → Velocity mode [rpm]
Velocity [pv] → Profile Velocity mode [u/s]



The graphical overview shows the most important objects which are used. Other objects are available in the different modes; for additional information, refer to the descriptions of the objects and modes.

10.2 Functions of Motion Control Interface (MCI)

Via the Motion Control Interface, numerous positioning functions can be addressed by a PLC directly.

10.2.1 Reference system

In many modes, the Motion Control Interface uses user units [u]. These user units [u] result from the conversion of the gear factor parameters and the No. of pole pairs 373.

Conversion between “user units” [u] and frequencies [Hz]

$$f [\text{Hz}] = v \left[\frac{\text{u}}{\text{s}} \right] \cdot \frac{\text{No. of pole pairs } 373 \cdot \text{Gear Box : Driving shaft revolutions } 1116}{\text{Feed Constant } 1115 \frac{[\text{u}]}{\text{U}} \cdot \text{Gear Box : Motor shaft revolutions } 1117}$$

$$v \left[\frac{\text{u}}{\text{s}} \right] = f [\text{Hz}] \cdot \frac{\text{Feed Constant } 1115 \frac{[\text{u}]}{\text{U}} \cdot \text{Gear Box : Motor shaft revolutions } 1117}{\text{No. of pole pairs } 373 \cdot \text{Gear Box : Driving shaft revolutions } 1116}$$



Feed Constant 1115
Gear Box: Shaft revolutions 1116
Gear Box: Motor revolutions 1117



The same formulas can be used for converting acceleration values from a[Hz/s] to a[u/s²] and vice versa. In the formulas, replace speeds f[Hz] and f[u/s] by accelerations a[Hz/s] and a[u/s²].

For more details about the reference system, refer to the “Positioning” application manual.

10.2.2 Modes of operation

In *Override Modes Of Operation 1454*, you can define the operation mode of the frequency inverter.

The available options depend on the set frequency inverter configuration.

Available values for *Override Modes Of Operation 1454* in configurations of the frequency inverter with position control (Parameter *Configuration 30* = x40):

Modes of operation	
1	– Profile position mode
2	– Velocity mode [rpm] (factory setting)
3	– Profile velocity mode [u/s]
6	– Homing mode
255 (-1)	– Table travel record mode (manufacturer-specific mode of operation)
254 (-2)	– Move away from limit switch (manufacturer-specific mode of operation)
253 (-3)	– Electronic Gear: Slave (manufacturer-specific mode of operation)

Usable values for *Modes of operation* in frequency inverter configurations without positioning control (Parameter *Configuration 30* ≠ x40):

Modes of operation	
2	– Velocity mode [rpm]

10.2.3 Current position and contouring errors

Parameter *Act. position value* **1108** returns the actual position in user units.

Parameter *Act. contouring error* **1109** returns the actual contouring error.

The contouring error can be monitored internally in order to trigger a device error once a threshold is reached. For details on parameters *Fault reaction* **1120**, *Warning limit* **1105**, *Error limit* **1106** and *Contouring error time* **1119**, refer to application manual "Positioning".


10.2.4 Target window

The target window monitors the current position after completion of a positioning operation. A positioning operation is complete as soon as the current position is in the target window. Via parameter *Target Window* **1165**, you can define as from which distance from the target position the signal "Target Reached" is set. This setting is valid both for the positive and negative direction.

If the parameter value is set to 0, the operation will be complete as soon as the Position reference value reaches the target position. For the Position reference value an internal value is used, that is calculated anew depending on the profile data for each internal cycle step.

Via parameter *Target Window Time* **1166**, you can define how long the axis must be in the target window before "Target Reached" is signaled.

Parameter		Setting		
No.	Description	Min.	Max.	Fact. sett.
1165	Target Window	0 u	2^{20} u	182 u
1166	Target Window Time	1 ms	65 535 ms	1 ms



The size of the target window affects the automatic sequence of motion blocks because the positioning operation requires a higher precision in the case of a small target window (small tolerance). The following motion block is started when the target window is reached.

10.2.5 Position Controller

The position controller evaluates the positioning operation (target/actual position) and tries to control the drive such that it comes as close as possible to the specifications. For this purpose, an additional frequency is calculated for compensation of position deviations. By setting the corresponding parameter, this frequency can be limited. The parameter settings of the position controller determine how quick and to what extent position deviations are to be compensated.

Via *Time Constant* **1104**, you can define the maximum time in which the position deviation is to be compensated.

Via parameter *Limitation* **1118**, you can define to which value the speed is limited for compensation of the position deviation.

Parameters		Settings		
No.	Description	Min.	Max.	Factory setting
1104	Time constant	0.00 ms	300.00 ms	10.00 ms ¹⁾ 100.00 ms ²⁾
1118	Limit	0 u/s	$2^{31}-1$ u/s	327 680 u/s


1) Factory parameter setting *Configuration 30* = 240 or 540

2) Factory parameter setting *Configuration 30* = 440


Example:

Position deviates by 1 motor shaft revolution, time constant is set to 1 ms. The position controller will increase the motor frequency by 1000 Hz in order to compensate the position deviation. Parameter *Limitation 1118* must be set accordingly.

Controller block diagram



In order to avoid oscillations of the drive while it is at standstill, amplification is reduced to 50 % of the parameterized value for small position deviations.



The following behavior may indicate that the controller parameters are not configured properly:

- drive is very loud
- drive vibrates
- frequent contouring errors
- inexact control

For the setting options of other control parameters, e.g. speed controller and acceleration pilot control, refer to the operating instructions of the frequency inverter.



Optimize the settings in actual operating conditions, as control parameters for speed controller and acceleration pilot control depend on actual load. Optimize with different load types to obtain a good control behavior in all situations.

10.2.6 Homing

When the drive is started, a defined starting position must be identified for absolute-value positioning. In a homing operation, the point of reference of the positioning operation is determined. All positioning data relates to this point of reference. Once the homing operation is started, the drive moves until it reaches a home switch or limit switch and stops there. The limit switches limit the motion path. The direction of movement (search direction) at the start of the homing operation is defined by the homing mode. Once the limit switches are reached, the direction of rotation of the drive will be reversed, depending on the selected homing mode. The Limit switches can also be used as a reference for homing. For a list of homing modes, refer to chapter "List of Homing Modes"

Relative positioning and moving in velocity mode is possible without homing.

Homing can be started:

- via a digital input
- by a control word via system bus or field bus ¹⁾
- automatically before the start of a motion block positioning operation

¹⁾ Extension module with system bus or field bus interface required



If an absolute value encoder with an absolute value encoder module (e.g. EM-ABS-01) is used, homing is not required when power supply is turned on. This is defined by parameter *Operation Mode 1220*.

For more details about the homing function, refer to the "Positioning" application manual.

10.2.6.1 Start position after homing

After homing:

Initial Position 1185 = -1 → Drive stops at "stopped" position.

Initial Position 1185 ≠ -1 → Drive will be moved actively to the set position.

10.2.6.2 Flying homing

Flying homing can be used in order to update the home position during positioning operations. For a description of this function, refer to Chapter "Positioning".

10.2.7 Move away from Hardware limit switches

When a hardware limit switch is triggered, an error message will be triggered depending on the settings of parameter *Fault reaction 1143* and the relevant direction of rotation will be disabled.

After an error reset, it is possible to move in the direction that is still enabled. Generally, any mode of operation can be used for clearing, as long as the travel command has the enabled direction.

As long as the limit switch is triggered, the limit switch warning in the status word and actual value parameters *Warnings 269*, *Warnings Application 273* and *Controller status 275* will remain. Once the limit switch is cleared, the warning will be deleted in the status word and actual value parameters.

For simple clearing of the limit switches, you can use mode "-2 Clear limit switch" (see Chapter 11.4.6 "Move away from limit switch mode").

11 Control of frequency inverter

The frequency inverter can generally be controlled via three operation modes. The operation modes can be selected via the data set switchable parameter *Local/Remote* **412**.

Parameters		Settings		
No.	Description	Min.	Max.	Factory setting
412	<i>Local/Remote</i>	0	44	44

For operation with a Field bus, only operation modes 0, 1 and 2 are relevant. The other settings refer to the control option via the control unit.

Operation mode	Function
0 - Control via contacts (Chapter 11.1)	The Start and Stop commands as well as the direction of rotation are controlled via digital signals.
1 - Control via state machine (Chapters 11.1.1, 11.3, 11.4)	The frequency inverter is controlled via the control word. Positioning functions through the control word and the modes of operation as described in CANopen® DS402 will only be supported with this set-up.
2 - Control via remote contacts (Chapter 11.1)	The Start and Stop commands as well as the direction of rotation are controlled via virtual digital signals of the control word.



Parameter *Local/Remote* **412** is dataset switchable, i.e. you can switch between the different operation modes by selecting another data set.

The data set switching can be effected locally via control contacts at the digital inputs of the frequency inverter or via the bus. For data set switching via the bus, parameter *Dataset selection* **414** is used.

Parameters		Settings		
No.	Description	Min.	Max.	Factory setting
414	<i>Data set selection</i>	0	4	0


With *Data set selection* **414** = 0, data set switching via contact inputs will be active. If *Data set selection* **414** is set to 1, 2, 3 or 4, the selected data set is activated and data set switching via the contact inputs is deactivated.

If *Data set selection* **414** is set to 5, data set switching via contact inputs will be active if the frequency inverter is not enabled.


Via parameter *Active data set* **249**, the currently selected data set can be read. *Active data set* **249**, indicates the active data set (value 1, 2, 3 or 4). This is independent of whether the data set switching was done via contact inputs or *Data set selection* **414**.

11.1 Control via contacts/remote contacts

In operation mode "Control via contacts" or "Control via remote contacts" (Parameter *Local/Remote* **412** = 0 or 2), the frequency inverter is controlled directly via digital inputs S1IND (STOA and STOB), S2IND through EM-S3IND or via the individual bits of the virtual digital signals in the control word. The function of these inputs is described in the frequency inverter user manual.



The digital inputs set via the control word can be monitored using parameter *Digital Inputs* **250**. Digital input S1IND will only be displayed if controller release is switched on at STOA and STOB **and** the control word (Bit 0) was set. If the data set switching function is used, please ensure that Parameter *Local/Remote* **412** is set to "2 – Control via remote contacts" is set in all data sets used.



If operation mode "Control via remote contacts" is used, controller release must be turned on at STOA (Terminal X210A.3) and STOB (Terminal X210B.2) **and** Bit 0 of the control word must be set in order to be able to start the drive. Operation modes "Control via contracts" and "Control via remote contacts" only support *modes of operation* = "velocity mode".



ACTIVE CUBE frequency inverters support an external 24 V power supply for the frequency inverter control electronics. Even when mains voltage is disconnected, communication between the controller (PLC) and the frequency inverter is still possible.


Bit 4 "Power supply – enabled" of the status word shows the current mains power supply status:

Bit 4 "Power supply – enabled" = 0 signals "No mains voltage", starting of drive not possible.

Bit 4 "Power supply – enabled" = 1 signals "Mains voltage on", drive ready for starting.

11.1.1 Device state machine

State machine:



Status word	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
Switched on	1	0	0	0	1	1
Operation enabled	1	1	0	1	1	1
Fault	x	x	1	x	x	x



"x" means any value.

Bit 7 "**Warning**" can display a device-internal warning message at any time. The current warning is evaluated by reading the warning status with parameter *Warnings* **270**.

Bit 10 "**Target reached**" is set when the specified reference value is reached. In the special case of power failure regulation, the bit is also set when the power failure regulation reaches the frequency 0 Hz (see frequency inverter Operating Instructions). For "Target reached", there is a hysteresis (tolerance range) which can be set via the parameter *Max. control deviation* **549** see frequency inverter operating instructions).

Bit 11 "**Internal limit value active**" indicates that an internal limit is active. This may be the current limit, the torque limit or the overvoltage control. All functions will result in the reference value being left or not reached.

Bit 15 "**Warning 2**" signals a critical operating state which will result in a fault switch-off of the frequency inverter within a short time. This bit is set if there is a delayed warning relating to the motor temperature, heat sink/inside temperature, Ixt monitoring or mains phase failure.


11.2 Control via state machine

In the operation mode “Control via state machine (*Local/Remote* **412** = 1), the frequency inverter is addressed via the control word of the state machine.

Transition 4 to status “Operation enabled” is only possible:

- If, in a configuration for positioning control (parameter *Configuration* **30** = x40), the controller release is set via STOA and STOB,
- If, in other configurations (parameter *Configuration* **30** ≠ x40) the controller release is set via STOA and STOB and if one of the digital inputs S2IND or S3IND is set. (Typically: S2IND = Start clockwise/S3IND = Start anticlockwise)


Parameter *Control word* **410** is applicable to the frequency inverter if parameter *Local/Remote* **412** is set to “1 – Control via statemachine”.



Bits 9 ... 15 are used depending on the configuration and on *Mode of Operation*.

Control word bits 4, 5, 6 “Depending on mode of operation” and bit 8 “Stop” are only used in positioning control configurations (Parameter *Configuration* **30** = x40).

The actual value parameter *Status word* **411** shows the current operating status.



Bit 14 is not used.

Status word bits 12 and 13 "Operation mode specific" are only used in positioning control configurations (Parameter *Configuration 30* = x40).



ACTIVE CUBE frequency inverters support an external 24 V power supply for the inverter control electronics. Even when mains voltage is disconnected, communication between the controller (PLC) and the frequency inverter is still possible.


Bit 4 "Voltage enabled" of the status word shows the current mains power supply status:

Bit 4 "Voltage enabled" = **0** signals "No mains voltage", starting of drive not possible.

Bit 4 "Voltage enabled" = **1** signals "Mains voltage on", drive ready for start.

11.2.1 State machine diagram

State machine:



Control word:

The device control commands are triggered by the following bit patterns in the status word.

Control word						
Command	Bit 7	Bit 3	Bit 2	Bit 1	Bit 0	Transitions
	Fault reset	Enable operation	Quick stop (Low active)	Enable voltage	Switch on	
Shutdown	X	X	1	1	0	2, 6, 8
Switch on	X	0	1	1	1	3
Enable operation	X	1	1	1	1	4
Disable voltage	X	X	X	0	X	7, 9, 10, 12
Quick stop (Low active)	X	X	0	1	X	7, 10, 11
Disable operation	X	0	1	1	1	5
Fault reset	0 → 1	x	x	x	x	15

"X" means any value.



Transition 3 (command "Switch On" [0x07]) will only be processed if Bit 4 "Voltage enabled" of the Status word is set.



Transition 4 (Command "Enable operation" [0xF]) will only be processed if the release is set via the hardware contacts STO.

If the hardware release via STO is not set, the frequency inverter will remain in status "Switched On" [0x33] until the hardware release via STO is present.

In status "Operation enabled" [0x37], the device will switch to status "Switched On" [0x33] internally once the hardware release via STO is reset.



In configurations **with** positioning control (parameter *Configuration 30* = x40), the following must be noted:

- Transition **4'** is **not** available.
- In status "5-Operation enabled [0x37]" an additional start signal must be provided via bits from the "High Byte" of the control word in order to start a movement of the motor. For a description of the start signal for this "Motion Control Interface" (MCI), refer to Chapter 11.4. Parameter *Override Modes Of Operation 1454* is available for switching to other MCI modes.
- Digital inputs (STOA and STOB) must be set. Start clockwise and Start anticlockwise have no function in these configurations.



In configurations **without** Motion Control (parameter *Configuration 30* ≠ x40), the following must be noted:

- Transition **4'** will only be processed if Bit 4 "Voltage enabled" of the status word is set. This feature is downward-compatible with older software versions.
- The frequency inverter can only be controlled if the logic operation is true. The logic inputs for Start Clockwise and Start anticlockwise can be connected directly with "On" or "Off" (parameter *Start Clockwise 68* and *Start Anticlockwise 69*). Digital inputs (STOA and STOB) must be set. This results in:
 - Release: (= STOA and STOB) **AND** (Start clockwise **OR** Start Anticlockwise)

Status word:

The status word indicates the operating status.

Status word						
State	Bit 6	Bit 5	Bit 3	Bit 2	Bit 1	Bit 0
	Switch on disabled	Quick stop (Low active)	Fault	Operation enabled	Switched on	Ready to switch on
Switch on disabled	1	X	0	0	0	0
Ready to switch on	0	1	0	0	0	1
Switched on	0	1	0	0	1	1
Operation enabled	0	1	0	1	1	1
Quick stop active	0	0	0	1	1	1
Fault reaction active	0	X	1	1	1	1
Fault	0	X	1	0	0	0



"X" means any value.

Bit 7 "**Warning**" can be set at any time. It reports a device-internal warning. The cause of the warning is evaluated by reading the warning status with parameter *Warnings* **270**.

Bit 9 "**Remote**" is set if the operation mode is set to "Control via state machine" (*Local/Remote* **412** = 1) **and** controller release is turned on.

Bit 10 "**Target reached**" is set when the specified reference value is reached. In configurations without Motion Control (parameter *Configuration* **30** ≠ x40) "Target reached" refers to the reference speed from auf Parameter *Override Target Velocity vl [rpm]* **1459**. In the special case of power failure regulation, the bit is also set when the power failure regulation reaches the frequency 0 Hz (see frequency inverter operating instructions).

For "Target reached", there is a hysteresis (tolerance range) which can be set via the parameter *Max. control deviation* **549** see frequency inverter Operating Instructions).

Bit 11 "**Internal limit value active**" indicates that an internal limit is active. This may be the current limit, the torque limit or the overvoltage control. All functions will result in the reference value being left or not reached.

Bit 15 "**Warning 2**" signals a critical operating state which will result in a fault switch-off of the frequency inverter within a short time. This bit is set if there is a delayed warning relating to the motor temperature, heat sink/inside temperature, Ixt monitoring or mains phase failure.

11.3 Configurations without positioning control

In configurations without positioning control (*Configuration 30* ≠ x40) *Override Modes Of Operation 1454* is set permanently to "2 - velocity mode". This setting cannot be changed.

Relevant parameters:


410	Control word
411	Status word
1459	Override Target velocity v_l [rpm]
240	Actual speed
418	Minimum frequency
419	Maximum frequency
420	Acceleration clockwise
422	Acceleration (anticlockwise)
421	Deceleration clockwise
423	Deceleration (anticlockwise)
424	Emergency stop (clockwise)
425	Emergency stop (anticlockwise)

The ramp times are specified via parameters 430...433.

11.3.1 Behavior in the case of a quick stop

In quick stop, the parameters *Switch-Off Threshold 637* (percent of parameter *Maximum Frequency 419*) and *Holding time 638* (holding time after falling short of the Switch-Off Threshold) are relevant. *Maximum Frequency*. In the case of a quick stop, the drive is stopped via emergency stop ramps.

The emergency stop ramps are set via parameters *Emergency Stop Clockwise 424* and *Emergency Stop Anticlockwise 425*.



If frequency/speed reaches the value zero during the switch-off time, the drive continues to be supplied with current until the switch-off time has elapsed. This ensures that the drive is at a standstill when the state changes.



The quick stop behavior is only relevant for configurations without Motion Control (parameter *Configuration 30* ≠ x40).

11.3.2 Behavior in the case of transition 5 (disable operation)

The behavior in transition 5 from "Operation enabled" to "Switched On" can be configured via parameter *State transition 5* **392**.

Parameters		Settings		
No.	Description	Min.	Max.	Factory setting
392	State transition 5	0	2	2

Operation mode	Function
0 -Coast to stop	Immediate transition from "Operation enabled" to "Switched On", drive coasts to a standstill
1 -DC brake	Activation of DC brake, at the end of DC deceleration, there is the change from "Operation enabled" to "Switched On"
2 -Ramp	Transition with normal ramp, when the drive has come to a standstill, there is the change from "Operation enabled" to "Switched On"



Setting 1 "Direct current brake" is only possible with applications with U/f characteristic control (e.g. configuration 110). Other configurations do not support this operation mode.

If the frequency inverter is operated with a configuration which does not support the operation mode Direct Current Brake (e.g. configuration 210, field-oriented control), value "1" cannot be used.

In this case, the operation mode is not offered in the selection menus of the control unit KP500 and the control software VPlus.



By default, *State-transition 5* **392** is set to operation mode "2 - Ramp" For configurations with torque control, the default value is "0 - coasting".

If the configuration is changed, the value set for *State-transition 5* **392** is also changed, if necessary.



The behavior in transition 5 is only relevant for configurations without Motion Control (parameter *Configuration* **30** ≠ x40).

If *State-transition 5* **392** was triggered with "1 - DC brake", a new control word will only be accepted after completion of the transition process. The change of state from "Operation enabled" to "Started" is done after the *Braking time* **632** parameterized for the DC brake has elapsed.

If parameter *State-transition 5* **392** = "2 - Ramp" is set, the control word can be set to "Operation enabled" again, while the drive is decelerating. In this way, the drive accelerates to its set reference value again and remains in the state "operation enabled".

The change of state from "Operation enabled" to "Switched On" is done after the value has dropped below the set Switch-Off Threshold and the set holding time has elapsed (equivalent to the behavior in the case of a quick stop). In this context, parameters *Switch-Off Threshold stop function* **637** (percentage of parameter *Maximum Frequency* **419**) and *Holding time* **638** (Holding time after passing of threshold) are relevant.

11.3.3 Reference value/actual value

Depending on the settings of Local/Remote as well as Modes of Operations, the controller (PLC) can define the reference frequency for the frequency inverter via parameter *Reference frequency RAM [Hz]* **484** or *Override Target Velocity vl [rpm]* **1459** and receive the actual value via parameter *Actual speed* **240**.


The use of the reference/actual value channel depends on the set configuration (control method). The actual value is generated according to the control method use.



The reference value in parameter *Override Target Velocity vl [rpm]* **1459** and the actual value in parameter *Actual speed* **240** are interpreted as values with unit $[\text{min}^{-1}]$. Conversion into a frequency value (reference value) or from a frequency value (actual value) is performed in the frequency inverter.

The entry for parameter *Reference frequency RAM [Hz]* **484** is done in [Hz] directly.

The reference value for the frequency inverter from parameter *Reference frequency RAM [Hz]* **484** or *Override Target Velocity vl [rpm]* **1459** is connected to the reference line value. This reference value will be combined with the internal reference value from the reference frequency channel and directed to the ramp. For information on the reference frequency channel, refer to the operating instructions of the frequency inverter.



Reference percentage **524** can be used for regular changing of reference percentages, e.g. as a reference value for technology controllers or as a reference torque.

Parameters		Settings		
No.	Description	Min.	Max.	Factory setting
434	Ramp Setpoint	1	3	3
484	Reference frequency RAM [Hz]	-999.99	999.99	0.00
524	Reference percentage RAM [%]	-300.00	300.00	0.00

Operation mode 434	Function
1 - Internal reference frequency	The internal reference frequency is determined from the reference frequency channel.
2 - Reference line value	The reference value is supplied externally via the bus
3 - Internal reference frequency + reference line value	Addition (considering the sign) of internal reference frequency and reference line value



This function is only relevant in the case of configurations without positioning control (parameter *Configuration* **30** \neq x40).



If *Ramp Setpoint 434* = 2 (reference line value only), this reference line value is limited to f_{min} .

The sign in front of f_{min} with reference value = 0 is derived from the sign in front of the last reference line value which was not 0.

After Mains On, the reference line value is limited to $+f_{min}$.

For *Ramp Setpoint 434* = 3, the sign of the total reference value results from the total of internal reference frequency and reference line value.

The reference values can be controlled at the frequency inverter via the control unit or the control software VPlus via the following parameters:

Actual values		
Parameters	Contents	Format
<i>Internal reference frequency 228</i>	Internal reference value from the reference frequency channel	xxx.xx Hz
<i>Bus reference frequency 282</i>	Reference line value from Field bus	xxx.xx Hz
<i>Ramp reference frequency 283</i>	= sum of internal reference frequency + reference line value	xxx.xx Hz

11.3.4 Example sequence

In configurations without Motion Control (*Configuration 30* \neq x40), the PLC must send the correct sequence:

1	Control word =	0x0000	Disable voltage
2	Control word =	0x0006	Shut down
3	Control word =	0x0007	Switch On
4	Control word =	0x000F	Enable operation

OR

1	Control word =	0x0000	Disable voltage
2	Control word =	0x000F	Enable operation



In configurations without positioning control (*Configuration 30* \neq x40), the second (shortened) sequence can be used, because transition **4'** is available in these configurations.

11.4 Configurations with position control



WARNING

Dangerous state due to new mode!

If *Override Modes Of Operation 1454* is changed during operation (control word = 0xnnnF), a dangerous state may occur in the new mode.

- Before changing *Override Modes Of Operation 1454*, check the status word (e.g. for status 0xnn33).



Definition Motion Control

For the full function of the Motion Control Interfaces/Motion Control Override, you will have to set *Local/Remote 412* = "1-Control via state machine". In all other operation modes of parameter *Local/Remote 412*, there are major restrictions. The descriptions in this chapter and of all objects used are based on the setting *Local/Remote 412* = "1-Control via state machine".



The usage of Positioning for setting *Local/Remote 412* \neq 1 is described in the "Positioning" application manual.

The function of the state machine describes the basic operating behavior of the frequency inverter in configurations with position control (*Configuration 30* = x40). The parameters described in 11.2 "Control via state machine", i.e. *Control word 410* and *Status word 411* support the bits marked as operation mode specific.

These bits and bit "Target reached" has different meanings in the different position control operation modes – defined by *Override Modes Of Operation 1454*. The following chapters describe the application of the operation mode specific bits in the *control word* and *status word*, depending on the different position control operation modes. Default value of *Override Modes Of Operation 1454*: "2 – velocity mode".

Basic functions:

The state machine must be set to "operation enabled", before the position command can be issued via the operation mode specific bits of the *control word*.

The bits in the *control word* and *status word* marked as operation mode specific are only supported in configurations with position control (*Configuration 30* = x40).


11.4.1 Velocity mode [rpm]


“Velocity mode” can be selected via parameter *Override Modes Of Operation* **1454** = **2**. In velocity mode, the mode-specific bits of the control word control the ramp generator (RFG – Ramp Function Generator). The block diagram illustrates the function.

Relevant parameters:


410	<i>Control word</i>
411	<i>Status word</i>
1459	<i>Override Target velocity vl [rpm]</i>
240	<i>Actual speed</i>
418	<i>Minimum Frequency</i>
419	<i>Maximum Frequency</i>
420	<i>Acceleration (Clockwise)</i>
422	<i>Acceleration Anticlockwise</i>
421	<i>Deceleration (Clockwise)</i>
1454	<i>Override Modes Of Operation</i>

The ramp times are specified via parameters **430...433**.





Block diagram



Bit 4:rfg enable

Rfg enable = 0 The reference speed comes from a manufacturer-specific special function.

Rfg enable = 1 The reference speed corresponds to the ramp output.



The special function will only be evaluated if *S. Special Function Generator 1299* is not "9-zero".

If *S. Special Function Generator 1299* = "9-Zero", the value of the ramp output will always be used.

If *S. Special Function Generator 1299* ≠ "9-Zero", the reference value from the ramp output will also be used if bit 4 "rfg enable" = 1, and if bit 4 "rfg enable" = 0, the reference value from the source specified in *1299 S. Special Function Generator*.

Reference value source		
	<i>S. Special Function Generator 1299</i> ≠ "9-Zero"	<i>S. Special Function Generator 1299</i> = "9-Zero"
Bit 4 rfg enable = 0	Reference value from special function	Reference value from ramp output
Bit 4 rfg enable = 1	Reference value from ramp output	

Bit 5:rfg unlock

Rfg unlock = 0 The last speed will be maintained and used.

Rfg unlock = 1 The ramp function is active and changes according to the reference value and the ramp.

Bit 6/rfg use ref

Rfg use ref = 0 Reference value "0" is used.

Rfg use ref = 1 The reference value from *Override Target Velocity vl [rpm] 1459* is used.

Bit 8 HALT

HALT = 0 → Execute positioning.

HALT = 1 → Stop axis. (The frequency inverter remains enabled in "Operation enabled" state.)

11.4.1.1 Example sequence

In order to start "velocity mode", the correct sequence must be sent by the PLC.

1	Control word = 0x0000	Disable voltage
1	Status word = 0x0050	Switch On Disabled
2	Modes of operation = 2	(Velocity mode)
3	Control word = 0x0006	Shutdown
	Status word = 0x0031	Ready to switch on
4	Control word = 0x0007	Switch On
	Status word = 0x0033	Switched On
5	Control word = 0x000F	Enable operation, no change of previous status if already enabled.
	Status word = 0xnn37	Operation enabled
6a	Control word = 0x007F	Starts "Velocity mode" with reference value from parameter <i>Override Target Velocity vl [rpm]</i> 1459 .
	Status word = 0xnn37	Operation enabled
6b	Control word = 0x006F	1299 S. Special Function Generator: = "9-Zero" ➔ Starts "Velocity mode" with reference value from parameter <i>Override Target Velocity vl [rpm]</i> 1459 . 1299 S. Special Function Generator: ≠ "9-Zero" ➔ Starts with reference value with source from 1299 S. Special Function Generator
	Status word = 0xnn37	Operation enabled
6C	Control word = 0x003F	Starts "Velocity mode" with reference value "0"
	Status word = 0xnn37	Operation enabled
6d	Control word = 0x002F	1299 S. Special Function Generator: = "9-Zero" ➔ Starts "Velocity mode" with reference value "0" 1299 S. Special Function Generator: ≠ "9-Zero" ➔ Starts with reference value with source from 1299 S. Special Function Generator
	Status word = 0xnn37	Operation enabled
6E	Control word = 0x005F	Starts "Velocity mode" at current speed – current ramps will be canceled.
	Status word = 0xnn37	Disable voltage
6f	Control word = 0x004F	1299 S. Special Function Generator: = "9-Zero" ➔ Starts "Velocity mode" at current speed – current ramps will be canceled. 1299 S. Special Function Generator: ≠ "9-Zero" ➔ Starts with reference value from source from 1299 S. Special Function Generator
	Status word = 0xnn37	Disable voltage
7	Control word = 0x01xx	HALT: The drive is decelerated at the ramp <i>Deceleration (Clockwise)</i> 421 or <i>Deceleration Anticlockwise</i> 423 .
	Status word = 0xnn37	Operation enabled


⚠ WARNING
Dangerous state due to new mode!

If *Override Modes Of Operation 1454* is changed during operation (control word = 0xnnnF), a dangerous state may occur in the new mode.

- Before changing *Override Modes Of Operation 1454*, check the status word (e.g. for status 0xnn33).



Once the sequence of the first four status words has been processed correctly, the ACU is ready for operation (dark table area).

In state "operation enabled" (0xnnnF), the state of the Motion Control can be changed (white table area).

With control word transition from 0xnnF to 0x000F, "Velocity mode" will be stopped.

Then, the mode can be restarted via 0xnnF.

As long as 0x0007 is active, the "Modes of Operation" can also be changed safely. Once *Override Modes Of Operation 1454* has been set to another value, operation can be started with a corresponding sequence.

11.4.2 Profile Velocity mode [u/s] (pv)

"Profile velocity mode" (pv) can be selected via *Override Modes Of Operation 1454 = 3*.


In "Profile velocity mode" (pv), the frequency inverter receives a target speed in user units per second [u/s].


Relevant parameters:

410 <i>Control word</i>	1276 <i>Velocity Window</i>
411 <i>Status word</i>	1277 <i>Velocity Window Time</i>
418 <i>Minimum Frequency</i>	1278 <i>Threshold Window</i>
419 <i>Maximum Frequency</i>	1279 <i>Threshold Window Time</i>
1107 <i>Act. Speed</i>	1454 <i>Override Modes Of Operation</i>
1176 <i>Ramp time Accel.</i>	1457 <i>Override Profile Acceleration</i>
1178 <i>Ramp time Decel.</i>	1458 <i>Override Profile Deceleration</i>
1179 <i>Emergency ramp</i>	1460 <i>Override Target Velocity pv [u/s]</i>
1275 <i>Max Slippage</i>	

The ramp times are specified via parameters **1176** and **1178**.

In "Profile velocity mode" (pv), the mode-specific bits of the control word and the status word are used as follows:





Profile velocity mode enables setting of a reference speed in units per second [u/s]. The reference speed *Override Target Velocity pv [u/s]* **1460** will be applied immediately in status "Operation enabled" (0xnn37). The acceleration and deceleration ramps are set via parameters *Override Profile Acceleration* **1457** and *Override Profile Deceleration* **1458**.

If bit 8 "Halt" of the control word is set, the drive will be decelerated and kept at a standstill at the ramp set in parameter *Override Profile Deceleration* **1458**. If bit 8 is reset, the drive will be accelerated to the current reference speed at the ramp set in parameter *Override Profile Acceleration* **1457**.

Control word Bit 8: Halt

HALT = 0 → Execute Profile Velocity Mode.

HALT = 1 → Halt Axis. (The Frequency inverter remains in state "Operation enabled".)



The current speed in user units per second [u/s] can be displayed in a controller via parameter *Velocity Window* **1276**.

Via parameter *Velocity Window* **1276** and *Velocity Window Time* **1277** Bit 10 "Target reached" of the status word is set.

Via parameter *Threshold Window* **1278** and *Threshold Window Time* **1279** Bit 12 "Velocity" of the status word is set.

Via parameter *Max Slippage* **1275** a slip monitoring via Bit 13 "Max Slippage" of the status word can be set up.

Status word bit 10: Target reached

Target reached = 0 → The actual velocity doesn't match the reference velocity.

Target reached = 1 → **The actual velocity matches the reference velocity.**

The actual velocity differs at least from the defined time period in *Velocity Window Time* **1277** up to the defined amount [us] in *Velocity Window* **1276**.

Status word Bit 12: Velocity

Velocity → **The Actual Velocity matches the comparison speed.**

= 0 The Actual Velocity has exceeded for a defined time (*Threshold Window Time* **1279**) a defined Velocity in user units per seconds [u/s] (*Threshold Window* **1278**).

Velocity → The Actual Velocity doesn't match the Comparison Velocity.

= 1

Status word bit 13: Maximum slippage

Maximum slippage = 0 → **The actual Slippage speed is smaller than defined.** The comparison value of the slippage speed is defined Object *Max Slippage* **1275**.

Maximum slippage = 1 → **The actual Slippage speed is bigger than defined.** The comparison value of the slippage speed is defined *Max Slippage* **1275**.

11.4.2.1 Example sequence

In order to start "Profile velocity mode", the correct sequence must be sent by the PLC.

1	Control word = 0x0000	Disable voltage
1	Status word = 0x0050	Switch On Disabled
2	Modes of Operation = 3	Profile Velocity mode
3	Control word = 0x0006	Shutdown
	Status word = 0x0031	Ready to switch on
4	Control word = 0x0007	Switch On
	Status word = 0x0033	Switched On
5	Control word = 0x0007 ↓ 0x000F	Enable operation. Profile velocity mode is started at the target speed <i>Override Target Velocity pv [u/s]</i> 1460 and the ramps <i>Override Profile Acceleration</i> 1457 and <i>Override Profile Deceleration</i> 1458 . Target speed and ramp values are applied immediately.
	Status word = 0xnn37	Operation enabled

1) A profile comprises the following entries. If a value is not changed, the old value will remain active.

- **1456** *Override Profile Velocity*
- **1457** *Override Profile Acceleration*
- **1458** *Override Profile Deceleration*
- **1460** *Override Target Velocity pv [u/v]*

WARNING



Dangerous state due to new mode!

If *Override Modes Of Operation* **1454** is changed during operation (control word = 0xnnnF), a dangerous state may occur in the new mode.

- Before changing *Override Modes Of Operation* **1454**, check the status word (e.g. for status 0xnn33).



Once the sequence of the first four status words has been processed correctly, the ACU is ready for operation (dark table area).

In state "operation enabled" (0xnnnF), the state of the Motion Control can be changed (white table area).

As long as 0x0007 is active, the "Modes of Operation" can also be changed safely. Once *Override Modes Of Operation* **1454** has been set to another value, operation can be started with a corresponding sequence.

11.4.3 Profile position mode


“Profile position mode” can be selected via *Override Modes Of Operation* **1454 = 1**.
In profile position mode, the frequency inverter receives a target position, followed by the command to travel to this target.


Relevant parameters:

410 <i>Control word</i>	1455 <i>Override Target Position</i>
411 <i>Status word</i>	1456 <i>Override Profile Velocity</i>
418 <i>Minimum Frequency</i>	1457 <i>Override Profile Acceleration</i>
419 <i>Maximum Frequency</i>	1458 <i>Override Profile Deceleration</i>
1454 <i>Override Modes Of Operation</i>	1179 <i>Emergency ramp</i>

The ramp times are specified via parameters **1176** and **1178**.

In “Profile position mode”, the mode-specific bits of the control word and the status word are used as follows:





Control word

Change on set-point Bit 9	Change set-point immediately Bit 5	New set-point Bit 4	Description
0	0	0 → 1	Positioning operation to be completed (target reached) before the next one is started.
X	1	0 → 1	Next positioning operation to be started immediately.
1	0	0 → 1	Positioning operation to be started with the current speed profile until the current reference value is reached, then, the next positioning operation is to be processed.

Identification	Value	Description
Abs/rel Bit 6	0	<i>Override Target Position 1455</i> is an absolute value.
	1	<i>Override Target Position 1455</i> is a relative value.
Halt Bit 8	0	Execute positioning operation.
	1	Stop axis with <i>Override Profile Deceleration 1458</i> (if not supported with <i>Override Profile Acceleration 1457</i>), the frequency inverter will remain in status "Operation enabled".

Status word

Identification	Value	Description
Target reached Bit 10	0	Halt (control bit 8) = <i>Override target position 1455</i> 0: not reached (yet). See also chapter 10.2.4 "Target window".
		Halt (control bit 8) = Axis decelerated 1:
	1	Halt (control bit 8) = <i>Override target position 1455</i> 0: reached. See also chapter 10.2.4 "Target window".
		Halt (control bit 8) = Speed of axis is 0 1:
Reference value confirmed Bit 12	0	The travel profile calculation has not applied the position value (yet).
	1	The travel profile calculation has applied the position value.
Contouring error Bit 13	0	No contouring error.
	1	Contouring error.


Example:

Individual reference value

Control bit "Switch at reference value" = 0

Control bit "Change reference value immediately" = 0


Once a reference value has been transmitted to the drive, the controller signals a permissible value in the control work by a rising signal edge for the bit "New reference value". The drive responds by setting the bit "Reference value confirmed" and starts moving to the new target position. After that, the controller resets the bit "New reference value", and the drive resets the bit "Reference value confirmed". Once the bit "Reference value confirmed" has been reset, the drive is ready for receiving a new target position.



Example:
single set-point

control bit *change on set-point* = 0
control bit *change set immediately* = 1

A new reference value is confirmed by the control bit "New reference value" (rising edge) while a reference value is being processed. The new reference value is processed immediately.



Example: set of set-points


 control bit *change on set-point* = 0/1

 control bit *change set immediately* = 0

The travel profile is changed during an active positioning operation.

Change on set point = 0 The current target position is approached with a **Stop**. Once the position has been reached, the new reference value is set.

Change on set point = 1 The current target position is approached at the active speed. Once the current target position has been reached, the new reference value is applied without reducing the speed to zero.



11.4.3.1 Example sequence

In order to start "Profile position mode", the correct sequence must be sent by the PLC.

1	Control word = 0x0000 Status word = 0x0050	Disable voltage Switch On Disabled
2	Modes of Operation = 1	(Profile Position mode)
3	Control word = 0x0006 Status word = 0x0031	Shutdown Ready to switch on
4	Control word = 0x0007 Status word = 0x0033	Switch On Switched On
5	Control word = 0x0007 ↓ 0x000F Status word = 0xnn37	Enable operation. Positioning operation is not started. Operation enabled
6a	Control word = 0x0007 or 0x000F ↙ ↘ 0x001F Status word = 0xnn37	Operation enabled, start absolute positioning with profile ¹⁾ . If a positioning operation is already in process, this operation will be completed. Then, the new profile will be used. Operation enabled
6b	Control word = 0x0007 or 0x000F ↙ ↘ 0x005F Status word = 0xnn37	Operation enabled, start relative positioning with profile ¹⁾ . If a positioning operation is already in process, this operation will be completed. Then, the new profile will be used. Operation enabled
6c	Control word = 0x0007 or 0x000F ↙ ↘ 0x003F Status word = 0xnn37	Operation enabled, start absolute positioning with profile ¹⁾ . Running positioning operations will be changed and apply the new profile Operation enabled
6d	Control word = 0x0007 or 0x000F ↙ ↘ 0x007F Status word = 0xnn37	Operation enabled, start relative positioning with profile ¹⁾ . Running positioning operations will be changed and apply the new profile Operation enabled
7	Control word = 0x01nF Status word = 0xnn37	HALT: The drive is decelerated at the ramp set in <i>Deceleration (clockwise) 421</i> or <i>Deceleration anticlockwise 423</i> . Operation enabled

1) A profile comprises the following entries. If a value is not changed, the old value will remain active.

- **1455** *Override Target Position*
- **1456** *Override Profile Velocity*
- **1457** *Override Profile Acceleration*
- **1458** *Override Profile Deceleration*

 **WARNING**



Dangerous state due to new mode!

If *Override Modes Of Operation 1454* is changed during operation (control word = 0xnnnF), a dangerous state may occur in the new mode.

- Before changing *Override Modes Of Operation 1454*, check the status word (e.g. for status 0xnn33).



Once the sequence of the first four status words has been processed correctly, the ACU is ready for operation (dark table area).

In state "operation enabled" (0xnnnF), the state of the Motion Control can be changed (white table area).

With control word transition from 0xnnF to 0x000F, "Profile position mode" will be stopped. Then, the mode can be restarted via 0xnnF.

As long as 0x0007 is active, the "Modes of Operation" can also be changed safely. Once *Override Modes Of Operation 1454* has been set to another value, operation can be started with a corresponding sequence.



In order to start a profile, you don't have to set the control word to 0x0007 first.

Once a profile has been processed, a new profile can be started with the bit "New reference value" (bit 4) in control word 0xnnnF.

While a profile is being processed, you can start a new profile without stopping by using the bits "Change reference value immediately" (bit 5) and "New reference value" (bit 4).

11.4.4 Homing mode


“Homing mode” can be selected via parameter *Override Modes Of Operation 1454*. In homing mode, the frequency inverter moves the drive to a reference position. The method used for this movement is defined by parameter *Homing mode 1130*.


Relevant parameters:

410	<i>Control word</i>	1130	<i>Homing mode</i>
411	<i>Status word</i>	1132	<i>Fast speed</i>
418	<i>Minimum Frequency</i>	1133	<i>Creep speed</i>
419	<i>Maximum Frequency</i>	1134	<i>Acceleration</i>
1454	<i>Override Modes Of Operation</i>		

The ramp times are specified via parameter *Ramp time 1135*.

In homing mode, the mode-specific bits of the control word and the status word are used as follows:





Control word

Identification	Value	Description
Homing operation start Bit 4	0	Homing not active.
	0 → 1	Start homing with <i>Acceleration 1134</i> and <i>Fast Speed 1132</i> and <i>Creep Speed 1133</i> .
	1	Homing active.
	1 → 0	Stop homing.
Halt Bit 8	0	Execute command from bit 4 "Start homing".
	1	Stop axis with acceleration value (as deceleration) for homing. (The frequency inverter remains enabled in "Operation enabled" status.)

Status word

Identification	Value	Description
Target reached Bit 10	0	Halt = 0: Home position (still) not reached. Halt = 1: Axis decelerated.
	1	Halt = 0: Home position reached. Halt = 1: Axis has speed 0.
Homing attained Bit 12	0	Homing not completed yet.
	1	Homing completed successfully.
Homing error Bit 13	0	No homing error.
	1	Homing error occurred, homing not completed successfully.

For a description of homing operations, refer to the Application manual "Positioning".

11.4.4.1 Example sequence

In order to start "homing mode", the correct sequence must be sent by the PLC.

1	Control word = 0x0000	Disable voltage
1	Status word = 0x0050	Switch On Disabled
2	Modes of operation = 6	(Homing)
3	Control word = 0x0006	Shutdown
	Status word = 0x0031	Ready to switch on
4	Control word = 0x0007	Switch On
	Status word = 0x0033	Switched On
5	Control word = 0x000F	Enable operation.
	Status word = 0xnn37	Operation enabled
6a	Control word = 0x001F	Enable operation and start homing.
	Status word = 0x1n37	Operation enabled and homing attained.

WARNING

Dangerous state due to new mode!

If *Override Modes Of Operation 1454* is changed during operation (control word = 0xnnnF), a dangerous state may occur in the new mode.

- Before changing *Override Modes Of Operation 1454*, check the status word (e.g. for status 0xnn33).



Once the sequence of the first four status words has been processed correctly, the ACU is ready for operation (dark table area).

In state "operation enabled" (0xnnnF), the state of the Motion Control can be changed (white table area).

With control word transition from 0x0007 (or 0x000F) to 0x001F the homing operation is started. "Home position set" - Bit 12 returns the status in the status word.

As long as 0x0007 is active, the "Modes of Operation" can also be changed safely. Once *Override Modes Of Operation 1454* has been set to another value, operation can be started with a corresponding sequence.

11.4.5 Table travel record

“Table travel record mode” can be selected via parameter *Override Modes Of Operation 1454*.

In “Table travel record mode”, the drive moves to successive positions automatically.


“Table travel record mode” uses pre-defined positions. Each target position is defined by a motion block. Several motion blocks can be defined.


For a description of motion blocks, refer to the Application manual “Positioning”.

Relevant parameters:

410	<i>Control word</i>	1108	<i>Act. Position</i>
411	<i>Status word</i>	1106	<i>Error Threshold</i>
418	<i>Minimum Frequency</i>	1119	<i>Contouring Error Time</i>
419	<i>Maximum Frequency</i>	1165	<i>Target Window</i>
1454	<i>Override Modes Of Operation</i>	1166	<i>Target Window time</i>
1246	<i>Actual Motion Block</i>	1179	<i>Emergency ramp</i>
1249	<i>Motion Block to Resume</i>		

In “Table travel record mode” the mode-specific bits of the control word and the status word are used as follows:





Control word

Identification	Value	Description
Sequence mode Bit 4	0	Single motion.
	1	Automatic sequence.
Resume Bit 6	0	Start motion block = motion block switching.
	1	Start motion block = last Actual Motion Block The motion block which is resumed can be read via object 1249 .
Halt Bit 8	0	Execute command from bit 4 "Automatic sequence".
	1	Stop axis at ramp of current motion block The frequency inverter remains in "Operation – enabled" status.
Start motion block Bit 9	0	Stop axis at ramp of current motion block.
	0 → 1	Execute motion block(s).
Motion block select 0...4 Bit 11...15	n	Start motion block = n + 1.

Motion block select

Control word															
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Motion block select						Sta	Halt		Res		Seq				
4	3	2	1	0											

Start motion block = motion block select + 1

Motion block select					Resulting start motion block
4	3	2	1	0	
0	0	0	0	0	1
0	0	0	1	1	4
1	0	0	0	0	17
1	1	1	1	1	32

Status word

Identification	Value	Description
Motion block in progress Bit 8	0	Single motion: Motion block complete. Automatic sequence: Sequence complete.
	1	Single motion/automatic sequence active.
Target reached Bit 10	0	Halt (control bit 8) = 0: Target position not reached yet (only motion blocks with positioning). See also chapter 10.2.4 "Target window".
		Halt (control bit 8) = 1: Axis decelerated.
	1	Halt (control bit 8) = 0: Target position reached (only motion blocks with positioning). See also chapter 10.2.4 "Target window".
		Halt (control bit 8) = 1: Axis has speed 0.
In gear Bit 12	0	Electronic gear not in gear.
	1	Electronic gear in gear.
Following error Bit 13	0	No contouring error.
	1	Contouring error.

Basic functions

The control bit "Automatic sequence" defines if a single motion (*Automatic sequence* = 0) or and automatic motion block sequence (*Automatic sequence* = 1) is to be executed.

In both cases, the selection of the required motion block (motion block number of single motion or start motion block number of automatic sequence) is calculated by the motion block switching feature with the rising edge of "*Start motion block*".

"Motion block is being processed" is set to "1" while a selected motion block or an automatic sequence is being executed. "Motion block is being processed" will remain set until the motion block sequence is complete. When a single motion block is executed, "Motion block is being processed" will be set to "0" once the single motion block is complete. When an automatic sequence is executed, "Motion block is being processed" will be set to "0" once a motion block with setting 0 for Next motion block (end of motion block), -1 (error stop), -2 (Stop, error) or -3 (emergency stop, error) is reached.

During the automatic processing of motion blocks, the currently processed motion block is indicated by parameter *Actual Motion Block* **1246**.

If the execution of motion blocks is interrupted by setting "Start motion block" to "0", the drive will stop at the ramp set in the current motion block. The interrupted motion block or automatic motion block sequence can be continued by setting "Resume" and a falling signal edge for "Start motion block". If "Resume" is set to "1" and no valid motion block is available, the motion block selected by the motion block switching function will be used. A valid motion block is indicated by parameter *Motion block to Resume* **1249**. *Motion block to Resume* **1249** reads -1, if no valid motion block is present or if the last motion block or motion block sequence was not interrupted.


"Target reached" is set if the actual position of motion blocks with absolute or relative positioning reaches the *position window*.

"In Gear" is set when the electronic gear function is used and electronic gear synchronous running is reached.


Setting *Halt* "1" will stop a currently executed motion block. The axis is stopped at the ramp set in the current motion block. "Target reached" is set to "1" when the speed reaches value 0. The drive remains in "Operation – enabled" status. To continue the interrupted motion block, reset *Halt* to "0".

Examples:

“single motion block” sequence mode (control bit 4) = 0
2 motion blocks 7 + 10



"_motion block sequence" sequence mode (control bit 4) = 1
 sequence = motion block 4, 5, 6




Interrupted motion blocks sequence

Automatic sequence (control bit 4) = 1,

Sequence = Motion block 4, 5, 6

Motion block 5 interrupted



11.4.5.1 Example sequence

In order to start "Table travel record mode", the correct sequence must be sent by the PLC.

1	Control word = 0x0000	Disable voltage
1	Status word = 0x0050	Switch On Disabled
2	Modes of operation = -1	(Table travel record mode)
3	Control word = 0x0006	Shutdown
	Status word = 0x0031	Ready to switch on
4	Control word = 0x0007	Switch On
	Status word = 0x0033	Switched On
5a	Control word = 0x000F	Enable operation
	Status word = 0xnn37	Operation enabled
5b	Control word = 0x020F	Start motion block 1 as single motion block
	Status word = 0xn337	Operation enabled and Positioning active.
	Status word = 0xn637	Operation enabled and Target reached.
5c	Control word = 0x0A0F	Start motion block 2 as single motion block
	Status word = 0xn337	Operation enabled and Positioning active.
	Status word = 0xn637	Operation enabled and Target reached.
5d	Control word = 0x120F	Start motion block 3 as single motion block
	Status word = 0xn337	Operation enabled and Positioning active.
	Status word = 0xn637	Operation enabled and Target reached.
5E	Control word = 0x021F	Start motion block 1 as sequence motion block
	Status word = 0xn337	Operation enabled and Positioning active.
	Status word = 0xn637	Operation enabled and Target reached.
5f	Control word = 0x004F	Resume previous motion block as single motion block
	Status word = 0xn337	Operation enabled and positioning active.
	Status word = 0xn637	Operation enabled and target reached.
5g	Control word = 0x005F	Resume previous motion block as sequence motion block
	Status word = 0xn337	Operation enabled and positioning active.
	Status word = 0xn637	Operation enabled and target reached.

WARNING

Dangerous state due to new mode!

If *Override Modes Of Operation 1454* is changed during operation (control word = 0xn00F), a dangerous state may occur in the new mode.

- Before changing *Override Modes Of Operation 1454*, check the status word (e.g. for status 0xnn33).



Once the sequence of the first four status words has been processed correctly, the ACU is ready for operation (dark table area).

In state "operation enabled" (0xn00F), the state of the Motion Control can be changed (white table area).

Bit 9 "Start motion block" must be active during positioning. If bit 9 is reset to "0", the positioning operation is interrupted.

As long as 0x0007 is active, the "Modes of Operation" can also be changed safely. Once *Override Modes Of Operation 1454* has been set to another value, operation can be started with a corresponding sequence.

11.4.6 Move away from limit switch mode


“Move away from limit switch mode” can be selected via *Override Modes Of Operation* **1454 = -2**.


In “Move away from limit switch mode”, the drive moves back from a triggered limit switch to the permissible travel range.

Relevant parameters:

410 <i>Control word</i>	1454 <i>Override Modes Of Operation</i>
411 <i>Status word</i>	1179 <i>Emergency ramp</i>
418 <i>Minimum Frequency</i>	1133 <i>Creep speed</i>
419 <i>Maximum Frequency</i>	1134 <i>Acceleration</i>

In “Move away from limit switch mode”, the mode-specific bits of the control word and the status word are used as follows:





NOTE

“Move away from limit switch mode” will always work with hardware limit switches. In the case of software limit switches, the mode will only work if a software limit switch *Fault reaction 1144* with error stop was selected. If a setting with warning (e.g. “10-Warning”) was selected, the software limit switch will not trigger an error, thus “Move away from limit switch mode” will not clear the software limit switch.

NOTE

“Move away from limit switch mode” must not be used when one of the following error messages occurs:

- F1444 Pos. limit switch < Neg. limit switch
- F1445 Both limit switches at the same time
- F1446 Wrong limit switch wiring

If one of these errors has occurred, the wiring and parameter settings must be checked first before resuming operation.

Control word

Identification	Value	Description
Move away from limit switch mode Bit 4	0	Do not start or stop movement.
	1	Start (or resume) movement from limit switch to travel range.
Halt Bit 8	0	Execute command from bit 4 "Move away from limit switch".
	1	Stop axis with ramp of current motion block (The frequency inverter remains enabled in "Operation enabled" status).

Status word

Identification	Value	Description
Target reached Bit 10	0	Halt = 0: Limit switch still active
		Halt = 1: Axle decelerated
	1	Halt = 0: Limit switch cleared
		Halt = 1: Axle has speed 0

Basic functions

In mode -2 "Move away from limit switch", the drive is cleared from a triggered hardware limit switch or software limit switch. The direction of rotation depends on the active limit switch: If the positive limit switch is active, the drive moves to negative direction and vice versa.

"Move away from limit switch" mode is started in status "Operation enabled" by control word bit 4 "Move away from limit switch". The drive is accelerated to the speed from parameter *Creep speed 1133* at the ramp set in *Acceleration 1134*. Once the active limit switch has been cleared, the drive is stopped. Once speed 0 has been reached, status word bit 10 "Target reached" will be set.

When both directions of rotation are blocked, e.g. due to simultaneous triggering of positive and negative hardware limit switch, error message "F1449 Both directions of rotation disabled". In this case, the function "Move away from limit switch" cannot be used.

NOTE

In the clearing phase of a hardware limit switch, the hysteresis defined in parameter *Hysteresis 1149* will be active. After detection of the limit switch edge, the axis will be moved on, at least by the defined hysteresis distance.

Setting *Halt* to "1" will stop the started clearing operation. The axis will be stopped. Status bit "Target reached" is set to "1" when the speed reaches value 0. The drive remains in "Operation enabled" status. By resetting *Halt* to "0", the interrupted clearing operation will be continued, and "Target reached" will be reset to "0".

11.4.6.1 Example sequence

In order to clear the limit switches, the correct sequence must be sent by the PLC.

1	Control word = 0x0000	Disable voltage
1	Status word = 0x0050	Switch On Disabled
2	Modes of operation = -2	(Move away from limit switch)
3	Control word = 0x0006	Shutdown
	Status word = 0x0031	Ready to switch on
4	Control word = 0x0007	Switch On
	Status word = 0x0033	Switched On
5	Control word = 0x000F	Enable Operation.
	Status word = 0xnn37	Operation enabled
6	Control word = 0x001F	Move away from limit switch mode
	Status word = 0xn2B7	Operation enabled, limit switch active, clearing active
	Status word = 0xn637	Operation enabled and limit switch cleared (target reached).

WARNING



Dangerous state due to new mode!

If *Override Modes Of Operation 1454* is changed during operation (control word = 0xnfnF), a dangerous state may occur in the new mode.

- Before changing *Override Modes Of Operation 1454*, check the status word (e.g. for status 0xnn33).



Once the sequence of the first four status words has been processed correctly, the ACU is ready for operation (dark table area).

In state "operation enabled" (0xnfnF), the state of the Motion Control can be changed (white table area).

Bit 4 "Move away from limit switch" must be active in the clearing phase. If bit 4 is reset to "0", the clearing operation is interrupted.

As long as 0x0007 is active, the "Modes of Operation" can also be changed safely. Once *Override Modes Of Operation 1454* has been set to another value, operation can be started with a corresponding sequence.

11.4.7 Electronic gear: Slave


The mode "Electronic gear: Slave" can be selected via parameter *Override Modes Of Operation* **1454** =-3.


In operation mode "Electronic gear: Slave", the drive follows a master drive as a slave drive.

Relevant parameters:

410	<i>Control word</i>	1125	<i>Phasing: Offset</i>
411	<i>Status word</i>	1126	<i>Phasing: Speed</i>
418	<i>Minimum Frequency</i>	1127	<i>Phasing: Acceleration</i>
419	<i>Maximum Frequency</i>	1142	<i>Resync. on Change of Gear-Factor</i>
1108	<i>Act. Position</i>	1165	<i>Target window</i>
1106	<i>Error Threshold</i>	1166	<i>Target window time</i>
1119	<i>Contouring Error Time</i>	1179	<i>Emergency ramp</i>
1123	<i>Gear Factor: Numerator</i>	1454	<i>Override Modes Of Operation</i>
1124	<i>Gear Factor: Denominator</i>		

In operation mode "Electronic gear: Slave", the mode-specific bits of the control word and the status word are used as follows:





⚠ WARNING

Dangerous state due to faulty parameterization

- The function Master/Slave Position Correction is only allowed to be used after complete setup of this function. Check for parameter setup chapter 11.4.7.1 "Master/Slave Position Correction".



Control word

Identification	Value	Description
Start electronic gear Bit 4	0	Stop drive at ramp <i>Override Profile Deceleration 1458</i> .
	1	Start electronic gear at reference master speed at ramp <i>Override Profile Acceleration 1457</i> .
Start M/S Correction Bit 5	0	M/S Correction not started.
	1	Start Master/Slave Position correction. See chapter 11.4.7.1 "Master/Slave Position Correction".
Direct Sync Bit 6	0	Direct synchronization on.
	1	Direct synchronization off.
Halt Bit 8	0	Execute command from bit 4 "Start el. gear".
	1	Stop axis with ramp of current motion block The frequency inverter remains in "Operation enabled" status.
Start phasing Bit 9	0	Phasing disabled / aborted.
	1	Start Phasing with profile defined by Bits 12 & 13.
Phasing switching 0...1 Bit 12...13	n	Phasing Profile = n + 1.

Phasing switching:

Control word															
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
		Ph. sw.				Pha	Halt		DS		SG				
		1	0												

Phasing profile = Phasing switch over + 1

Phasing select		Phasing profile
Bit 13	Bit 12	
0	0	1
0	1	2
1	0	3
1	1	4

Status word

Identification	Value	Description
Phasing done (or M/S Correction done) Bit 8	0	Phasing (or M/S Correction) in process or not started yet.
	1	Phasing (or M/S Correction) done.
Target reached/ In gear Bit 10	0	Halt = 0: Electronic gear (still) not in gear
		Halt = 1: Axis decelerated.
	1	Halt = 0: Electronic gear in gear.
		Halt = 1: Axis has speed 0.
M/S Position Correction successful Bit 12	0	M/S Correction is running or wasn't started yet.
	1	M/S Correction finished. See chapter 11.4.7.1 "Master/Slave Position Correction".
Following error Bit 13	0	No following error.
	1	Following error.

Basic functions

Mode “-3 Electronic gear: Slave” implements a mode for a slave drive in the electronic gear to a master drive. The master of the electronic gear must be connected to the slave via signal cables or System Bus (recommended). The master input is selected in the Slave via parameter *Master position source 1122* .

<i>Operation mode 1122</i>	Function
0 - Off	No source selected.
1 - Encoder 1	The current speed and position of the master drive is taken over from encoder input 1.
2 - Encoder 2/resolver	The current speed and position of the master drive is taken over from encoder input 2 or resolver.
11 - RxPDO1.Long1 extrapolated	<p>The current position of the master drive is taken over by the process data channel RxPDO1.Long1 of the system bus. Additionally, the data received are extrapolated, even for slow settings of TxPDO Time of the master. Depending on the application, select a setting of the corresponding TxPDO.Long of the master:</p> <ul style="list-style-type: none"> • “606 – Internal act. Position (16/16)”, mechanical position of master drive. Value will not change abruptly when a homing operation of the master drive is completed. • “607 – Act. Position (16/16)”, mechanical position of master drive. Value will jump when the master drive carries out a homing operation. • “620 – motion profile gen.: internal reference position”, reference position of master drive; advantage: Improved controller properties. Value will not change abruptly when a homing operation of the master drive is completed. • “627 - Motion profile gen.: reference position”, reference position of master drive; advantage: Improved controller properties. Value will jump when the master drive carries out a homing operation. <p>Settings 607 and 627 are only to be used in exceptional situations. In most applications, source 606 or 620 is the better setting.</p>

In setting “11 - RxPDO1.Long1 extrapolated” of parameter *Master Position Source 1122* the system bus synchronization must be set to 1 or 10 to ensure a reliable function of *Operation Mode 1180* .

<i>Operation mode 1180</i>
0 - Off ¹⁾
1 - RxPDO1 ²⁾
2 - RxPDO2 ³⁾
3 - RxPDO3 ³⁾
10 - SYNC

¹⁾ If the error message “F1453 System Bus synchronization not activated” is displayed when the slave drive is started, operation mode 1, 2, 3 or 10 must be selected.

²⁾ Synchronization of processing with data telegram or cyclic sending of SYNC telegram.

³⁾ Not recommended for el. gear because no extrapolation done.


Synchronization between several drives must be performed at high updating rates in order to guarantee optimum results. In the transmitter of the TxPDO object, set a low value for the time (e.g. *TxPDO1 Time* **931**). If you use the SYNC function of System Bus, set parameter *SYNC time* **919** to a lower value.

Note that, due to these settings, the bus load of the system bus must provide for sufficient reserves for proper operation.



System Bus is described in the manuals of the extension modules with System Bus interface.

Block diagram: electronic gear and phasing function



The master position and speed are multiplied by the *gear factor*. When phasing is started, the phasing profile is added to the master speed until the phasing offset is reached.

The *Gear factor* is defined via the following parameters:

Parameters	
1123	<i>Gear Factor: Numerator</i>
1124	<i>Gear factor: Denominator</i>
1142	<i>Resync. on Change of Gear-Factor</i>

Phasing is defined via the following parameters:

Parameters	
1125.1	<i>Phasing: Offset</i>
1125.2	
1125.3	
1125.4	
1126.1	<i>Phasing: Speed</i>
1126.2	
1126.3	
1126.4	
1127.1	<i>Phasing: Acceleration</i>
1127.2	
1127.3	
1127.4	

Start electronic gear and phasing function

The electronic gear is started by control word bit 4 "Start electronic gear". The drive accelerates according to parameter *Override Profile Acceleration* **1457**. Once the slave speed is coupled into the master, status word bit 10 "Target reached/In Gear" is set. The conditions for "In Gear" status are set via parameters *In Gear'-Threshold* **1168** and *In Gear'-Time* **1169**.

"Target reached/In Gear" is set when the electronic gear function is used and electronic gear synchronous running is reached.

"Target reached/In Gear" is set when the electronic gear function is used and electronic gear synchronous running is reached.

Setting *Halt* "1" will stop a currently executed movement. The axis is stopped at ramp *Override Profile Deceleration* **1458**. "Target reached" is set to "0" to start the deceleration and to "1" when the speed reaches value 0. The drive remains in "Operation – enabled" status. To continue the interrupted movement, reset *Halt* to "0". Bit "Target reached" is set to "0" to start the acceleration and to "1" when the conditions for "Gear in" of parameters *In Gear'-Threshold* **1168** and *In Gear'-Time* **1169** are reached.

Phasing

With the phasing function, the slave position is offset from the master position received by the value of *Phasing: Offset* **1125**.


Phasing is described above in this chapter.

Function without direct synchronization ("Standard Synchronization")

The drive accelerates the master speed at the ramps parameterized in the motion block. As soon as the master speed is reached for the first time, the drive is synchronized with the master drive. The slave is engaged at the current position and operates at a synchronous angle with the master. In the case of a relative positioning operation, this engaging position is used as the start position.

The acceleration and deceleration for synchronizations follow an S-curve.

The relative position change due to acceleration is not compensated.




Function with direct synchronization

The drive accelerates the master speed at the ramps parameterized in the motion block. When the motion block is started, the drive is synchronized with the master drive directly. The master position is processed directly by the position controller.

The acceleration and deceleration for synchronizations follow an S-curve.

The relative position change due to acceleration is compensated by the position controller.



11.4.7.1 Master/Slave Position Correction

NOTE

When using this functionality master drive and slave drive have to use the same mechanical characteristics (i.e. gear transmission ratios) and use the same reference system.

The Master/Slave Position Correction offers as part of the Electronic Gear the possibility to synchronize the absolute Position of the Slave to the absolute Position of the master.

This function is helpful in example in applications, in which drives often work independently from each other and have to work together for certain activities. In example this could be the case in crane applications, where normal loads are operated intently from each other and which are switched together for heavy loads. To speed up the switching together process, the Master/Slave Position correction can be used to synchronize the absolute position of the Slave with the absolute position of the Master. Additionally by using an Offset a relative reference can be set up in the target position.

Preparations Master drive

The Master drive must be set up as follows:

TxPDO2 Identifier 927 = 640 (or a different not used Identifier)

TxPDO2 Function 932 = 1 – controlled by time or 2 – controlled by SYNC

TxPDO2.Long1 964 = 743 – Act. Position [User Units]

Additionally the following parameters must be set according to the electronic gear:
TxPDO1.Long1 954 corresponding to the description of *Master Position Source 1122*

TxPDO1 Identifier 925 = 384 (or a different not used Identifier)

TxPDO1 Function 930 = 1 – controlled by time or 2 – controlled by SYNC

Preparations Slave drive

The Slave drive must be set up as follows:

RxPDO2 Function 926 = 640 (or the Identifier defined in the Master drive)

Additionally the following parameters must be set according to the electronic gear:

RxPDO1 Function 924 = 384 (or the Identifier defined in the Master drive)

Source Master position 1122 = 11 – RxPDO1.Long



The function Master/Slave Position Correction expects the Target Position [u] always in RxPD2.Long. When using this function RxPDO2.Long1 and also RxPDO2.Word1, RxPDO2.Word2, RxPDO2.Boolean1 and RxPDO2.Boolean2 are not allowed to be used for any other purpose.

Starting of Master/Slave Position Correction in Slave drive

To start the Master/Slave Position correction at first Bit 4 and then Bit 5 have to be set in the Control word. Bit 5 is only allowed to be set when Bit 10 In Gear is shown in the Status word.

By setting Bit 5 in the Control word the Slave drive is started to position to the Master position + Offset.

The acceleration is done with Parameter *Acceleration* **1134**. The used velocity can be set up via Parameter *Fast Speed* **1132**.

As long as the Master/Slave Position correction is executed, Bit 12 is deactivated in the Status word. When the Master/Slave Position correction is finished successfully Bit 12 is set.

During the Correction sequence the Status word bit 8 "Master/Slave Position correction" is set to "Low". As soon as the Master/Slave Position correction is finished or cancelled, the Bit is set to "High". After first switch-on (or after a device reset) the "Phasing Done" bit is also "Low".

Since Bit 8 is also used for Phasing, always the last started function is signaled by this bit.

Offset Reference

The Offset for the M/S Synchronization can be set via *M/S Synchronization offset* **1284**.

Parameters		Settings		
No.	Description	Min.	Max.	Factory setting
1284	M/S Synchronisation-soffset	-2147483647 u	2147483647 u	0 u



Application limitations

The function can be used in most of all applications without any limitations. In applications with very long travelling distances the following must be checked:

- The position difference to be compensated must not be greater than $2^{15}-1$ motor revolutions.
- The position difference to be compensated must not be greater than $2^{31}-1$ user units.

Depending on the used reference system it can vary, which limit is decisive. Always the smaller limit must be complied with.

A motor with a reference speed of 6000 rpm would have to travel for around 5.5 minutes into one direction to exceed this limit.

11.4.7.2 Example sequence

In order to start “Electronic Gear: Slave mode”, the correct sequence must be sent by the PLC.

1	Control word = 0x0000	Disable voltage
1	Status word = 0x0050	Switch On Disabled
2	Modes of operation = -3	(Electronic Gear: Slave mode)
3	Control word = 0x0006	Shutdown
	Status word = 0x0031	Ready to switch on
4	Control word = 0x0007	Switch On
	Status word = 0x0033	Switched On
5	Control word = 0x000F	Operation enabled, reference speed “0”
	Status word = 0xnn37	Operation enabled
6a	Control word = 0x001F	Start electronic gear without direct synchronization
	Status word = 0xn327	Operation enabled, Slave not coupled (yet), Phasing not finished.
	Status word = 0xn337	Operation enabled, Slave not coupled (yet), Phasing finished.
	Status word = 0xn727	Operation enabled, Slave coupled, Phasing not (yet) finished.
	Status word = 0xn737	Operation enabled, Slave coupled, Phasing finished.
6b	Control word = 0x005F	Start Electronic Gear with Direct Synchronisation
	Status word = See 6a	See 6a
7a	Control word = 0x021F	Start Electronic Gear without Direct Synchronisation and Phasing Profile 1
	Status word = See 6a	See 6a
7b	Control word = 0x121F	Start Electronic Gear without Direct Synchronisation and Phasing Profile 2
	Status word = See 6a	See 6a
7c	Control word = 0x221F	Start Electronic Gear without Direct Synchronisation and Phasing Profile 3
	Status word = See 6a	See 6a
7d	Control word = 0x321F	Start Electronic Gear without Direct Synchronisation and Phasing Profile 4
	Status word = See 6a	See 6a
8a	Control word = 0x025F	Start Electronic Gear with Direct Synchronisation and Phasing Profile 1
	Status word = See 6a	See 6a
8b	Control word = 0x125F	Start Electronic Gear with Direct Synchronisation and Phasing Profile 2
	Status word = See 6a	See 6a
8c	Control word = 0x225F	Start Electronic Gear with Direct Synchronisation and Phasing Profile 3
	Status word = See 6a	See 6a
8d	Control word = 0x325F	Start Electronic Gear with Direct Synchronisation and Phasing Profile 4
	Status word = See 6a	See 6a
9	Control word = 0x001F	Enable Operation, the Slave drive synchronizes to the Master position.
	Status word = 0x003F	
	Status word = 0xnn37	Operation enabled
	Status word = 0x1n37	M/S Position Correction finished.

 **WARNING**



Dangerous state due to new mode!

If *Override Modes Of Operation 1454* is changed during operation (control word = 0xnnnF), a dangerous state may occur in the new mode.

- Before changing *Override Modes Of Operation 1454*, check the status word (e.g. for status 0xnn33).



Once the sequence of the first four status words has been processed correctly, the ACU is ready for operation (dark table area).

In state "operation enabled" (0xnnnF), the state of the Motion Control can be changed (white table area).

Bit 4 "Start electronic gear" must be active during the movement. If bit 4 is reset to "0", the movement is interrupted.

As long as 0x0007 is active, the "Modes of Operation" can also be changed safely. Once *Override Modes Of Operation 1454* has been set to another value, operation can be started with a corresponding sequence.



Bit 5 "Start Position Correction" is only allowed to be used when the Slave is in gear (Status word Bit 10).

Bit 5 "Start Position Correction" should be used for optimum results when the master drive doesn't move.

When Bit 5 of the Control word is reset to "0" the movement is interrupted.

12 Actual values




Actual values		
No.	Description	Function
11	VABus SST error register	Modbus or VABus error register. See chapter 7.2 "Telegram check".
282	Bus reference frequency	Reference value from serial interface.
283	Ramp reference frequency	Reference value from reference frequency channel.
411	Status word	Status word. See chapter 11.1 "Control via contacts/remote contacts".

12.1 Actual values Motion Control Interface / Motion Control Override

Actual values MCI/MCO		
No.	Description	Function
1107	Act. Speed	Actual Speed in user units/Seconds [u/s].
1108	Actual Position	Actual Position in user units [u]. See also chapter 10.2.3.
1109	Act. Contouring Error	Actual Contouring error in user units [u]. See also chapter 10.2.3.
1129	Actual Master Speed	Actual Master Speed in user units/Seconds [u/s].

13 Parameter List

The parameter list is sorted numerically. For better overview, the parameters are marked with pictograms:

-  The parameter is available in the four data sets.
-  The parameter value is set by the SET-UP routine
-  This parameter cannot be written when the frequency inverter is in operation.

13.1 Actual values (Menu "Actual")
















Actual value parameter				
No.	Description	Unit	Indication range	Chapter
RS485/RS232				
11	VABusSST-Error-Register	-	0 ... 15	
Actual values of frequency inverter				
228	Internal reference frequency	Hz	-1000,00 ... 1000.00	11.3.3
240	Actual speed	min ⁻¹	-60000 ... 60000	11.3, 11.4
249	Active dataset	-	0 ... 4	11
260	Current error	-	0 ... 0xFFFF	14.5
270	Warnings	-	0 ... 0xFFFF	14.3
274	Warning application	-	0 ... 0xFFFF	14.4
282	Bus reference frequency	Hz	-999,99 ... 999,99	12
283	Ramp reference frequency	Hz	-999.99 ... 999.99	
Bus control				
411	Status word	-	0 ... 0xFFFF	11.2
Actual values of Motion Control Interface (MCI)				
1107	Act. Speed	u/s	-2 ³¹ ... 2 ³¹ -1	12.1
1108	Actual Position	u	-2147483647 ... 2147483647	
1109	Act. Contouring Error	u	-2147483647 ... 2147483647	
1129	Act. Master Speed	u/s	-2 ³¹ ... 2 ³¹ -1	
1246	Actual Motion Block	-	-10 ¹ , -3 ... 32	11.4.5
1249	Motion Block to Resume	-	-1 ... 32	
VABus/TCP				
1431	Module Info	-	String	6.4.2.1



Parameters *Current error* **260**, *Warnings* **270** and *Application warnings* **274** are only accessible via Field Bus. They cannot be addressed via the VPlus control software or the control unit.

13.2 Parameters (Menu "Para")

Parameters					
No.	Description	Unit	Setting range	Chapter	
VABus/TCP					
388	Bus Error Behaviour	-	0 ... 5	6.5	
Bus control					
392	State Transition 5	-	Selection	11.3.2	
410	Control word	-	0 ... 0xFFFF	11.2	
412	Local/Remote	-	Selection	11	
Data set switching					
414	Data set selection	-	0 ... 4	11	
Frequency ramps					
420	Acceleration (Clockwise)	Hz/s	0.00 ... 9999.99	11.3	
421	Deceleration (Clockwise)	Hz/s	0.01 ... 9999.99		
422	Acceleration Anticlockwise	Hz/s	-0.01 ... 9999.99		
423	Deceleration Anticlockwise	Hz/s	-0.01 ... 9999.99		
424	Emergency Stop Clockwise	Hz/s	0.01 ... 9999.99		
425	Emergency Stop Anticlockwise	Hz/s	0.01 ... 9999.99		
434	Ramp Setpoint	-	Selection	11.3.3	
Fixed frequency values					
484	Reference frequency RAM	Hz	-999.99 ... 999.99	11.3.3	
Fixed percentages					
524	Reference percentage RAM	%	-300,00 ... 300.00	11.3.3	
Digital outputs					
549	Max. control deviation	%	0.01 ... 20.00	11	
Stopping behavior					
637	Switch-Off Threshold	%	0.0 ... 100.0	11.3.1, 11.3.2	
638	Holding Time	s	0.0 ... 200.0		
System Bus					
900	Node-ID	-	Selection	7.1.4	
Position Controller					
1104	Time constant	ms	0 ... 300	10.2.5	
Contouring error monitoring					
1105	Warning Threshold	u	0 ... $2^{31}-1$	10.2.3	
1106	Error Threshold	u	0 ... $2^{31}-1$		
Motion Control Interface: Reference system					
<input checked="" type="checkbox"/>	1115	Feed Constant	-	1 ... 2147483647	10.2.1
<input checked="" type="checkbox"/>	1116	Gear Box: Driving Shaft Revolutions	-	1 ... 65535	
<input checked="" type="checkbox"/>	1117	Gear Box: Motor Shaft Revolutions	-	1 ... 65535	
Position Controller					
1118	Limit	u/s	0 ... $2^{31}-1$	10.2.5	
Contouring error monitoring					
1119	Contouring error time	ms	0 ... 65535	10.2.3	
1120	Fault reaction	-	Selection		

Electronic gear					
	1122	Master Position Source	-	Selection	11.4.7
	1123	Gear Factor Numerator	-	-32767 ... 32767	
	1124	Gear Factor Denominator	-	1 ... 65535	
	1125	Phasing: Offset	u	$-(2^{31}-1) \dots 2^{31}-1$	
	1126	Phasing: Speed	u/s	$1 \dots 2^{31}-1$	
	1127	Phasing: Acceleration	u/s ²	$1 \dots 2^{31}-1$	
Motion Control Interface: Homing					
	1130	Homing Mode	-	0 ... 35	11.4.4
	1132	Fast Speed	-	1 ... 2147483647	
	1133	Creep Speed	-	1 ... 2147483647	
	1134	Acceleration	-	1 ... 2147483647	
	1135	Ramp Rise Time	-	0 ... 2000	
Electronic gear					
	1142	Resync. on Change of Gear-Factor	-	Selection	11.4.7
Motion Control Interface: Limit switch fault reaction					
	1143	Fault reaction		Selection	10.2.7
Target window					
	1165	Target Window	u	$0 \dots 2^{20}-1$	11.4.5, 11.4.7
	1166	Target Window Time	ms	1 ... 65535	
Electronic gear					
	1168	In Gear'-Threshold	u	$1 \dots 2^{31}-1$	11.4.7
	1169	In Gear'-Time	ms	1 ... 65535	
Motion Control Interface: Profile position mode					
	1176	Ramp Rise Time.	ms	0 ... 2000	11.4.2
	1178	Ramp Fall Time.	ms	0 ... 2000	
	1179	Emergency Ramp	u/s ²	1 ... 2147483647	
System Bus					
	1180	Operation mode	-	Selection	11.4.7
MCI: Profile Velocity mode [u/s]					
	1275	Max. Slippage	ms	0 ... 2147483647	11.4.2
	1276	Velocity Window	u/s	0 ... 65535	
	1277	Velocity Window Time	ms	0 ... 65535	
	1278	Threshold Window	u/s	0 ... 65535	
	1279	Threshold Window Time	ms	0 ... 65535	
Motion Control Interface: Mapping					
	1299	S. Special Function Generator	-	Selection	11.4.1
VABus/TCP					
	1432	IP address	-	-	6.2
	1433	Netmask	-	-	
	1434	Gateway	-	-	
	1435	DNS Server	-	-	
	1436	DHCP Option	-	Selection	
	1437	IP command	-	Selection	
	1440	Email Function	-	Selection	
	1441	Email Text (Body)	-	Text	

Motion Control Override				
1454	Override Modes Of Operation	-	Selection	10.1
1455	Override Target Position	u	$-2^{31}-1 \dots 2^{31}-1$ u	
1456	Override Profile Velocity	u/s	$-1 \dots 2^{31}-1$ u/s	
1457	Override Profile Acceleration	u/s^2	$-1 \dots 2^{31}-1$ u/s^2	
1458	Override Profile Deceleration	u/s^2	$-1 \dots 2^{31}-1$ u/s^2	
1459	Override Target Velocity vl [rpm]	rpm	-32768...32767 rpm	
1460	Override Target Velocity pv [u/s]	u/s	$-2^{31}-1 \dots 2^{31}-1$ u/s	

14 Appendix

14.1 List of control words

The tables on this page provide an overview of the functions of the **control word** bits.

Bit	<i>Standard (no positioning)</i>	<i>Positioning without MCI</i>	<i>MCI: Velocity Mode</i>	<i>MCI: Profile Velocity Mode</i>	<i>MCI: Profile Position Mode</i>
0	Switch On	Switch On	Switch On	Switch On	Switch On
1	Enable Voltage	Enable Voltage	Enable Voltage	Enable Voltage	Enable Voltage
2	Quick Stop (low active)	Quick Stop (low active)	Quick Stop (low active)	Quick Stop (low active)	Quick Stop (low active)
3	Enable Operation	Enable Operation	Enable Operation	Enable Operation	Enable Operation
4			Rfg enable		New setpoint
5			Rfg unlock		Change set immediately
6			Rfg use ref		Abs/rel
7	Fault reset	Fault reset	Fault reset	Fault reset	Fault reset
8	Halt	Halt	Halt	Halt	Halt
9					Change on setpoint
10					
11					
12					
13					
14					
15					

Bit	<i>MCI: Homing Mode</i>	<i>MCI: Table Travel record Mode</i>	<i>MCI: Move away from Limit Sw.</i>	<i>MCI: Electronic Gear: Slave</i>
0	Switch On	Switch On	Switch On	Switch On
1	Enable Voltage	Enable Voltage	Enable Voltage	Enable Voltage
2	Quick Stop (low active)	Quick Stop (low active)	Quick Stop (low active)	Quick Stop (low active)
3	Enable Operation	Enable Operation	Enable Operation	Enable Operation
4	Homing operat.start	Sequence mode	Move away from LS	Start Gearing
5				
6		Resume		Direct Sync
7	Fault reset	Fault reset	Fault reset	Fault reset
8	Halt	Halt	Halt	Halt
9		Start motion block		Start Phasing
10				
11		Motion Block Select 0		
12		Motion Block Select 1		Phasing Profile Sel. 1
13		Motion Block Select 2		Phasing Profile Sel. 2
14		Motion Block Select 3		
15		Motion Block Select 4		

14.2 List of status words

The tables on this page provide an overview of the functions of the status word bits.

Bit	<i>Standard (no positioning)</i>	<i>Positioning without MCI</i>	<i>MCI: Velocity Mode</i>	<i>MCI: Profile Velocity Mode</i>	<i>MCI: Profile Position Mode</i>
0	Ready to Switch On	Ready to Switch On	Ready to Switch On	Ready to Switch On	Ready to Switch On
1	Switched On	Switched On	Switched On	Switched On	Switched On
2	Operation enabled	Operation enabled	Operation enabled	Operation enabled	Operation enabled
3	Fault	Fault	Fault	Fault	Fault
4	Voltage enabled	Voltage enabled	Voltage enabled	Voltage enabled	Voltage enabled
5	Quick Stop (low active)	Quick Stop (low active)	Quick Stop (low active)	Quick Stop (low active)	Quick Stop (low active)
6	Switch On Disabled	Switch On Disabled	Switch On Disabled	Switch On Disabled	Switch On Disabled
7	Warning	Warning	Warning	Warning	Warning
8		Homing done			
9	Remote	Remote	Remote	Remote	Remote
10	Target reached	Target reached	Target reached	Target reached	Target reached
11	Internal limit active	Internal limit active	Internal limit active	Internal limit active	Internal limit active
12				Speed	Set-point acknowl.
13				Max slippage error	Following error
14		Target Pos. reached			
15	Warning 2	Warning 2	Warning 2	Warning 2	Warning 2

Bit	<i>MCI: Homing Mode</i>	<i>MCI: Table Travel record Mode</i>	<i>MCI: Move away from Limit Sw.</i>	<i>MCI: Electronic Gear: Slave</i>
0	Ready to Switch On	Ready to Switch On	Ready to Switch On	Ready to Switch On
1	Switched On	Switched On	Switched On	Switched On
2	Operation enabled	Operation enabled	Operation enabled	Operation enabled
3	Fault	Fault	Fault	Fault
4	Voltage enabled	Voltage enabled	Voltage enabled	Voltage enabled
5	Quick Stop (low active)	Quick Stop (low active)	Quick Stop (low active)	Quick Stop (low active)
6	Switch On Disabled	Switch On Disabled	Switch On Disabled	Switch On Disabled
7	Warning	Warning	Warning	Warning
8		Motion Block in Progress		Phasing Done
9	Remote	Remote	Remote	Remote
10	Target reached	Target reached	Target reached	Target reached
11	Internal limit active	Internal limit active	Internal limit active	Internal limit active
12	Homing attained	In gear		
13	Homing error	Following error		Following error
14				
15	Warning 2	Warning 2	Warning 2	Warning 2

14.3 Warning messages

The different control methods and the hardware of the frequency inverter include functions for continuous monitoring of the application. In addition to the messages documented in the frequency inverter user manual, further warning messages are activated by the Field Bus module. The bit-coded warning reports are issued via parameter *Warnings 270* according to the following pattern: Parameter *Warnings 270* is provided for read-out via a PLC, Parameter *Warnings 269* provides the information, including a brief description in VPlus and the control panel.

Warning messages		
Bit no.	Warning code	Description
0	0x0001	Warning Ixt
1	0x0002	Warning short-time Ixt
2	0x0004	Warning long-time Ixt
3	0x0008	Warning heat sink temperature Tk
4	0x0010	Warning inside temperature Ti
5	0x0020	Warning Limit
6	0x0040	Warning Init
7	0x0080	Motor temperature warning
8	0x0100	Warning mains failure
9	0x0200	Warning motor circuit breaker
10	0x0400	Warning Fmax
11	0x0800	Warning analog input MF11A
12	0x1000	Warning analog input A2
13	0x2000	Warning System Bus
14	0x4000	Warning Udc
15	0x8000	Warning <i>Application warning status 367</i>



The meanings of the individual warnings are described in detail in the frequency inverter Operating Instructions.

14.4 Application warning messages

When the highest bit of the warning message is set, an “Application warning message” is present. The application warning messages are bit-encoded as per the following pattern via parameter *Application warnings* **274**. Parameter *Application warnings* **273** indicates the warnings as plain text in the control panel and the VPlus PC control software.

Use parameter *Application warnings* **274** in order to read the warning messages via Field Bus.

Application warning messages			
Bit no.	Warning code	Description	
0	0x0001	BELT	- V-belt
1	0x0002	SW-LIM CW	- SW limit switch clockwise
2	0x0004	SW-LIM CCW	- SW limit switch anticlockwise
3	0x0008	HW-LIM CW	- HW limit switch clockwise
4	0x0010	HW-LIM CCW	- HW limit switch anticlockwise
5	0x0020	CONT	- contouring error
6	0x0040	ENC	- Warning Absolute encoder
7	0x0080	User 1	- User Warning 1
8	0x0100	User 2	- User Warning 2
9	0x0200	(reserved)	
10	0x0400	(reserved)	
11	0x0800	(reserved)	
12	0x1000	(reserved)	
13	0x2000	(reserved)	
14	0x4000	(reserved)	
15	0x8000	(reserved)	



For details on the warnings, refer to the user manual and the “Positioning” application manual.

Warning bit 6 “Absolute value encoder” can be read via parameter **1274** in VPlus or **1273** via Field Bus. For details on absolute value encoder warnings, refer to the extension module manual EM-ABS-01.

14.5 Error messages

The error code stored following a fault comprises the error group FXX (high-byte, hexadecimal) and the code YY (low-byte, hexadecimal).

Communication error			
	Key	Meaning	
Motion Control Interface	F04	04	Control deviation position controller
	F14	42	Pos. SW limit switch
		43	Neg. SW limit switch
		44	Pos. SW limit sw. < Neg. SW limit sw.
		45	Pos. and Neg. HW-Lim Switch Simultaneously
		46	Limit Switch Incorrect Wired
		47	Pos. HW Limit Switch
		48	Neg. HW Limit Switch
		51	Switch: Pos. Dir. Blocked
		52	Neg. Dir. Blocked
		53	System bus-Synchronization not activated
		60	Pos. HW Limit Sw.: Non-permissible signal source
		61	Pos. HW Limit Sw.: Input deactivated by PWM /FF input
		62	Pos. HW Limit Sw.: Input deactivated of index controller
		63	Pos. HW Limit Sw.: wrong mode for MF11
		64	Pos. HW Limit Sw.: Input deactivated by encoder 1
		65	Pos. HW Limit Sw.: Input deactivated by encoder 2
		66	Pos. HW Limit Sw.: wrong mode for EM-S1IOD
		70	Neg. HW Limit Sw.: Non-permissible signal source
		71	Neg. HW Limit Sw.: Input deactivated by PWM /FF input
		72	Neg. HW Limit Sw.: Input deactivated of index controller
	73	Neg. HW Limit Sw.: wrong mode for MF11	
	74	Neg. HW Limit Sw.: Input deactivated by encoder 1	
	75	Neg. HW Limit Sw.: Input deactivated by encoder 2	
	76	Neg. HW Limit Sw.: wrong mode for EM-S1IOD	
	F15	xx	User-Defined Error in Motion Block xx (1 £ xx £ 32)
		70	No Homing Done
71		Homing Encoder-Mode w.o. Z-Impulse	
72		Both Directions Locked	
73		No Touch Probe Signal Detected	
Ethernet	F27	14	Communication loss to PLC

The current error can be read via parameter *Current error* **260** as well as via the Emergency Message.

Parameter *Current error* **259** indicates the current error as plain text in the control panel and the VPLus PC control software.

In addition to the error messages mentioned, there are other error messages specified in the user manual. The errors of the Motion Control Interface (F14xx, F15xx) are described in detail in the "Positioning" user manual.

14.6 Conversions

The speeds/frequencies can be converted to other speed formats using the formulas in this chapter:

Frequency [Hz] into	speed [1/min]	See Chapter 14.6.2
	Speed into user units per second [u/s]	See Chapter 14.6.4
Speed [1/min] in	Frequency [Hz]	See Chapter 14.6.1
	Speed into user units per second [u/s]	See Chapter 14.6.6
Speed into user units per second [u/s] into	Speed [1/min]	See Chapter 14.6.5
	Frequency [Hz]	See Chapter 14.6.3

14.6.1 Speed [1/min] into frequency [Hz]

$$f [\text{Hz}] = \frac{n[\text{min}^{-1}] \times \text{No. of pole pairs (P.373)}}{60}$$

14.6.2 Frequency [Hz] into speed [1/min]

$$n[\text{rpm}] = \frac{f [\text{Hz}] \times 60}{\text{No. of pole pairs (P.373)}}$$

14.6.3 Speed in in user units per second [u/s] into frequency[Hz]

$$f [\text{Hz}] = v \left[\frac{\text{u}}{\text{s}} \right] \times \frac{\text{No. of pole pairs (P.373)}}{\text{Feed Constant (P.1115)}} \times \frac{\text{Gear Box: Motor Shaft Revolutions (P.1117)}}{\text{Gear Box: Driving Shaft Revolutions (P.1116)}}$$

14.6.4 Frequency [Hz] into speed in user units per second [u/s]

$$v \left[\frac{\text{u}}{\text{s}} \right] = f [\text{Hz}] \times \frac{\text{Feed Constant (P.1115)}}{\text{No. of pole pairs (P.373)}} \times \frac{\text{Gear Box: Driving Shaft Revolutions (P.1116)}}{\text{Gear Box: Motor Shaft Revolutions (P.1117)}}$$

14.6.5 Speed in user units per second [u/s] into speed [1/min]

$$v \left[\frac{\text{u}}{\text{s}} \right] = f [\text{Hz}] \times \frac{\text{Feed Constant (P.1115)}}{\text{No. of pole pairs (P.373)}} \times \frac{\text{Gear Box: Driving Shaft Revolutions (P.1116)}}{\text{Gear Box: Motor Shaft Revolutions (P.1117)}}$$

14.6.6 Speed [1/min] into speed in user units per second [u/s]

$$v \left[\frac{\text{u}}{\text{s}} \right] = n [\text{rpm}] \times \frac{\text{Feed constant (P.1115)}}{60} \times \frac{\text{Gear Box: Driving Shaft Revolutions (P.1116)}}{\text{Gear Box: Motor Shaft Revolutions (P.1117)}}$$

14.7 ASCII table (0x00 – 0x7F)

Dec.	Hex.	Char.
0	00	NUL
1	01	
2	02	STX
3	03	ETX
4	04	EOT
5	05	ENQ
6	06	ACK
7	07	BEL
8	08	BS
9	09	TAB
10	0A	LF
11	0B	VT
12	0C	FF
13	0D	CR
14	0E	
15	0F	
16	10	
17	11	
18	12	
19	13	
20	14	
21	15	NAK
22	16	
23	17	
24	18	
25	19	
26	1A	
27	1B	ESC
28	1C	
29	1D	
30	1E	
31	1F	
32	20	SPACE
33	21	!
34	22	"
35	23	#
36	24	\$
37	25	%
38	26	&
39	27	'
40	28	(
41	29)
42	2A	*

Dec.	Hex.	Char.
43	2B	+
44	2C	,
45	2D	-
46	2E	.
47	2F	/
48	30	0
49	31	1
50	32	2
51	33	3
52	34	4
53	35	5
54	36	6
55	37	7
56	38	8
57	39	9
58	3A	:
59	3B	;
60	3C	<
61	3D	=
62	3E	>
63	3F	?
64	40	@
65	41	A
66	42	W
67	43	C
68	44	D
69	45	E
70	46	F
71	47	G
72	48	H
73	49	I
74	4A	J
75	4B	K
76	4C	L
77	4D	M
78	4E	N
79	4F	O
80	50	P
81	51	Q
82	52	R
83	53	S
84	54	D
85	55	U

Dec.	Hex.	Char.
86	56	V
87	57	W
88	58	X
89	59	Y
90	5A	Z
91	5B	[
92	5C	\
93	5D]
94	5E	^
95	5F	_
96	60	`
97	61	a
98	62	b
99	63	c
100	64	d
101	65	e
102	66	f
103	67	g
104	68	h
105	69	i
106	6A	j
107	6B	k
108	6C	l
109	6D	m
110	6E	n
111	6F	o
112	70	p
113	71	q
114	72	r
115	73	s
116	74	t
117	75	u
118	76	v
119	77	w
120	78	x
121	79	y
122	7A	z
123	7B	{
124	7C	
125	7D	}
126	7E	~
127	7F	DEL



Frequently used values are marked.

Index

A	
Acknowledging error messages	42
Actual position value.....	57
Actual values.....	118
Application warning messages.....	126
Application warnings.....	126
Assembly	
Communication module	23
B	
Bus Error behavior.....	34, 42
Bus reference frequency	118
C	
Contouring errors	57
Control	
Contacts.....	61
Remote contacts	61
Copyright.....	8
Current position	57
D	
Decommissioning	17
Designated use	10
Disassembly	
Communication module	24
E	
Electrical connections	15
Error messages	127
Example sequence	
Electronic Gear	
Slave mode (Electronic gear	
Slave).....	116
Move away from limit switch.....	106
Profile Velocity mode [u/s]	82
Table travel mode.....	102
Without Motion control.....	72
Example telegrams.....	46
G	
General Information about the Documentation	
.....	7
H	
Homing.....	57
Homing mode	91
I	
Index parameters	
Read.....	45
Write	45
Installation	15
L	
Local/Remote	60
M	
Maintenance.....	16
Master/Slave Position Correction.....	114
Motion Control Interface (MCI)	50
Motion Control Override	51
Move away from limit switch mode	103
P	
Parameter access	
Index parameters	
Read	45
Write index parameter	45
Position Controller.....	57
Position deviation.....	58
Profile Position mode	83
R	
Ramp reference frequency	118
Reference system	56
S	
Safety	
General.....	9
Sequence example	
Homing mode	93
Velocity mode	77
State machine	
Device control	64
Storage	15
T	
Table travel record mode	94
Target window	57
TCP/IP address.....	27
Transition 5 of state machine	70
Transport	15
W	
Warning messages.....	125
Warranty and liability	8

Bonfiglioli worldwide network.

Bonfiglioli Australia

2, Cox Place Glendenning NSW 2761
Locked Bag 1000 Plumpton NSW 2761
Tel. (+ 61) 2 8811 8000 - Fax (+ 61) 2 9675 6605
www.bonfiglioli.com.au - sales@bonfiglioli.com.au

Bonfiglioli Brazil

Travessa Cláudio Armando 171 - Bloco 3
CEP 09861-730 - Bairro Assunção
São Bernardo do Campo - São Paulo
Tel. (+55) 11 4344 1900 - Fax (+55) 11 4344 1906
www.bonfigliolidobrasil.com.br
bonfigliolidobrasil@bonfiglioli.com

Bonfiglioli Canada

2-7941 Jane Street - Concord, Ontario L4K 4L6
Tel. (+1) 905 7384466 - Fax (+1) 905 7389833
www.bonfigliolicanada.com
sales@bonfigliolicanada.com

Bonfiglioli China

19D, No. 360 Pu Dong Nan Road
New Shanghai International Tower
200120 Shanghai
Tel. (+86) 21 5054 3357 - Fax (+86) 21 5970 2957
www.bonfiglioli.cn - bdssales@bonfiglioli.com.cn

Bonfiglioli Deutschland

Sperberweg 12 - 41468 Neuss
Tel. (+49) 02131 2988-0
Fax (+49) 02131 2988-100
www.bonfiglioli.de - info@bonfiglioli.de

Bonfiglioli España

TECNOTRANS BONFIGLIOLI S.A.
Pol. Ind. Zona Franca sector C, calle F, nº6
08040 Barcelona
Tel. (+34) 93 4478400 - Fax (+34) 93 3360402
www.tecnotrans.com - tecnotrans@tecnotrans.com

Bonfiglioli France

14 Rue Eugène Pottier BP 19
Zone Industrielle de Moimont II
95670 Marly la Ville
Tel. (+33) 1 34474510 - Fax (+33) 1 34688800
www.bonfiglioli.fr - btf@bonfiglioli.fr

Bonfiglioli India

PLOT AC7-AC11 Sidco Industrial Estate
Thirumudivakkam - Chennai 600 044
Tel. +91(0) 44 24781035 - 24781036 - 24781037
Fax +91(0) 44 24780091 - 24781904
www.bonfiglioliindia.com - bonfig@vsnl.com

Bonfiglioli Italia

Via Sandro Pertini lotto 7b
20080 Carpiano (Milano)
Tel. (+39) 02 985081 - Fax (+39) 02 985085817
www.bonfiglioli.it
customerservice.italia@bonfiglioli.it

Bonfiglioli New Zealand

88 Hastie Avenue, Mangere Bridge, Auckland
2022, New Zealand - PO Box 11795, Ellerslie
Tel. (+64) 09 634 6441 - Fax (+64) 09 634 6445
npollington@bonfiglioli.com.au

Bonfiglioli Österreich

Molkereistr 4 - A-2700 Wiener Neustadt
Tel. (+43) 02622 22400 - Fax (+43) 02622 22386
www.bonfiglioli.at
info@bonfiglioli.at

Bonfiglioli South East Asia

No 21 Woodlands industrial park E1
#02-03 Singapore 757720
Tel. (+65) 6893 6346/7 - Fax (+65) 6893 6342
www.bonfiglioli.com.au
sales@bonfiglioli.com.sg

Bonfiglioli South Africa

55 Galaxy Avenue,
Linbro Business Park - Sandton
Tel. (+27) 11 608 2030 OR - Fax (+27) 11 608 2631
www.bonfiglioli.co.za
bonfigsales@bonfiglioli.co.za

Bonfiglioli Türkiye

Atatürk Organize Sanayi Bölgesi,
10015 Sk. No: 17, Çigli - Izmir
Tel. +90 (0) 232 328 22 77 (pbx)
Fax +90 (0) 232 328 04 14
www.bonfiglioli.com.tr
info@bonfiglioli.com.tr

Bonfiglioli United Kingdom

Industrial Solutions
Unit 7, Colemeadow Road
North Moons Moat - Redditch,
Worcestershire B98 9PB
Tel. (+44) 1527 65022 - Fax (+44) 1527 61995
www.bonfiglioli.com
uksales@bonfiglioli.com

Mobile Solutions
3 - 7 Grosvenor Grange, Woolston
Warrington - Cheshire WA1 4SF
Tel. (+44) 1925 852667 - Fax (+44) 1925 852668
www.bonfiglioli.co.uk
mobilesales@bonfiglioli.co.uk

Bonfiglioli USA

3541 Hargrave Drive Hebron, Kentucky 41048
Tel. (+1) 859 334 3333 - Fax (+1) 859 334 8888
www.bonfiglioliusa.com

Bonfiglioli Vietnam

Lot C-9D-CN My Phuoc Industrial Park 3
Ben Cat - Binh Duong Province
Tel. (+84) 650 3577411 - Fax (+84) 650 3577422
www.bonfiglioli.vn
salesvn@bonfiglioli.com



Bonfiglioli has been designing and developing innovative and reliable power transmission and control solutions for industry, mobile machinery and renewable energy applications since 1956.