


## TD-32B SLC-5XX Leased Line


Web: www.westermo.co.uk
E-mail: technical@westermo.co.uk
Tel: +44 (0) 1489 580585

Tel: +44 (0) 1489 580585 Fax: +44 (0) 1489 580586

## **Switch Settings**

## **TD-32**





## **Notes**

Switch settings are for 8,n,1 @ 19.2Kbps on the DTE side and 14.4Kbps on the line side.

- I. Ensure the RS232 cable meets the specification described below.
- 2. Set SW3/I ON for 2 wire leased line or OFF for 4 wire leased line and SWI is set for Answer or Dial as required.
- 3. Ensure that the communication setting and error detection for the SLC 5XX / RS Linx's are the same.

