
INTRODUCTION

• While regular sensors detect the existence of objects, displacement sensors detect the amount of displacement when objects move from one position to another. Detecting the amount of displacement allows you to measure the height and thickness of the objects.

LASER DISPLACEMENT SENSOR

The principle of laser displacement sensor ranging


- The principle of laser displacement sensor ranging is a method where triangulation is applied by combining the emitting element and the position sensitive device (PSD) to perform ranging (detecting the amount of displacement).
- The emitting element of Panasonic Electric Works SUNX's laser displacement sensors uses a semi-conductor laser. The laser light is focused through the emitting lens and projected on an object. At that time, some of the light beam that is reflected from the object produces a light spot on the position sensing device. When the object moves,




the PSD moves as well. Detecting the changes in positions makes it possible to detect the amount of displacement of the object.

Some of the receiving elements use a linear image sensor, and not the PSD. The PSD enables you to acquire information only about the center position of the amount of light of the entire light spot. On the other hand, the emitting elements with the linear image sensor detect the amount of light received by each cell. Therefore, even when there are variations in the amount of light within the spot due to influences from the object's surface, even more accurate detection can be performed for the peak position of the light intensity. This significantly reduces errors due to the influence of the objects' surfaces.

Principle For detection of a V-shaped groove



As the sensor measures the peak position of the light spot, it is not affected by secondary reflected light, resulting in no error.





TECHNICAL GUID

INFORMATION

LASER DISPLACEMENT SENSOR

Features

Non-contact detection

 Detects an object without contact. Non-contact sensing ensures longer life for the sensor and absolutely no damage to the object.


High accuracy detection

• Advanced optical system and electronic circuit technology have achieved a sensing accuracy of up to 0.01 µm 0.0004 mil (**HL-C2** series).

Effective use of the laser displacement sensors


When there are variations in materials and colors

 When performing a displacement measurement of a moving object that has significantly different materials and colors, errors can be reduced to a minimum by mounting the sensor as shown below.




Measurement of rolling objects

• When measuring a rolling object, mount the sensor as shown below. It can reduce influences such as downward / upward fluctuations and displacement.



When objects have an uneven surface

• When a moving object has an uneven surface, mount the sensor as shown below in order to reduce the influence of step edges when measuring the object.



Short response time


• The use of an optical beam for detection and complete electronic circuitry makes the sensors respond so quickly that they can be easily used on a high-speed production line.

Detection according to workpieces

 Stable detection is possible by using the minute spot light for minute objects, such as IC pins, and the line spot light for diffusely reflecting surfaces, such as cutting surfaces.

Measurement in a narrow space or a depressed portion


 When performing a displacement measurement in a narrow space or in a hole, mount the sensor so that the light route from the emitting parts to the receiving parts will not be interrupted.




Measurement of black objects or objects that reflect little light

• When performing a displacement measurement on black objects that reflect little light, the resolution becomes lower. This is because the amount of light is reduced at the receiving part and the signal received from the PSD becomes small. In such a case, mount the sensor as shown below in order to increase the amount of light received.

<For specular reflection>



/ Bringing the sensor close \ to an sensing object /



Mounting the sensor this way increases the amount of light received by receiving specular reflective light


which is a greater amount of

reflected light.

The amount of light received is in inverse proportion to the squared distance between the sensor and an object. When shortening the distance, the amount of light received increases.

When mounting the sensor head to the wall

 Mount the sensor as shown below in order to prevent multiple reflective light rays from entering into the receiving part on the wall. In addition, in the case that the reflective rate of the wall is high, using a non-glossy black wall is effective.





Inductive Proximity Sensors

Displacement Sensors Electrostatic Sensors Static Removers About Laser Beam General Precautions

MEASUREMENT SENSOR


Features

Measurement sensors have an emitter and a receiver for measuring the width or the position of an object. There are two
methods; the light intensity variation method that identifies changes in the amount of light received and the CCD method
that uses a CCD on the receiving element.

Principle of detection

Light intensity variation method

• Light is emitted parallel to the receiver from the emitter, and this parallel light is collected in the receiving element through the receiver lens. If there is a light interrupted object within the parallel light, then the light is interrupted and the amount of light received changes. Due to this change, the amount of light can be output as the size of the light interrupted object.




Effective use of the measurement sensors

Shading calibration

 The CCD method measurement sensors have variations in the distribution of light intensity from the semiconductor laser that is the light source and the CCD image sensor has variations in sensitivity to the light received. Therefore, the distribution of light-receiving sensitivity becomes uneven. In order to equalize it, the LD series (LD-C60) has the shading calibration function. Implement the shading calibration before sensing.


Distribution of the light intensity Distribution of the light intensity





• Light is emitted parallel to the receiver from the emitter, and the linear CCD image sensor on the receiver receives the light.

If there is a light interrupted object within the parallel light, then the light is interrupted and a shadow that is proportional to the size of the light interrupted object is produced on the CCD. Due to this shadow, the size and position of the object is output.




EDDY CURRENT TYPE DISPLACEMENT SENSOR

Principle of detection

 The eddy current type displacement sensors produce a high-frequency magnetic field by applying a high-frequency current to the coil inside the sensor head. If there is a measurement object (metal) within this magnetic field, then excess current is produced around the magnetic flux that passes through the object surface due to the electromagnetic induction effect. This changes the impedance of the coil within the sensor head.


The eddy current type displacement sensors measure the distance based on the change of the oscillation caused by this phenomenon.



Eddy current

Operation principles of the GP-X series and GP-A series

• As the distance between the measurement object (metal) and the sensor head becomes smaller, then greater excess current is produced and the loss of energy at the sensor head increases. As a result, when the distance is made closer, the oscillation becomes smaller. When the distance is greater, the oscillation becomes greater. The sensors rectify the variations in the oscillation and that causes a change of the DC voltage. The rectified signal is almost proportional to the distance. However, linearity is corrected through linearization and an output that is proportional to the distance can be obtained.



Mutual interference

 When placing the same model sensors close to each other, the resolution may become poor due to the influence of the same frequency magnetic field of the other sensors. This is called mutual interference. There are methods to prevent mutual interference as shown below.

Mount the sensors with enough space so that no



(For details, refer to the section "PRECAUTIONS FOR PROPER USE" of each sensor.

<Use interference provention function. (GP-X)>


<Use along with a different frequency type. (GP-A)>


Output correction according to materials

 The sensors are adjusted so that a standard sensing object is 0 V when in a direct contact and 5 V when at the maximum sensing range (full scale). Then, the output is corrected so that the sensing range becomes proportional to the analog output according to the materials being sensed.

GP-X series


The output is linearly corrected for three materials [stainless steel (SUS304), iron, and aluminum]. Selection of the materials is performed by switching settings within the controller. In addition, the sensor is equipped with a three-point calibration function. Adjusting the three points, the contact point (zero point), the half scale (half of the maximum sensing range), and the full scale (the maximum sensing range) optimizes the linearity of the distance to the object and the output.





GP-A series

The output is linearly corrected with iron as the standard sensing object. Therefore, other materials (stainless steel, aluminum, copper, etc.) will have different output characteristics. Refer to the sensing characteristics in the catalog. In addition, fine adjustment is possible through the shift adjustment and span adjustment.



Photoelectric Sensors Pressure Sensors

Flow Sensors

Inductive Proximity Sensors

Electrostatic Sensors Static Removers About Laser Beam General Precautions

1397 DISPLACEMENT SENSORS

GLOSSARY

Term	Description
Resolution	When enlarging the linear output, there are minute fluctuations caused by noise inside the sensor even if an object is at rest. The width of this fluctuation is called resolution. When the width is smaller, the resolution is higher. In the digital signal process method, the measurement value is the minimum readable value. It is the minimum value that the device can indicate or that can be digitally output.
Linearity	The linear output of the displacement sensor is proportional to the amount of displacement. It is almost linear; but, there is a little gap between the actual line and the ideal line. Linearity indicates how large this gap is. This is also called linearity error. Example: In case of 2 mm 0.079 in sensing type $\underbrace{2.0}_{0.079} \underbrace{2.0}_{0.039} \underbrace{1.0}_{0.039} \underbrace{1.0}_{0.039} \underbrace{1.0}_{0.039} \underbrace{1.0}_{0.039} \underbrace{1.0}_{0.039} \underbrace{1.0}_{0.079} \underbrace{1.0}_{0.039} \underbrace{2.0}_{0.079} \underbrace{1.0}_{0.039} \underbrace{2.0}_{0.079} \underbrace{1.0}_{0.039} \underbrace{2.0}_{0.079} \underbrace{1.0}_{0.039} \underbrace{1.0}_{0.079} \underbrace{1.0}_{0.039} \underbrace{1.0}_{0.079} \underbrace{1.0}_{0.039} \underbrace{1.0}_{0.079} \underbrace{1.0}_{0.039} \underbrace{1.0}_{0.079} \underbrace{1.0}_{0.039} \underbrace{1.0}_{0.079} \underbrace{1.0}_{0.079} \underbrace{1.0}_{0.039} \underbrace{1.0}_{0.079} \underbrace{1.0}_{$
Temperature characteristics	When the ambient temperature changes, the linear output also fluctuates. This fluctuation range is called temperature drift, and it indicates the value caused by changes of 1 °C 34 °F. For example, if 0.01 % F.S./°C is regarded as F.S. (Full Scale) = 10 V, it indicates that the fluctuation of 0.01 % of F.S. per 1 °C 34 °F, is 1 mV.
Spot diameter Optical displacement sensor	The spot diameter is generally defined to be $1/e^2(13.5 \%)$ of the sensor's laser beam center light strength. There is light that leaks outside the defined range; therefore, if the reflective rate of the light is high compared to the area around the sensing point, influences may be exerted.
Measurement center distance (Optical displacement sensor	This refers to the distance from the emitter front of the sensor to the center of the measuring range. The sensors with voltage output are the ones where the linear output voltage becomes 0 V at this time.

Photoelectric Sensors Pressure Sensors Flow Sensors Displacement Sensors Electrostatic Sensors Static Removers About Laser Beam General Precautions