


ODW-series

How to use ODW-series in existing networks

RS-232 point-to-point connection




 Fibre Optic
 RS-232

ODW-series

How to use ODW-series in existing networks


RS-232 multidrop connection



ODW-series

How to use ODW-series in existing networks

RS-422/485 point-to-point connection



ODW-series

How to use ODW-series in existing networks

RS-422/485 multidrop connection

