

Remote  
Terminal

**GT1-ID16ML-1**


Connector  
Terminal  
Conversion Unit

**XW2D-20G6**

Connecting  
Cable

**XW2Z-□□□A**

Connections  
Diagrams



COM terminals are connected internally.