

Remote
Terminal

GT1-OD16ML


Connector
Terminal
Conversion Unit

XW2D-20G6

Connecting
Cable

XW2Z-□□□A

Connections
Diagrams



Each V and G terminal is connected internally. V and G on the connector and terminals V and G are connected internally.