



# For C200H-NC211 Use

XW2Z-□□□J-A2  
 XW2Z-□□□J-A5  
 (R88D-UEP□□□)



## Connector




MR-34LF  
 (Honda Tsushin Kogyo)

XG4M-3430-T

## Wiring Diagram XW2Z-□□□J-A2

C200H-NC211  
 (Multi-pole square  
 connector with 34 poles)

XW2B-40J6-2B  
 (XG4M-3430)



## XW2Z-□□□J-A5

C200H-NC211  
 (Multi-pole square  
 connector with 34 poles)

XW2B-40J6-2B  
 (XG4M-3430)

