


For CQM1 Use


XW2Z-□□□J-A3



Connector

Position Control
Unit side

Servo Terminal
Unit side



XM2D-1501 Socket
XM2S-1511 Hood

XG4M-1630-T

Wiring Diagram XW2Z-□□□J-A3

CQM1-CPU43-EV1
(XM2D-1501)

XW2B-20J6-3B
(XG4M-1630)

