


For C200HW-NC113 Use

XW2Z-□□□J-A6
XW2Z-□□□J-A8
(R88D-UEP□□□)


Connector



Wiring Diagram XW2Z-□□□J-A6

C200H-NC113
(PCB I/O connector with 40 poles)

XW2B-20J6-1B
(XG4M-2630-T)



XW2Z-□□□J-A8

C200H-NC113
(PCB I/O connector with 40 poles)

XW2B-20J6-1B
(XG4M-2630-T)

