


For C200HW-NC213/NC413 Use

XW2Z-□□□J-A7
XW2Z-□□□J-A9
(R88D-UEP□□□)

Connector

Position Control
Unit side

Servo Terminal
Unit side




MR-34LF
(Honda Tsushin Kogyo)

XG4M-3430-T

Wiring Diagram XW2Z-□□□J-A7

C200H-NC213/NC413
(Multi-pole square
connector with 34 poles)

XW2B-40J6-2B
(XG4M-3430-T)



XW2Z-□□□J-A9

C200H-NC213/NC413
(Multi-pole square
connector with 34 poles)

XW2B-40J6-2B
(XG4M-3430-T)

