Easy-Teach Colour Detection Sensor

Easy-Teach Colour Detection Sensor

The E3X-DACLR provides reliable and easy to set up one-touch colour verification. Up to four colours can be identified. The separate amplifier allows mounting in easily accessible areas for operators while the small sensor head can be mounted in locations even when space is limited.

- · Easy to set up one-touch colour verification for 1 to 4 colours
- Model for remote teaching
- Small sensor head for easy mounting even when space is tight
- White LED and multi detection modes for reliable operation even for challenging applications



Ordering Information

Туре	Output	Tolerance adjustment	Connection method	Order code PNP ^{*1}
Single colour detection	Digital colour detected out	 Object teaching (good sample) with auto- 	M8 4-pin pigtail (with 30 cm PVC cable) ^{*2}	E3X-DACLRX1P-M3J 0.3M
1 to 4 colour detection	Digital colour detected out (with bank switching)	tolerance – 2-point teaching (good and bad sample)		E3X-DACLRX4P 2M

*1. NPN models are available. Contact your Omron representative.

*2. Models with 2 m PVC cable or M12 pigtail connector are available. Contact your Omron representative.

Content list

All products can be ordered separately under the following order codes:

E3X-CLRX1P-M3J 0.3M

1 x	E32-L15	Fiber sensing head
1 x	E3X-DAC8-S	Amplifier
1 x	E3X-CN21-M3J-2 0.3M	M8-4 pin amplifier connector
1 x	AFBN0044	E3X-DACLR Quick Start Guide

E3X-CLRX4P 2M

1x E32-L15	Fiber sensing head
1x E3X-DAC51B-S 2M	Amplifier with 2m PVC cable
1 x AFBN0044	E3X-DACLR Quick Start Guide

Ratings and Specifications

Amplifier Units

Item	Туре	Single colour	1 to 4 colour		
Light source (wavelength)		White LED (420 to 700 nm)			
Sensing method		C Mode: RGB ratio determination (or I Mode: Light intensity determination for red, green, or blue; Black Mode: Determination of total light intensity for red, green, and blue) *1			
Number of registered colors		1	4 (2-color simultaneous determination × 2 banks)		
Power su	ipply voltage	12 to 24 VDC \pm 10%, ripple (p-p) 10% max.			
Power co	onsumption	960 mW max. (current consumption: 40 mA max	at power supply voltage of 24 VDC)		
Control o	outputs	NPN or PNP open collector Load power supply voltage: 26.4 VDC max. Load current: 50 mA max. (residual voltage: 2 V max.)			
Number of	of control outputs	1	2		
Remote o	control input		No-voltage input (contact/transistor) *2		
Protectio	on circuits	Reverse polarity for power supply connection, Outp	out short-circuit, Reversed output polarity protection		
Response time Super-high-speed mode *3 High-speed mode Standard mode High-resolution mode		Operate or reset: 60 µs Operate or reset: 300 µs Operate or reset: 1 ms Operate or reset: 4 ms	Operate or reset: 120 µs Operate or reset: 600 µs Operate or reset: 2 ms Operate or reset: 8 ms		
	ty setting (color regis- llowable range)	 Object teaching (good sample) with auto-tolera 2-point teaching (good and bad sample) 			
	Operation mode	ON for match (ON for same color as registered color) or O	N for mismatch (ON for different color from registered colo		
	Timer function	Timer type: OFF delay, ON delay, or one-short,	Timer time: 1 ms to 5 s (variable)		
	Control outputs		Output for each channel, AND output, and OR output		
Functions	Remote control		Bank switching (switching between banks A and B and banks C and D)		
	Display switch *4	Seven patterns total: Match + Threshold, Margin + Threshold, Analog bar display, Peak + Bottom, etc.			
	Initialization	Initial reset (factory defaults) or user reset (saved settings)	Initial reset (factory defaults)		
	Zero reset	Supported	Not supported		
Indicator	S	Operation indicator (orange)/I mode display indicator (orange)	Operation indicator for each channel (orange)		
Digital di	splay	7-segment displays (Main display: Red, Sub-display: Green)			
Display d	lirection	Switchable between normal and reversed.			
Ambient side)	illumination (Receiver	Incandescent lamp: 3,000 lux Sunlight: 10,000 lux			
Ambient	temperature range *5	Operating: -25°C to 55°C, Storage: -30°C to 70°C (with no icing or condensation)			
Ambient	humidity range	Operating and storage: 35% to 85% (with no condensation)			
Insulation resistance		20 MΩ min. (at 500 VDC)			
Dielectric strength		1,000 VAC at 50/60 Hz for 1 minute			
Vibration resistance		Destruction: 10 to 50 Hz with a 1.5-mm double amplitude for 2 h each in X, Y and Z directions			
Shock resistance		Destruction: 500 m/s ² , for 3 times each in X, Y and Z directions			
Degree of protection		IEC IP50 (with Protective Cover attached)			
Connecti	on method	Fiber connector with 30 cm PVC cable and M8 plug Pre-wired (standard cable length: 2 m)			
Weight (packed state)		Approx. 100 g			
weight (p	· · · · · · · · · · · · · · · · · · ·				
Materials	Case	Polybutylene terephthalate (PBT)			

*1. When teaching with/without a workpiece, the best sensing method will be automatically selected (RGB ratio (C Mode) or light intensity determination (I Mode)). If color differences are not strong enough and RGB ratios would result in unstable detection, then light intensity determination (I Mode) will be selected. The detection mode can be set to C, I, or Black Mode. *2. Input Specifications

2

	Contact input (relay or switch)	Non-contact input (transistor)
NPN	ON: Shorted to 0 V (sourcing current: 1 mA max.). OFF: Open or shorted to Vcc.	ON: 1.5 V max. (sourcing current: 1 mA max.) OFF: Vcc - 1.5 V to Vcc (leakage current: 0.1 mA max.)
PNP	ON: Shorted to Vcc (sinking current: 3 mA max.). OFF: Open or shorted to 0 V.	ON: Vcc - 1.5 V to Vcc (sinking current: 3 mA max.) OFF: 1.5 V max. (leakage current: 0.1 mA max.)

- *3. Mutual interference prevention cannot be used in super-high-speed mode, and light intensity determination (I Mode) must be used. In super-high speed hidde, and light intensity determination (I Mode) must be used. The response time will be 150 μs if an AND or OR is set for the control outputs.
 *4. With light intensity determination (I Mode and Black Mode), the correlation is not displayed, but rather the light intensity is displayed.
 *5. The allowable ambient operating temperature changes according to the number of Light that are light.
- number of Units that are linked. 2 Units: -25 to 55°C, 3 to 10 Units: -25 to 50°C, and
 - 11 to 16 Units: –25 to $45^{\circ}C$

Amplifier Unit Connector

Item Model		E3X-CN21-M3J-20.3M		
Rated current		2.5 A		
Rated voltage 50 V		V		
Contact resistance		20 mΩ max. (20 mVDC max., 100 mA max.) (The figure is for connection to the Amplifier Unit and the adjacent Connector. It does not include the conductor resistance of the cable.)		
No. of insertions		Destruction: 50 times (The figure for the number of insertions is for connection to the Amplifier unit and the adjacent Connector.)		
Materials	Housing	Polybutylene terephthalate (PBT)		
Materials	Contacts	Phosphor bronze/gold-plated nickel		
Weight (packed state) Approx. 55 g		Approx. 55 g		

Pin and wire arrangement

		Connector	Cable colour	
M8		1	brown	+
		2	orange/white	Output 2 or ext. input
		3	blue	-
		4	black	Output 1
			pink	Ext. Input

I/O Circuit Diagrams


NPN Output (available on request)

Model	Operation mode	Timing charts	Operation selector switch	Output circuit
Single colour	ON for match	Match Mismatch Operation ON Indicator (orange) OFF Output transistor OFF Load Operate (e.g., relay) Reset (Between brown and black leads)	LIGHT ON (L-ON)	Display Operation I mode indicator (orange) Indicator
	ON for mismatch	Match Mismatch Operation ON indicator (orange) OFF Output transistor OFF Load Operate (e.g., relay) Reset (Between brown and black leads)	DARK ON (D-ON)	Blue Blue
1 to 4 colours	ON for match	Match Mismatch Operation ON Output transistor OFF Load (e.g., relay) GFF (Between brown and black leads)	LIGHT ON (L-ON)	Display Ch2 operation indicator Ch1 Co operation indicator Ch1 Co indicator Ch1 Co indicator Photo- electric (orange) (orange) (orang
	ON for mismatch	Match Mismatch Operation ON indicator (orange) OFF Output ON transistor OFF Load Operate (e.g., relay) Reset (Between brown and black leads)	DARK ON (D-ON)	Conception of the second secon
PNP Output				
Model	Operation mode	Timing charts	Operation selector switch	Output circuit
Single colour	ON for match	Match Mismatch Operation ON Output ON transistor OFF Load Operate (e.g., relay) Reset (Between blue and black leads)	LIGHT ON (L-ON)	Display Operation I mode indicator (orange) Indicator IOrange) Photo- electric Black Control output 12 to
	ON for mismatch	Match Mismatch Operation ON indicator (orange) OFF Output ON transistor OFF Load Operate (e.g., relay) Operate (Bestween blue and black leads)	DARK ON (D-ON)	Black 12 to 12 to 24 VDC
1 to 4 colours	ON for match	Match Mismatch Operation ON indicator (orange) OFF Output ON transistor OFF Load Operate (e.g., relay) Operate (Bestween blue and black leads)	LIGHT ON (L-ON)	Display Ch2 operation indicator (orange) Ch1 Ch1 Ch1 Ch2 operation indicator (orange) Operation indicator (orange) Pink External indicator Ch1 control Black output 12 to
	ON for mismatch	Match Mismatch Operation ON indicator (orange) OFF Output ON transistor OFF Load Operate (e.g., relay) Operate (Bestween blue and black leads)	DARK ON (D-ON)	Grange) electric Sensor main circuit Corange output Blue Blue Corange Blue Corange Ch2 control Ch2 control Ch2 control Blue Corange Ch2 control Ch2 co
Note 1. Timing Charts for Timer Function Settings (T: Set Time)			2. Control Outputs (AND, OR, Sync) and Timing Chart for Timer Settings	
Match Mismatch L-ON OFF D-ON OFF				(T: Set Time) CH1 ON OFF CH2 ON OFF CH2 ON (AND) OFF CH2 ON (

AUDIN - 8, avenue de la malle - 51370 Saint Brice Courcelles - Tel : 03.26.04.20.21 - Fax : 03.26.04.28.20 - Web : http://www.audin.fr - Email : info@audin.fr

Nomenclature

Amplifier Units Single colour



Safety Precautions

Refer to Warranty and Limitations of Liability.

MARNING This product is not designed or rated for ensuring safety of persons either directly or indirectly.

Do not use it for such purposes.

Do not use the product with voltage in excess of the rated voltage. Excess voltage may result in malfunction or fire.

Never use the product with an AC power supply.




Otherwise, explosion may result.

High-temperature environments may result in burn injury.



1 to 4 colour



Precautions for Safe Use

The following precautions must be observed to ensure safe operation of the Sensor.

- 1. Do not use the Sensor in an environment where explosive or flammable gas is present.
- 2. Do not use the Sensor in a location subject to splattering of water, oils, or chemicals.
- 3. Do not attempt to disassemble, repair, or modify the Sensor.
- 4. Do not apply voltages or currents that exceed the rated range to the Sensor.
- 5. Do not use the Sensor in an ambient atmosphere or environment that exceeds the ratings.
- 6. Wire the power supply correctly, including the polarity.
- 7. Connect the load correctly.
- 8. Do not short-circuit the load at both ends.
- 9. Do not use the Sensor if the case is damaged.
- 10. Dispose of the Sensor as industrial waste.
- 11. Do not use the Sensor in locations subject to direct sunlight.
- 12. Burn injury may occur. The Sensor surface temperature rises depending on application conditions, such as the ambient temperature and the power supply voltage. Use caution when operating or performing maintenance on the Sensor.

Precautions for Correct Use

Do not use the product in atmospheres or environments that exceed product ratings.

Amplifier Unit • Designing

Operation after Turning Power ON

The Sensor is ready to detect within 200 ms after the power supply is turned ON. If the Sensor and load are connected to separate power supplies, be sure to turn ON the Sensor first. Time may be required for the degree of match to stabilize after the power supply is turned ON.

Operation When Turning Power OFF


Output pulses may occur when the power is turned OFF. Turn OFF the power supply to the load and the load line before turning OFF the power supply to the Sensor.

Mounting


Connecting and Disconnecting Connectors

Mounting Connectors

 Insert the Master or Slave Connector into the Amplifier Unit until it clicks into place.




Attach the protector seals (provided as accessories) to the sides of master and slave connectors that are not connected.



Note: Attach the seals to the sides with grooves.

Removing Connectors


- 1. Slide the slave Amplifier Unit(s) for which the Connector is to be removed away from the rest of the group.
- 2. After the Amplifier Unit(s) has been separated, press down on the lever on the Connector and remove it. (Do not attempt to remove Connectors without separating them from other Amplifier Units first.)




Adding and Removing Amplifier Units

Adding Amplifier Units

1. Mount the Amplifier Units one at a time onto the DIN track.



2. Slide the Amplifier Units together, line up the clips, and press the Amplifier Units together until they click into place.




Removing Amplifier Units

Slide Amplifier Units away from each other, and remove from the DIN track one at a time. (Do not attempt to remove Amplifier Units from the DIN track without separating them first.)

- Note 1. The specifications for ambient temperature will vary according to the number of Amplifier Unit used together. For details, refer to *Ratings and Specifications*2. Always turn OFF the power supply before joining or separating
 - Amplifier Units.

Mounting the End Plate (PFP-M)

An End Plate should be used if there is a possibility of the Amplifier Unit moving, e.g., due to vibration.




AUDIN - 8, avenue de la malle - 51370 Saint Brice Courcelles - Tel : 03.26.04.20.21 - Fax : 03.26.04.28.20 - Web : http: www.audin.fr - Email : info@audin.fr

Fiber Connection

The E3X Amplifier Unit has a lock button for easy connection of the Fiber Unit. Connect or disconnect the fibers using the following procedures:

1. Connection

Open the protective cover and raise the lock lever to release the lock. Next, insert the fibers according to the fiber insertion marks on the side of the Amplifier Unit, and lower the lock lever.




Note: Do not pull on, compress, or otherwise exert excessive force on the fibers after connecting them to the Amplifier Unit. (Do not exert more than 0.3 N·m.)

Note: If one of the fibers from the Fiber Unit has a white line, such as with a Coaxial Sensor, that fiber is for the Emitter. Insert it into the Emitter section. Refer to Dimensions for the Fiber Unit to see if there is an Emitter fiber.

2. Disconnecting Fibers

Remove the protective cover and raise the lock lever to pull out the fibers.



Note 1. To maintain the fiber properties, confirm that the lock is released before removing the fibers.2. Be sure to lock or unlock the lock button within an ambient temperature

range between -10° C and 40° C.

Adjusting

Mutual Interference Protection Function

Light from other sensors can cause the value on the digital display to become somewhat unstable. If this occurs, reduce the threshold to create a greater margin and enable more stable detection.

Output Short-circuits Protection

OVER/CUR will flash on the display if the output short-circuit protection function operates due to a load short-circuit in a control output. If this occurs, check the load connections.

EEPROM Writing Error

If the data is not written to the EEPROM correctly due to a power failure or static-electric noise, initialize the settings with the keys on the Amplifier Unit. ERR/EEP will flash on the display when a writing error has occurred.

Optical Communications

Several Amplifier Units can be slid together and used in groups. Do not, however, slide the Amplifier Units or attempt to remove any of the Amplifier Units during operation.

Others


Protective Cover

Always keep the protective cover in place when using the Amplifier Unit.

Fiber Unit

Installation Precautions Glossy Sensing Objects

If the sensing object is glossy, detection may not be stable. If the Sensor is inclined by 5° to 20° when using a glossy sensing object, as shown below, detection capabilities can be increased and stable detection achieved.




7


Dimensions

(Unit: mm) Tolerance class IT16 applies to dimensions in this data sheet unless otherwise specified.

Amplifier Units




AUDIN - 8, avenue de la malle - 51370 Saint Brice Courcelles - Tel : 03.26.04.20.21 - Fax : 03.26.04.28.20 - Web : http: www.audin.fr - Email : info@audin.fr



AUDIN - 8, avenue de la malle - 51370 Saint Brice Courcelles - Tel : 03.26.04.20.21 - Fax : 03.26.04.28.20 - Web : http: www.audin.fr - Email : info@audin.fr

OMRON



AUDIN - 8, avenue de la malle - 51370 Saint Brice Courcelles - Tel : 03.26.04.20.21 - Fax : 03.26.04.28.20 - Web : http://www.audin.fr - Email : info@audin.fr

AUDIN - 8, avenue de la malle - 51370 Saint Brice Courcelles - Tel : 03.26.04.20.21 - Fax : 03.26.04.28.20 - Web : http://www.audin.fr - Email : info@audin.fr

11

Read and Understand This Catalog

Please read and understand this catalog before purchasing the products. Please consult your OMRON representative if you have any questions or comments.

Warranty and Limitations of Liability

WARRANTY

OMRON's exclusive warranty is that the products are free from defects in materials and workmanship for a period of one year (or other period if specified) from date of sale by OMRON.

OMRON MAKES NO WARRANTY OR REPRESENTATION, EXPRESS OR IMPLIED, REGARDING NON-INFRINGEMENT, MERCHANTABILITY, OR FITNESS FOR PARTICULAR PURPOSE OF THE PRODUCTS. ANY BUYER OR USER ACKNOWLEDGES THAT THE BUYER OR USER ALONE HAS DETERMINED THAT THE PRODUCTS WILL SUITABLY MEET THE REQUIREMENTS OF THEIR INTENDED USE. OMRON DISCLAIMS ALL OTHER WARRANTIES. EXPRESS OR IMPLIED.

LIMITATIONS OF LIABILITY

OMRON SHALL NOT BE RESPONSIBLE FOR SPECIAL, INDIRECT, OR CONSEQUENTIAL DAMAGES, LOSS OF PROFITS OR COMMERCIAL LOSS IN ANY WAY CONNECTED WITH THE PRODUCTS, WHETHER SUCH CLAIM IS BASED ON CONTRACT, WARRANTY, NEGLIGENCE, OR STRICT LIABILITY.

In no event shall the responsibility of OMRON for any act exceed the individual price of the product on which liability is asserted.

IN NO EVENT SHALL OMRON BE RESPONSIBLE FOR WARRANTY, REPAIR, OR OTHER CLAIMS REGARDING THE PRODUCTS UNLESS OMRON'S ANALYSIS CONFIRMS THAT THE PRODUCTS WERE PROPERLY HANDLED, STORED, INSTALLED, AND MAINTAINED AND NOT SUBJECT TO CONTAMINATION, ABUSE, MISUSE, OR INAPPROPRIATE MODIFICATION OR REPAIR.

Application Considerations

SUITABILITY FOR USE

OMRON shall not be responsible for conformity with any standards, codes, or regulations that apply to the combination of products in the customer's application or use of the products.

At the customer's request, OMRON will provide applicable third party certification documents identifying ratings and limitations of use that apply to the products. This information by itself is not sufficient for a complete determination of the suitability of the products in combination with the end product, machine, system, or other application or use.

The following are some examples of applications for which particular attention must be given. This is not intended to be an exhaustive list of all possible uses of the products, nor is it intended to imply that the uses listed may be suitable for the products:

- Outdoor use, uses involving potential chemical contamination or electrical interference, or conditions or uses not described in this catalog.
- Nuclear energy control systems, combustion systems, railroad systems, aviation systems, medical equipment, amusement machines, vehicles, safety equipment, and installations subject to separate industry or government regulations.
- · Systems, machines, and equipment that could present a risk to life or property.

Please know and observe all prohibitions of use applicable to the products.

NEVER USE THE PRODUCTS FOR AN APPLICATION INVOLVING SERIOUS RISK TO LIFE OR PROPERTY WITHOUT ENSURING THAT THE SYSTEM AS A WHOLE HAS BEEN DESIGNED TO ADDRESS THE RISKS, AND THAT THE OMRON PRODUCTS ARE PROPERLY RATED AND INSTALLED FOR THE INTENDED USE WITHIN THE OVERALL EQUIPMENT OR SYSTEM.

PROGRAMMABLE PRODUCTS

OMRON shall not be responsible for the user's programming of a programmable product, or any consequence thereof.

Disclaimers

CHANGE IN SPECIFICATIONS

Product specifications and accessories may be changed at any time based on improvements and other reasons.

It is our practice to change model numbers when published ratings or features are changed, or when significant construction changes are made. However, some specifications of the products may be changed without any notice. When in doubt, special model numbers may be assigned to fix or establish key specifications for your application on your request. Please consult with your OMRON representative at any time to confirm actual specifications of purchased products.

DIMENSIONS AND WEIGHTS

Dimensions and weights are nominal and are not to be used for manufacturing purposes, even when tolerances are shown.

PERFORMANCE DATA

Performance data given in this catalog is provided as a guide for the user in determining suitability and does not constitute a warranty. It may represent the result of OMRON's test conditions, and the users must correlate it to actual application requirements. Actual performance is subject to the OMRON Warranty and Limitations of Liability.

ERRORS AND OMISSIONS

The information in this document has been carefully checked and is believed to be accurate; however, no responsibility is assumed for clerical, typographical, or proofreading errors, or omissions.

Cat. No. E75E-EN-01 In the interest of product improvement, specifications are subject to change without notice.

OMRON EUROPE B.V.

Wegalaan 67-69, NL-2132 JD, Hoofddorp, The Netherlands Phone: +31 23 568 13 00 AUDIN - & avenue de 13 568 13 70 Saint Brice Courcelles - Tel : 03.26.04.20.21 - Fax : 03.26.04.28.20 - Web : http: www.audin.fr - Email : info@audin.fr Fax: +31 23 568 13 88 Www.industrial.omron.eu