Exclusive Control Unit for Light Curtain SELC10 SERIES





SF4B / SF2BP.481~ / P.515~

Korea's S-mark..... P.1034~





















Selection Guide

SF4B

SF2B

SF-C10

Light Curtains

BSF4-AH80

Optical Touch Switch SW-101 Other Products

Definition of Sensing Heights

Less setup time for safety circuits

Plug-in type control unit

Quick-connection

Connecting to the light curtain is done using plug-in connections, which shortens setup and replacement time.



Easy setup requiring no torque control

A spring method is used for the terminal blocks for connections other than to the light curtain. There is no need to control tightening torques for

Flat-tipped screwdriver

Ferrule (sleeve) terminal

Please arrange separately.)

Release button

Slim type control unit

into narrow spaces inside panels.

Lead wire insertion hole

Slim design

Lead wire



Uses a spring method!

Removable terminal blocks reduce maintenance time

Removable terminal blocks are used. This reduces the work required for reconnecting wiring during maintenance.



Robust type control unit



The strong metal enclosure has a built-in safety relay. It has an IP65 protective structure, so that it can be set up individually without needing to be inserted into a control panel.





22.5 mm 0.886 in thickness. so can be inserted even



using plug-in connector connectionsAUDIN - 8, avenue de la malle - 51370 Saint Brice Courcelles Tel: 03.26.04.20.21 - Fax: 03.26.04.28.20 - Web: http: www.audin.fr - Email: info@audin.fr

SF-C12

SF-C11 / SF-C14EX

SF-C13

Connecting to the light curtain is done

WIRING DIAGRAMS

P.557~

Exclusive Control Unit for Light Curtain SF-C10 SERIES

DIMENSIONS

P.562


PRECAUTIONS FOR PROPER USE

P.560~

It is possible to build muting control circuits using a stand-alone light curtain from the SF4B series. The newlyreleased SF-C14EX application expansion unit allows the light curtain, muting sensors and muting lamps to be connected together directly, so that muting control circuits can be built very easily.

SPECIFICATIONS

P.555~



Both safety and productivity can be obtained by stopping only one part of the device SF-C14EX

Three safety circuit systems packaged into a single unit! Three safety circuit systems ① Light curtain output circuit, 2 Muting control circuit, and 3 Emergency stop circuit are packaged into a single unit. Functions that require multiple safety relay units and muting control

ORDER GUIDE


P.554__

Building of muting control circuits is easy

units can be concentrated into a single unit, which results in large space savings, less wiring and less installation work.

High-speed response 14 ms (Including light curtain)

High-speed response has been achieved due to the adoption of the semiconductor output. Avoids the response delays that occur when using more than one safety relay unit, and greatly reduces the light curtain safety distance and improves ease of working. Of course, it is not necessary to exchange the safety relays within the unit anymore, which contributes to the reduction of running cost.



①Light curtain output circuit ②Muting control circuit

③ Emergency stop circuit

FIBER SENSORS

LASER SENSORS

PHOTOELECTRIC SENSORS

MICRO PHOTOELECTRIC SENSORS

AREA SENSORS

SAFETY COMPONENTS

PRESSURE SENSORS

PROXIMITY SENSORS

PARTICULAR USE SENSORS

SENSOR OPTIONS WIRE-SAVING

SYSTEMS

MEASUREMENT SENSORS

DEVICES LASER MARKERS

Selection Guide
Light Curtains
SF4B
SF2B
BSF4-AH80
Control Units
SF-C10
Optical Touch Switch
SW-101

Other Products Definition of Sensing Heights

ectio

20 ms

Total 14 ms!

Relay replacement is not required!

FIBER SENSORS LASER SENSORS PHOTOELECTRIC SENSORS MICRO PHOTOELECTRIC SENSORS AREA SENSORS

SENSORS SAFETY COMPONENTS

PRESSURE SENSORS

PROXIMITY SENSORS

PARTICULAR USE SENSORS

SENSOR OPTIONS WIRE-SAVING

SYSTEMS MEASUREMENT

SENSORS STATIC CONTROL

LASER

MARKERS

Selection Guide

SF4B

SF2B

Light Curtains

BSF4-AH80

Control Units SF-C10 Optical Touch Switch

SW-101

Products

Definition of Sensing Heights

Other

Three safety circuit systems can be controlled independently so that equipment can be stopped all together or partially SF-C14EX

Motors that use muting control and those that do not use it can be controlled independently!

Controls the motors that use muting control (robots) and the motors that do not use muting control (turntables) with a single unit. When the workpiece comes in, the turntable can be stopped and the robot can keep operating condition, to protect the safety of the operator and to maintain productivity.

Safety circuit ① : Linked to light curtain beam received / interrupted status (partial stop)

When the light curtain is interrupted (when an workpiece enters or a person intrudes), this circuit switches off (open) the safety output and stops the turntable.


Safety circuit 2 : Linked to muting control (partial stop)

If an workpiece enters when the turntable has stopped normally, (muting conditions are achieved), this circuit allows the robot to operate.

If an workpiece enters while the turntable is turning (muting conditions are not achieved), this circuit switches off (open) the safety output and stops the robot.

Safety circuit 🕄 : Linked to emergency stop input (all stop)

When the emergency stop button is pressed, this circuit switches off (open) the safety output and stops all equipment (turntable and robot).




Equipped with blown lamp output for muting lamp

If a lamp in one of the two muting lamps that are connected to the unit blows, a warning is output. It is possible to replace the lamp before both lamps blow and the equipment stops. In addition, auxiliary output that is linked to the muting function, override function and light curtain control output is also available.

	Function	Operation
Auxiliary output 1	Muting output	ON when the muting function is invalid
Auxiliary output 2	Override output	ON when the override function is invalid
Auxiliary output 3	Blown lamp output	ON when the muting lamp is normal
Auxiliary Light curtain auxiliary output 4		ON when the light curtain is in light interrupted condition

Equipped with a digital indicator so that error details can be understood at a glance!

If a problem should occur, the same output (OFF signal) as when the object was detected is maintained in order to ensure safety, and the details of the error appear on the digital display.



Ui 🔲

Polarity selection switch

Supports both PNP and NPN polarities

A single model can be used for PNP / NPN input switching, reducing the number of parts that need to be registered.

SUNX

AUDIN - 8, avenue de la malle - 51370 Saint Brice Courcelles Tel : 03.26.04.20.21 - Fax : 03.26.04.28.20 - Web : http: www.audin.fr - Email : info@audin.fr

NPN

PNP

All Models

FIBER SENSORS

ORDER GUIDE

Designation	Appearance	Model No.	Applicable cable	Description	LASER SENSORS PHOTO- ELECTRIC
Connector connection type control unit		SF-C11	Light curtain connection cable: SFB-CB□ (For SF4B series) SF2B-CB□ (For SF2B series) Extension cable: SFB-CCJ10□	Use 8-core cable with connector to connect to the light curtain. Compatible with up to control category 4. Interference prevention wires and muting function cannot be used.	AREA SENSORS
Robust type control unit		SF-C12	Light curtain connection cable: SFB-CB05-MU Extension cable: SFB-CCJ10 _□ -MU	Use 12-core cable with connector to connect to the light curtain. Interference prevention wires can be used. Compatible with up to control category 4. Muting function cannot be used.	SAFETY COMPONENTS PRESSURE SENSORS INDUCTIVE PROXIMITY
Slim type control unit		SF-C13	Light curtain connection cable: SFB-CCB _□ (-MU) (For SF4B series) SF2B-CCB _□ (For SF2B series) Extension cable: SFB-CC _□ (-MU)	Use a discrete wire cable to connect to the light curtain. Muting function and interference prevention wires can be used. Compatible with up to control category 4.	PARTICULAR USE SENSORS SENSOR OPTIONS
Application expansion unit for the SF4B series		SF-C14EX SF-C14EX-01	Light curtain connection cable: SFB-CB□-EX Extension cable: SFB-CCJ10□	The muting control function and emergency stop input are equipped, expanding the applications of the light curtains. It can be connected to the light curtains using the exclusive connection cable. Compatible with up to control category 4.	WIRE- SAVING SYSTEMS MEASURE- MENT SENSORS STATIC CONTROL DEVICES LASER MARKERS

Note: Refer to the SF4B series (p.488~) and SF2B series (p.520~) for details of applicable cable.

SF-C12 spare relay set

A set of spare relays (2 safety relays and 1 removal tool) is available for the safety relay that is built into the SF-C12. Model No.: SF-C12-RY

Selection Guide
Light Curtains
SF4B
SF2B
BSF4-AH80
Control Units
SE-C10

Optical Touch Switch

SW-101 Other Products

Products Definition of Sensing Heights



FIBER SENSORS

SPECIFICATIONS

LASER SENSORS		Model No.	SF-C11	SF-C12	SF-C13
PHOTO- ELECTRIC SENSORS	Item		-	-	
MICRO	<u> </u>		SF4B / SF2B series	SF4B series IEC 61496-1, UL 61496-1, JIS B 9704-1	Light curtain manufactured by SUNX
PHOTO- ELECTRIC SENSORS		trol category	ISO 13840-1 (EN	954-1, JIS B 9705-1) compliance up to Cat	egory A standards
AREA		ly voltage / Current consumption		Ripple P-P 10 % or less / 100 mA or less (w	o ,
SENSORS	Fuse (power supply)			use, Triggering current: 0.5 A or more, Rese	,
SAFETY			NO contact × 3 (13-14, 23-24, 33-34)	NO contact × 2 (13-14, 23-24)	NO contact × 3 (13-14, 23-24, 33-34)
COMPONENTS PRESSURE	Enabling path Application category		10 contact × 3 (10-14, 20-24, 30-34)	AC-15, DC-13 (IEC 60947-5-1)	100 contact × 0 (10-14, 20-24, 00-04)
SENSORS INDUCTIVE PROXIMITY		Rated operation voltage (Ue) / Rated operation current (le)	30 V DC / 6 A, 230 V AC / 6 A, resistive load (For inductive load, during contact protection) Min. applicable load: 10 mA (at 24 V DC) (Note 2)	(For inductive load, during contact protection)	30 V DC / 4 A, 230 V AC / 4 A, resistive load (For inductive load, during contact protection) Min. applicable load: 10 mA (at 24 V DC) (Note 2)
PARTICULAR		Contact material / contacts	AgSnO, self cleaning, positively driven	AgNiO + 0.2 µm 0.008 mil Au plating, self cleaning, positively driven	AgSnO, self cleaning, positively driven
USE SENSORS		Contact resistance	100 m Ω or less (initial value)	50 m Ω or less (initial value)	100 m Ω or less (initial value)
SENSOR		Contact protection fuse rated	6 A (slow blow)	3 A (slow blow)	4 A (slow blow)
OPTIONS		Mechanical lifetime	10 million operatio	ns or more (switching frequency 180 operat	tions/min.) (Note 3)
WIRE-		Electrical lifetime	100,000 operations or more (swi	itching frequency 20 operations/min., 230 V	AC / 3 A resistive load) (Note 3)
SAVING SYSTEMS	Pick-u	ip delay (Auto reset / Manual reset)	80 ms or less / 90 ms or less	30 ms or less / 30 ms or less	80 ms or less / 90 ms or less
MEASURE- MENT	Resp	oonse time	10 ms or less	14 ms or less	10 ms or less
SENSORS	Auxi	liary output	Safety relay contact (NC contact) ×1 (41-42) (Related to enabling path)	Safety relay contact (NC contact) × 1 (31-32) (Related to enabling path)	Safety relay contact (NC contact) × 1 (41-42) (Related to enabling path)
STATIC CONTROL		Rated operation voltage / current	24 V DC / 2 A, Min. applicable load: 10 mA (at 24 V DC)	30 V DC / 3 A, Min. applicable load: 15 mA (at 24 V DC)	24 V DC / 2 A, Min. applicable load: 10 mA (at 24 V DC)
DEVICES		Contact protection fuse rated	2 A (slow blow)	3 A (slow blow)	2 A (slow blow)
MARKERS	Semiconductor auxiliary output (AUX)		<minus (setting="" for="" ground="" pnp)=""> Max. source current: 60 mA Applied voltage: same as supply voltage (between the semiconductor auxiliary output and +V) Residual voltage: 2.3 V or less (at source current 2 mA or less - Plus ground (Setting for NPN)> Max. sink current: 60 mA) - Residual voltage: 1.5 V or less (at source current 2 mA or less - Residual voltage: 2.3 V or less - Residual voltage: 1.5 V or less - Residual voltage: 2.3 V or less</minus>		 PNP open-collector transistor Max. source current: 60 mA Applied voltage: same as supply voltage (between the semiconductor (auxiliary output and +V) Residual voltage: 2.3 V or less (at source current 60 mA) Leakage current: 2 mA or less
		Output operation	Related to auxiliary output of light curtain		On when the light curtain is interrupted
Selection	Exce	ess voltage category		111	
Guide		Power supply (Ui)	(Green LED (lights up when the power is ON)
Light Curtains	Ors	Enabling path [OUT (Note 4)]	Green	LED (lights up when enabling contacts are	closed)
SF4B	Indicators	Interlock (INTER_LOCK)	Yellow LED (lights up when enabling contacts are opened)		Yellow LED (lights up when enabling contacts are opened)
SF2B	Ine	Fault (FAULT)	Yellow LED (blinks when fault occurs)	Orange LED (lights up when two light curtain input polarity selection switch settings are different)	Yellow LED (blinks when fault occurs)
BSF4-AH80	Exte	rnal relay monitor function	Incorporated	Incorporated (Note 5)	Incorporated
Control Units SF-C10 Optical Touch Switch	Pola	ing edge function rity selection tion (Note 6)	Incorporated (Sliding switch allow Minus ground: Correspond to PNF Plus ground: Correspond to NPN		Incorporated (Cable connection allows selection of plus / minus ground) Minus ground: Correspond to PNP output light curtain Due ground: Correspond to NPN output light curtain
SW-101	Polly	ution degree	i lus ground. Correspond to NEN	2	Plus ground: Correspond to NPN output light curtain
Other		Protection (Note 7)	Enclosure: IP40, Terminal: IP20	IP65	Enclosure: IP40, Terminal: IP20
Products Definition of	ental		· · · · · · · · · · · · · · · · · · ·	o dew condensation or icing allowed), Stora	
Sensing Heights	nme	Ambient temperature Ambient humidity	30 to 85 % RH, Storage: 30 to 95 % RH	35 to 85 % RH, Storage: 35 to 85 % RH	30 to 85 % RH, Storage: 30 to 95 % RH
	Environmental resistance	Vibration resistance	10 to 55 Hz frequency, 0.35 mm 0.014 in amplitude	10 to 55 Hz frequency, 0.75 mm 0.030 in amplitude	10 to 55 Hz frequency, 0.35 mm 0.014 in amplitude
			in X, Y, and Z directions for twenty times each Detachable-type spring gauge terminal	in X, Y, and Z directions for two hours each	in X, Y, and Z directions for twenty times each
	Connection terminal			European terminal	Spring gauge terminal
	Enclosure material Weight		ABS	Die-cast aluminium	ABS
			Net weight: 320 g approx.	Net weight: 1 kg approx.	Net weight: 200 g approx.
	Notes	 conditions used were ar 2) If several SF-C11 or SF a space of 5 mm 0.197 touching each other, re accordance with the arr at right. 3) Relay switching lifetime load, the switching freq 4) The operation indicator if 5) Terminals for utilizing the 	nditions have not been specified precisely, t a ambient temperature of +20 °C +68 °F. F-C13 units are being used in line together, le in or more between each unit. If the units are duce the rated operating current for safety on bient operating temperature as shown in the will vary depending on factors such as the tr uency, and ambient conditions. Is marked as "Enabling" on the unit for SF-C12 he functions of the SF4B series are available g switch to the PNP side for minus ground an	Are mounted close togeth e utput in e graphs ype of 2. ch to the	

 a) Terminals to dulizing the functions of the SF4b series are available.
 b) Please switch the sliding switch to the PNP side for minus ground and to the NPN side for plus ground.
 c) 35 40 45 50 55
 c) 32 95 104 113 122 131
 c) 35 40 45 50 55
 c) 32 95 104 113 122 131
 c) 35 40 45 50 55
 c) 32 95 104 113 122 131 0 32 Tel : 03.26.04.20.21 - Fax : 03.26.04.28.20 - Web : http://www.audin.fr - Email : info@audin.fr

35 40 45 50 55 95 104 113 122 131 - Ambient temperature (°C °F) →



556

FIBER SENSORS

SPECIFICATIONS

<u> </u>	Model No.		LASER
Item		SF-C14EX(-01) (Note 2)	PHOTO
	nectable light curtains	SF4B series	- ELECT SENSO
	licable standards	IEC 61496-1, UL 61496-1, EN 61496-1, JIS B 9704-1	- MICRO PHOT ELEC SENS
Conť	trol category	Applicable to Category 4 based on ISO 13849-1 (EN 954-1, JIS B 9705-1)	
Supr	ply voltage	24 V DC ± 10 % Ripple P-P 10 % or less	AREA SENS
Curr	rent consumption	0.2 A or less (Excluding light curtain and other external connecting device)	SAFETY
Saf	ety outputs fety output 1 fety output 2 fety output 3	PNP open-collector transistor 2 outputs × 3 or NPN open-collector transistor 2 outputs × 3 (selectable using a slider switch) <when is="" output="" pnp="" selected=""> • Maximum source current: 200 mA or less • Applied voltage: same as supply voltage (between the safety output and +V) • Residual voltage: 2 V or less (at 200 mA source current)</when>	- COMPO PRESI SENSI INDUC PROX SENSI
	Operation mode (Output operation)	Safety output 1: ON when the light curtain is in light receiving condition, OFF when the light curtain is in light interrupted condition (Note 3) Safety output 2: ON when the light curtain is in light receiving condition or the muting function is valid OFF when the light curtain is in light interrupted condition and the muting function is invalid (Note 3) Safety output 3: ON when the emergency stop is invalid, OFF when the emergency stop is valid	- PARTIC USE SENSO SENS OPTIC
	Protection circuit (Short-circuit protection)	Incorporated	WIRE SAVII SYST
	Response time	OFF response: 14 ms or less (Safety output 1 and 2: including the response time of the light curtain) ON response: 90 ms or less (auto-reset) / 140 ms or less (manual reset) (Note 4)	MEAS MENT SENS
Au Au Au	iliary outputs uxiliary output 1 uxiliary output 2 uxiliary output 3 uxiliary output 4 (Note 5)	PNP open-collector transistor × 3 or NPN open-collector transistor × 3 (selectable using a slider switch) <when is="" output="" pnp="" selected=""> • Maximum source current: 60 mA or less • Applied voltage: same as supply voltage (between the auxiliary output and +V) • Residual voltage: 2 V or less (at 60 mA source current) * State of the super state of the supe</when>	STA CON DEV LASE MAR
	Operation mode (Output operation)	Auxiliary output 1: ON when the muting function is invalid, OFF when the muting function is valid Auxiliary output 2: ON when the override function is invalid, OFF when the override function is valid Auxiliary output 3: ON when the muting lamp is normal, OFF when the muting lamp is error Auxiliary output 4: ON when the light curtain is in light interrupted condition, OFF when the light curtain is in light receiving condition (Note 5)	
	Protection circuit (Short-circuit protection)	Incorporated	
Muti	ing lamp output	Applicable muting lamp: 24 V DC, 3.6 to 30 W (L1, L2 of each unit)	Sel Gui
	Protection circuit (Short-circuit protection)	Incorporated	Ligh Cur
e	Protection	Enclosure: IP40, Terminal: IP20 (Refer to p.984 for details of standards.)	SF
sti	Ambient temperature	-10 to +55 °C +14 to +131 °F (No dew condensation or icing allowed), Storage: -25 to +70 °C -13 to +158 °F	SF
resi	Ambient humidity	30 to 85 % RH, Storage: 30 to 95 % RH	BSF Co
ental	Dielectric strength voltage	1,000 V AC for one min. between all supply terminals connected together and enclosure	Un
Environmental	Insulation resistance	20 MΩ, or more, with 500 V DC megger between all supply terminals connected together and enclosure	SF – Optic
Enviro	Vibration resistance	10 to 55 Hz frequency, 0.35 mm 0.014 in amplitude in X, Y and Z directions for two hours each	Swit
	Shock resistance	30 G acceleration in X, Y and Z directions for three times each	- SV
Mate	erial	Enclosure: ABS	– Oti – Pro
Conr	nection terminal	Detachable spring gauge terminal	Sens
Weig	ght	Net weight: 250 g approx.	
		<u>, </u>	2 C

Notes: 1) Where measurement conditions have not been specified precisely, the conditions used were an ambient temperature of +20 °C +68 °F.

2) SF-C14EX-01 is Handy-controller non-compatible type.

3) Both safety output 1 and 2 are OFF when the emergency stop is valid regardless of whether the light curtain is in the light receiving or light interrupted condition.

4) The auto-reset cannot be used with safety output 3.
5) The auxiliary output incorporated in the SF4B series is output.

FIRER

AREA SENSORS



LASER MARKERS

Selection Guide

Light Curtains

SF4B

SF2B


BSF4-AH80



Wiring diagram of SF-C11 and SF4B series or SF2B series (Control category 4 or 2)

For PNP output (minus ground)

• Set the light curtain input polarity selection switch to the PNP side and ground the 0 V line.




Notes: 1) The above diagram is when using manual reset. If automatic reset is used, disconnect the lead from X2 and connect it to X3. In this case, a reset (RESET) button is not needed.

- 2) Use a momentary-type switch as the reset (RESET) button.
- 3) Emission halt occurs when the test (TEST) button is open, and emission occurs when the test (TEST) button is short-circuited. If not using the test (TEST) button, short-circuit T1 and T2. However, use a test rod or similar to interrupt the light in order to carry out self-diagnosis separately.

For NPN output (plus ground)


 In the above diagram, set the light curtain input polarity selection switch to the NPN R side and ground the + side.



Wiring diagram of SF-C12 and SF4B series (Control category 4)

For PNP output (minus ground)

 Set the two light curtain input polarity selection switches to the PNP side and connect the FG terminal to the 0 V line.



Note: The above diagram is when using manual reset. If automatic reset is used, connect a normal close-type pushbutton switch between T1 and T2 and leave between X1 and X2 open.

For NPN output (plus ground)

• In the above diagram, set the two light curtain input polarity selection switches to the NPN side and connect the FG terminal to the + side.

When connecting the SF-C11 to the light curtains, make sure to use the 8-core connection cable with a connector. Refer to the SF4B series (p.481~) and SF2B series (p.515~) for details. SFB-CB \square , SF2B-CB \square , S

Terminal arrangement diagram

	Terminal	Function
	A1	+24 V DC
	A2	0 V
GH BY	13-14, 23-24, 33-34	Enabling path (NO contact × 3)
	41-42	Auxiliary output (NC contact × 1)
	X1	Reset output terminal
ot Friend	X2	Reset input terminal (Manual)
	X3	Reset input terminal (Automatic)
	А	Netwood
	В	Not used
	T1	Test output terminal
	T2	Test input terminal
	AUX	Semiconductor auxiliary output

Pin layout for light curtain connectors



A2

14

23

24 33

34 41 42

)	Connector pin No.	Emitter side connector	Receiver side connector
0	1	Interlock (Note)	OSSD2
2	2	+24 V DC	+24 V DC
	3	Emission halt	OSSD1
	4	Auxiliary output	EDM (External relay monitor)
	(5)	Synchronization wire +	Synchronization wire +
	6	Synchronization wire -	Synchronization wire -
	(7)	0 V	0 V
	8	Shielded wire	Shielded wire

Note: It is not used with the SF2B series.

When connecting the **SF-C12** to the light curtains, make sure to use the 12-core connection cable with a connector. Refer to the **SF4B** series (p.481~) for details.

SFB-CB05-MU (Cable length: 0.5 m 1.640 ft) SFB-CCJ10E-MU (Extension cable for emitter, cable length: 10 m 32.808 ft)

SFB-CCJ10D-MU (Extension cable for receiver, cable length: 10 m 32.808 ft)

Terminal arrangement diagram

Terminal	Function	Terminal	Function
FG	Frame ground (F.G.) terminal	R+	Interference prevention wire - (Receiver side)
A2	0 V	R-	Interference prevention wire + (Receiver side)
A1	+24 V DC	E+	Interference prevention wire - (Emitter side)
13-14, 23-24	Enabling path (NO contact × 2)	E-	Interference prevention wire + (Emitter side)
31-32	Auxiliary output (NC contact × 1)	T2	Emission halt input
FB4	External relay monitor	T1	terminal
FB3	terminal 2	X2	Automatic reset / manual reset selection terminal
FB2	External relay monitor	X1	Manual reset: X1 – X2 short-circuited
FB1	terminal 1		

Pin layout for light curtain connectors

	Connector pin No.	Emitter side connector	Receiver side connector
$\mathbb{D} \sim \mathbb{O} \sim \mathbb{O} $	1	Interlock	OSSD2
	2	+24 V DC	+24 V DC
® <u>≮</u> ∽ , , , <u>∕</u> _@	3	Emission halt	OSSD1
	4	Auxiliary output	EDM (External relay monitor)
70	5	Synchronization wire +	Synchronization wire +
Note: Input and	6	Synchronization wire -	Synchronization wire -
output for pin	1	0 V	0 V
Nos. (1) and	8	Shielded wire	Shielded wire
12 are not	9	Interference prevention wire +	Interference prevention wire +
used by this	(10)	Interference prevention wire -	Interference prevention wire -
product	(1)	(Muting lamp output)	(Muting input 1)
	(12)	(Override input)	(Muting input 2)

0

(

(

Ν

· Connect the light curtain control outputs OSSD1 and

OSSD2 to S4 and S2 respectively and ground the + side.

For NPN output (plus ground)

FIRER SENSORS LASER SENSORS

PHOTO-ELECTRIC


SENSORS

LIGHT CURTAIN WIRING DIAGRAMS

Wiring diagram of SF-C13 and SF4B series or SF2B series (Control category 4 or 2)

For PNP output (minus ground)

· Connect the light curtain control outputs OSSD1 and OSSD2 to S1 and S2 respectively.




- Notes: 1) The above diagram is when using manual reset. If automatic reset is used, disconnect the lead from X2 and connect it to X3. In this case, a reset (RESET) button is not needed.
 - 2) Use a momentary-type switch as the reset (RESET) button.
 - 3) This is a test input (pink) for the SF2B series.
 - 4) This is not equipped on the SF2B series.
 - 5) This is a shield for the SF2B series. Output polarity cannot be set.

Terminal arrangement diagram

	ה		
10	A1	Terminal	Function
10	A2 S1	A1	+24 V DC
20	S2 S3	A2	0 V
	S4	S1 to S4	Light curtain control output (OSSD) input terminal
10	AUX X1	AUX	Semiconductor auxiliary output
20	X2 X3	X1	Reset output terminal
	13	X2	Reset input terminal (Manual)
10	14 23	X3	Reset input terminal (Automatic)
10	24 33	13-14, 23-24, 33-34	Enabling path (NO contact × 3)
20	34	41-42	Auxiliary output (NC contact × 1)
	41 42		
hai		Lise a senarate te	minal block to carry out wiring

Use a separate terminal block to carry out wiring for light curtains that cannot be connected to the SF-Č13.



Notes: 1) The above diagram is when using manual reset. If automatic reset is used, disconnect the lead from X2 and connect it to X3. In this case, a reset (RESET) button is not needed.

- 2) Use a momentary-type switch as the reset (RESET) button.
- 3) This is a test input (pink) for the SF2B series.
- 4) This is not equipped on the SF2B series.
- 5) This is a shield for the SF2B series. Output polarity cannot be set.

When connecting the SF-C13 to the light curtains, make sure to use a discrete wire connection cable. Refer to the SF4B series (p.481~) and SF2B series (p.515~) for details SFB-CCB□(-MU), SF2B-CCB□, SFB-CC□(-MU)

SF-C10

Selection Guide

Light Curtains

SF4B SF2B

BSF4-AH80



LASER SENSORS PHOTO-ELECTRIC SENSORS

SAFET COMPONENT

SAVING SYSTEMS

MEASURE-MENT SENSORS

STATIC CONTROL

DEVICES

LASER MARKERS

Selection Guide

Light Curtains

SF4B

SF2B

BSF4-AH80


FIBER SENSORS


LIGHT CURTAIN WIRING DIAGRAMS

Wiring diagram of SF-C14EX and SF4B series (Control category 4)

For PNP output (minus ground)

Set the output polarity selection switch to the PNP side and ground the 0 V line.






Notes: 1) The above diagram is when using manual reset. If automatic reset is used, disconnect the lead from X12 and X22, and connect them to X13 and X23 as shown by the dotted lines. In this case, a reset (RESET) button is not needed. Terminals X31 to X32 are for manual reset only. 2) Use a momentary-type switch for the reset (RESET) button.

For NPN output (plus ground)

Set the output polarity selection switch to the NPN side and ground the + side of the power supply input.



- Notes: 1) The left diagram is when using manual reset. If automatic reset is used, disconnect the lead from X12 and X22, and connect them to X13 and X23 as shown by the dotted lines. In this case, a reset (RESET) button is not needed. Terminals X31 to X32 are for manual reset only
 - 2) Use a momentary-type switch for the reset (RESET) button.

Terminal arrangement diagram

Contro Units SF-C10 Optical Touch Switch SW-101 Other Products Definition of Sensing Heights

14	QI	LIGHT CURTAIN APPLICATION EXPANSION UNIT
24	잃出	SF-C14EX
34	QЦ	
44	QIP	
54	ЮЮ	S12 OID
64	ЮЮ	S21 OTD
S3+	oīb	S22 010
S 3	ЮТЫ	X11
S3-	ŎĨЬ	X12
S4+	ŎТ	X13
S4	ŏfБ	X21
S4-	Жf	X22
T1	XH	
T2	×н	
	XH	
01	ΧЧ	X32 QIP
02	QП	
L1+	ЮЮ	
L1-	OID	
L2+	Oīb	
L2-	ЮĩЫ	⊫+ ÖĨĎ
		⊐⊑ ⊫õĩñ
A1	U.	P B+ KH
A2	ØĪ	

	Terminal	Function	Terminal	Function			
	14	Safety output 1, Light received / Light	S11	Emergency stop			
	24	interrupted output of the light curtain	S12	contact input			
	34	Safety output 2, Light curtain output	S21	2 NC input Between S11 and S12			
	44	including the muting function	S22	Between S21 and S22			
	54	Safety output 3	X11	Safety output 1 reset input			
	64	Emergency stop output	X12	X11 - X12: Manual reset			
	S3+	Muting sensor input 1	X13	X11 - X13: Auto-reset			
	S3	(PNP output type) S3+, S3–: Power supply	X21	Safety output 2 reset input			
	S3-	S3: Sensor output	X22	X21 - X22: Manual reset X21 - X23: Auto-reset Safety output 3 reset input X31 - X32: Manual reset			
	S4+	Muting sensor input 2	X23				
	S4	(NPN output type) S4+, S4–: Power supply	X31				
	S4-	S4: Sensor output	X32				
	T1	Test input terminal Open: Test mode	AUX1	Auxiliary output 1, Muting output			
ļ	T2	Short-circuit: Normal operation	AUX2	Auxiliary output 2, Override output			
	01	Override input terminal Open: Invalid	AUX3	Auxiliary output 3, Blown lamp output			
	O2	Short-circuit: Valid	AUX4	Auxiliary output 4, Light curtain auxiliary output			
	L1+	Muting lamp output	IE+	Interference prevention terminal, Emitter side +			
	L1-	1	IE-	Interference prevention terminal, Emitter side –			
	L2+	Muting lamp output	IR+	Interference prevention terminal, Receiver side +			
	L2-	2	IR-	Interference prevention terminal, Receiver side –			
	A1	+24 V DC					
	A2	0 V					



Pin layout for light curtain connectors

<u>®</u>	Connector pin No.	Emitter side connector	Receiver side connector
k@ .®	1	Interference prevention wire +	Interference prevention wire +
<u> </u>	2	+24 V DC	+24 V DC
	3	Interference prevention wire –	Interference prevention wire –
	4	Auxiliary output	Not used
	5	Synchronization wire +	Synchronization wire +
	6	Synchronization wire –	Synchronization wire –
	1	0 V	0 V
	8	Shielded wire	Shielded wire



FIRER SENSORS

LASER SENSORS

PHOTO-ELECTRIC

SENSORS

MICRO PHOTO-ELECTRIC SENSORS

SENSORS

AFETY OMPONENTS

PRESSURE SENSORS

INDUCTIVE PROXIMITY SENSORS

PARTICULAR

USE SENSORS


SENSOR OPTIONS

WIRE-SAVING SYSTEMS MEASURE-MENT SENSORS STATIC CONTROL DEVICES LASER MARKERS

ARFA

PRECAUTIONS FOR PROPER USE

Part description and function (SF-C14EX)



No.	Description	Function		
1	Emitter side connector	The emitter of SF4B series is connected.		
2	Receiver side connector	The receiver of SF4B series is connected.		
3	Digital indicator (Red)	Lights up or blinks when there is a problem. Lights up when blanking function is enabled.		
4	Power indicator (Ui) (Green)	Lights up when the power is ON.		
5	Test input indicator (TEST) (Yellow)	Lights up when test input is enabled. Blinks while communication with SFB-HC handy-controller is in progress.		
6	Muting sensor 1 indicator (MU1) (Orange)	Lights up when muting sensor 1 is ON.		
\bigcirc	Muting sensor 2 indicator (MU2) (Orange)	Lights up when muting sensor 2 is ON.		
8	Safety output 1 indicator (OUT1) (Green)	Lights up when safety output 1 is ON.		
9	Safety output 2 indicator (OUT2) (Green)	Lights up when safety output 2 is ON.		
10	Safety output 3 indicator (OUT3) (Green)	Lights up when safety output 3 is ON.		
1	Output polarity selection switch	PNP (minus ground) or NPN (plus ground) can be selected. The factory setting is PNP (minus ground).		
(12)	Auxiliary output 1 indicator (AUX1) (Orange)	Lights up when auxiliary output 1 is ON.		
(13)	Auxiliary output 2 indicator (AUX2) (Orange)	Lights up when auxiliary output 2 is ON.		
(14)	Auxiliary output 3 indicator (AUX3) (Orange)	Lights up when auxiliary output 3 is ON.		
(15)	Interlock 1 indicator (INTER LOCK1) (Yellow)	Lights up when interlock 1 is ON.		
(16)	Interlock 2 indicator (INTER LOCK2) (Yellow)	Lights up when interlock 2 is ON.		
17	Interlock 3 indicator (INTER LOCK3) (Yellow)	Lights up when interlock 3 is ON.		

Wiring

 The following solid wire and twisted wires (lead wire) are recommended.

SF-C11

Power supply and output line connector: 0.2 to 2.5mm² (AWG24 to 12) Signal line connector: 0.2 to 1.5mm² (AWG24 to 16)

SF-C13

Single wire: Ø0.4 to Ø1.2 mm Ø0.016 to Ø0.047 in (AWG26 to 16) Twisted wire (lead wire) : 0.3 to 1.25mm² (AWG22 to 16)

SF-C14EX(-01)

Power supply line connector (A1, A2) : 0.2 to 2.5mm² (AWG24 to 12) Other connectors: 0.2 to 1.5mm² (AWG24 to 16)

Refer to P.1027 for general precautions.

Output waveform (Safety output ON) [SF-C14EX(-01)]

· When safety output is ON, self-diagnosis of the output circuit is carried out, so that the output transistor will periodically turn OFF. (OFF pulse width: 100 µs or less) When the OFF signal is fed back, the receiver judges the output circuit as normal. When the OFF signal is not fed back, the receiver judges either the output circuit or wiring as error, and the safety output maintains OFF status.



Since the OFF signal of SF-C14EX might cause malfunction, perform the connecting paying attention to the input response time of the machine to be connected to SF-C14EX

Time chart [SF-C14EX(-01)]

Normal operation

 The diagram shows operation with safety outputs 1 and 2 in manual-reset mode.

	_ight ree										11	
cuitani i								111		1 1 1		
Emergency		Invalio Valid			1	1 11	i	111	i			
Muting sens		ON OFF	 	0 t	I 0 3 se				 		to 3 sec.	
Muting sens		ON OFF ·	1	01	1		-		1			
Reset input		ON OFF		Л	1		-	111 111 111	 		' '' ' '' '	
Reset input		ON OFF	 	ЛĹ	1		1		1	uĽ.		
Reset input	3	ON OFF	Í		1	1 11 1 11	-	111 111 111	1	 	 	Л
Safety outpo (14, 24)		ON OFF ·	1					111 <u>111</u> 111	1			
Safety outpo (34, 44)		ON OFF	i					111	Ĺ			
Safety outpo (54, 64)		ON OFF	 		1	<u> </u> 	1		1			
Auxiliary out (Muting outp		ON OFF										
Auxiliary out (Auxiliary output of ligh	put 4	ON OFF										
Muting lamp output 1 / 2	C	ON OFF	i						 			

- The diagram above is the timing chart of SF-C14EX(-01) in normal operation.
- · In normal operation, auxiliary output 2 (override output) is maintained in the ON state.
- · In normal operation, auxiliary output 3 (muting lamp output) is maintained in the ON state.

SW-101 Other Products Sensing Heights

Selection Guide Light Curtains SF4B

SF2B

BSF4-AH80

SF-C10

Optical Touch Switch



PRECAUTIONS FOR PROPER USE

Time chart [SF-C14EX(-01)]

Test input, Override input

in auto-reset mode.

FIBER SENSORS LASER SENSORS PHOTO-FLECTRIC

PHOTO-ELECTRIC SENSORS MICRO PHOTO-ELECTRIC SENSORS

AREA SENSORS

SAFETY COMPONENTS PRESSURE SENSORS INDUCTIVE PROXIMITY SENSORS PARTICULAR USE SENSORS SENSORS OPTIONS SAVING SVSTEMS MEASURE-MENT SENSORS STATIC CONTROL DEVICES

> LASER MARKERS

Selection Guide

Light Curtains

SF4B

SF2B

BSF4-AH80

Control Units

SF-C10

Optical Touch Switch

SW-101

Products

Sensing Heights

Definition of

Other

Test input Short-o	Dpen
Light Light re curtain Light inte	
Muting sensor 1 / 2	ON 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1
Safety output 1 (14, 24)	ON OFF
Safety output 2 (34, 44)	OFF 3 sec. + Cveride input time. Max. 60 sec. +
Auxiliary output 1 (Muting output)	ON OFF
Auxiliary output 2 (Override output)	ON OFF
Muting lamp output 1 / 2	ON

. The diagram shows operation with safety outputs 1 and 2

- · Safety outputs 1 and 2 are OFF during test input.
- The override function becomes valid when all the conditions listed below are satisfied:
 - An incandescent lamp with 3.6 to 30 W is at least connected to either muting lamp output 1 or 2.
- The signal is input to either muting sensor 1 or 2.
- The override input terminal O1 and O2 is short-circuited and the test input terminal T1 / T2 is opened within 1 sec. (3 sec. continuously)

If one of the three conditions above becomes invalid or the timing exceeds 60 sec., the override function becomes invalid.

Blown lamp output

• The diagram shows operation with safety outputs 1 and 2 in auto-reset mode.

	eceived terrupted		
Muting sensor 1	ON OFF		
Muting sensor 2	ON OFF		
Safety output 2 (34, 44)	ON OFF		
Auxiliary output 1 (Muting output)	ON OFF		
Auxiliary output 3 (Blown lamp output)			
Muting lamp output 1	ON OFF	 J Blown lamp	 Blown lamp
Muting lamp output 2	ON OFF		Blown lamp

• The lamps are monitored during muting state, and if either of them breaks, auxiliary output 3 is turned OFF. If only one lamp breaks, the muting state is maintained, however, if both lamps break, the muting state is canceled immediately.

Others

- When connecting this product to a product other than the connectable input device, the system does not conform to the control category 4 based on ISO 13849-1 (EN 954-1, JIS B 9705-1).
- The power supply unit of SF-C10 series uses the electronic fuse which does not require any replacement.
- When the electronic fuse trips, turn off the power supply and eliminate the cause for the overcurrent. After that, turn the power back on.
- The electronic fuse is not meant to be used for equipment that is operated continuously. Note that the specification may not be satisfied by continuous operation.

- Make sure to carry out the wiring in the power supply off condition.
- Wrong wiring will damage the product.
- Verify that the supply voltage variation is within the rating. Note that if a voltage exceeding the rated range is applied, or if an AC power supply is directly connected, the unit may get burnt or damaged.
- The DC power supply unit must satisfy the conditions given below:
 - 1) Power supply unit authorized in the region where this device is to be used.
- Power supply unit conforming to EMC Directive and Lowvoltage Directive (In case CE conformity is required.)
- Power supply unit conforming to the Low-voltage Directive and with an output of 100 VA or less.
- The frame ground (F.G.) terminal must be connected to ground when using a commercially available switching regulator.
- 5) Power supply unit with an output holding time of 20 ms or more.
- 6) Use an isolation transformer for the DC power supply unit.
- If surges are likely to occur, take countermeasures such as connecting a surge absorber to the origin of the surge.
- 8) Power supply unit corresponding to CLASS 2 (In case UL / c UL conformity is required.)

<Additional information>


As provided in IEC 60536 (CLASS: Protection against Electric Shook), this power supply should require no ground earth and satisfy the insulation distance by double insulation or reinforced insulation.

(If the power supply conforms to Low-voltage Directive and has an output of 100 VA or less, it can be used as a suitable product.

Do not run the wires together with high-voltage lines or power lines or put them in the same raceway. This can cause malfunction due to induction.

- This product is not dust-proof / splash proof. Be sure to put this product into a control box having IP54 construction. (Excluding SF-C12)
- Avoid dust, dirt and steam.
- Take care that the product does not come in direct contact with oil, grease, or organic solvents, such as, thinner, etc.
- Note that this equipment is applicable only in the control circuit grounded in accordance with IEC 60204-1 and JIS B 9960-1, or in the control circuit in which the insulation monitor unit (ground fault detection unit) is included.
- This unit is suitable for indoor use only.
- The seal as shown in the drawing on the below is stuck to the engagement point of unit. If the seal is peeled off or broken, SF-C10 series will not be certified as "Safety equipment" and will not be covered by our guarantee.





DIMENSIONS (Unit: mm in) The CAD data in the dimensions can be downloaded from the SUNX website: http://www.sunx.com

