
Emergency Stop Switch

A22E

Install in 22-dia. or 25-dia. Panel Cutout

- Direct opening mechanism with minimum contact separation of 3 mm in accordance with EN60947-5-1,
 →. (only for NC contacts)
- Safety lock mechanism prevents misuse. (No tampering – in accordance with EN 418)
- Easy mounting and removal of Switch Blocks using an incorporated lever.
- Finger protection mechanism on Switch Unit provided as a standard feature.
- Install using either round, forked crimp terminals, or ferrules.






Model Number Structure

Model Number Legend

Completely Assembled


Shipped as a set which includes the Pushbutton, Lamp (lighted models only), and Switch.



Subassembled


The Pushbutton, Lamp, or Switch can be ordered separately. Use them in combination for models that are not available as assembled Units. These can also be used as inventory for maintenance parts.

Unit Combinations




1. Pushbutton

Lighted/Non-lighted




2. Lamp



3. Switch

Lighted/Non-lighted



^{*1)} Operational voltage: 95 to 110 VAC *2) Operational voltage: 190 to 230 VAC

List of Models

Completely Assembled (Ask your local OMRON representative)

Non-lighted Models

	Appearance	Output	Push-lock turn-reset system	Color of cap
40-dia. head Push-pull		SPST-NC	A22E-MP-01	
rusii-puii		SPST-NO/SPST-NC	A22E-MP-11	
	A22E-MP	DPST-NC	A22E-MP-02	
60-dia. head		SPST-NC	A22E-LP-01	
Push-pull		SPST-NO/SPST-NC	A22E-LP-11	
	A22E-LP	DPST-NC	A22E-LP-02	
30-dia. head	o de	SPST-NC	A22E-S-01	
Push-lock Turn-reset		SPST-NO/SPST-NC	A22E-S-11	
	A22E-S	DPST-NC	A22E-S-02	
40-dia. head Push-lock		SPST-NC	A22E-M-01	
Turn-reset		SPST-NO/SPST-NC	A22E-M-11	Red
	A22E-M	DPST-NC	A22E-M-02	
60-dia. head Push-lock	9	SPST-NC	A22E-L-01	
Turn-reset		SPST-NO/SPST-NC	A22E-L-11	
	A22E-L	DPST-NC	A22E-L-02	
30-dia. head	<u> </u>	SPST-NC	A22E-SK-01	
Push-lock Key-reset		SPST-NO/SPST-NC	A22E-SK-11	
	A22E-SK	DPST-NC	A22E-SK-02	
40-dia. head Push-lock		SPST-NC	A22E-MK-01	
Key-reset		SPST-NO/SPST-NC	A22E-MK-11	
	A22E-MK	DPST-NC	A22E-MK-02	

Lighted Models

Appearance	Output	Lighting	Rated voltage	Push-lock turn-re- set system	Color of cap
40-dia. head			6 VDC	A22EL-M-6D-01	
Push-lock Turn-reset	SPST-NC		6 VAC	A22EL-M-6A-01	
Turn-reset	SFS1-NC		12 VAC/VDC	A22EL-M-12A-01	
_			24 VAC/VDC	A22EL-M-24A-01	
			6 VDC	A22EL-M-6D-11	
	SPST-NO/SPST-NC		6 VAC	A22EL-M-6A-11	
	3F31-NU/3F31-NC	LED	12 VAC/VDC	A22EL-M-12A-11	Red
			24 VAC/VDC	A22EL-M-24A-11	
			6 VDC	A22EL-M-6D-02	
	DPST-NC		6 VAC	A22EL-M-6A-02	
	DP31-NC		12 VAC/VDC	A22EL-M-12A-02	
			24 VAC/VDC	A22EL-M-24A-02	
40-dia. head	CDCT NC	1	110 VAC	A22EL-M-T1-01	
Push-lock	SPST-NC		220 VAC	A22EL-M-T2-01	
Turn-reset with Voltage Reduction Unit	SPST-NO/SPST-NC	1	110 VAC	A22EL-M-T1-11	
	SPS1-NO/SPS1-NC	SI-NC	220 VAC	A22EL-M-T2-11	-
	DDCT NC		110 VAC	A22EL-M-T1-02	
	DPST-NC		220 VAC	A22EL-M-T2-02	

Subassembled

Pushbuttons

Non-lighted

Sealing capability and size		IP65 oil-resistant models	
Sealing capability and size	Small (30 dia.)	Medium (40 dia.)	Large (60 dia.)
Push-pull		A22E-MP	A22E-LP
Push-lock, Turn-reset	A22E-S	A22E-M	A22E-L
Push-lock, key-reset	A22E-SK	A22E-MK	

Lighted

Sealing capability and size	IP65
Sealing capability and size	Medium (40 dia.)
Push-lock, Turn-reset	A22EL-M

Lamp

LED

Rated voltage	6 VDC	6 VAC	12 VAC/VDC	24 VAC/VDC	Super-bright 24 VAC/VDC
Red	A22-6DR	A22-6AR	A22-12AR	A22-24AR	A22-24ASR

Note: For voltage-reduction lighting, use the A22-24AR.

Incandescent

Ra	ated voltage	6 VAC	14 VAC	28 VAC	130 VAC
		A22-5	A22-12	A22-24	A22-H1

Switch (Standard Load)

Without Voltage Reduction Unit

Classification		Non-lighted	Lighted	
Appea	arance			
Switch	Action	Momentary	Momentary	
Contacts		Womentary	Womentary	
	SPST-NO	A22-10M	A22L-10M	
	SPST-NC	A22-01M	A22L-01M	
For standard loads	SPST-NO + SPST- NC	A22-11M	A22L-11M	
	DPST-NO	A22-20M	A22L-20M	
	DPST-NC	A22-02M	A22L-02M	

With Voltage Reduction Unit

Classi	fication	Lighted (110 VAC)	Lighted (220 VAC)	
Appearance				
Switch	Action	Momentary	Momentary	
Contacts		Womentary	Womentary	
	SPST-NO	A22L-10M-T1	A22L-10M-T2	
	SPST-NC	A22L-01M-T1	A22L-01M-T2	
For standard loads	SPST-NO + SPST- NC	A22L-11M-T1	A22L-11M-T2	
	DPST-NO	A22L-20M-T1	A22L-20M-T2	
	DPST-NC	A22L-02M-T1	A22L-02M-T2	

Note: 1. The above illustrations are for the DPST-NO contact.

2. When using with a Voltage Reduction Unit, use the A22-24AR.

Accessories (Order Separately)

Item	Appearance	Classif	ication	Model	Remarks	
		SPST-NO		A22-10	Provided as standard. Order Switch	
Switch Blocks		SPST-NC		A22-01	Blocks only when adding or replacing them.	
		Direct lighting		A22-TN		
Lamp Sockets		Voltage-	110 VAC	A22-T1	Used when changing the lighting	
•		reduction lighting	220 VAC	A22-T2	method.	
Mounting Latches	R	For momentary models	y-action	A22-3200	Provided as standard. Order Mounting Latches only when mounting Switch	
		For alternate-a	ction models	A22-3210	Blocks or Lamp Sockets that are purchased individually.	
Lock Ring		Rounded shap	e	A22Z-3360	The body is equipped with a Lock Fitting. This Lock Fitting is used when a more secure lock feature is required.	
Hole Plug		Round	Round		Can be plugged into pre-cut panel holes for future expansion. The color is black.	
		One hole		A22Z-B101		
Control Boxes (Enclosures)		One hole, yellow box (for emergency stop)		A22Z-B101Y	Material: Polycarbonate resin	
		Two holes		A22Z-B102	1	
		Three holes		A22Z-B103		
Connectors	Ê	Applicable ca- ble diameter	7 to 9 dia.	A22Z-3500-1	Plastic connector used to extend	
		(mm)	9 to 11 dia.	A22Z-3500-2	a cable from the Switch Box.	
25-dia. Ring	0			A22Z-R25	Can be fit into a 25-dia. hole in the panel. Since this is not attached to the main body, order separately.	
Legend Plates for Emer-	SERGENCE)	60-dia. black le low back-grour		A22Z-3466-1	"EMERGENCY STOP" is indicated on	
gency Stop	STOP	90-dia. black le low back-groun		A22Z-3476-1	the plate.	
Lamp Extractor	5	_		A22Z-3901	Rubber tool used to replace Lamps easily	
Tightening Tool	2	_		A22Z-3905	Tool used to tighten nuts from the back of the panel	
Lock Plate				A22Z-3380	Use to fix the lever on the Switch.	

A22E G-309

Specifications

Approved Standards

Recognized organization	Standards	File No.
UL (See note.)	UL508	E41515
AZCO	EN60947-5-1	C9805502

Note: UL-approved for CSA C22.2 No. 14 and bears the c mark.

Approved Standard Ratings

- UL, cUL (File No. E41515) 6 A at 220 V, 10 A at 110 VAC
- EN60947-5-1 (Low Voltage Directive) Rated current: 10 A; Rated voltage: 220 VAC

Ratings

Contacts (Standard Load)

Rated			Rated cu	ırrent (A)	
carry	Rated voltage	AC15 (induc- tive load)	AC12 (resistive load)	DC13 (induc- tive load)	DC12 (resis- tive load)
	24 VAC	10	10		
	110 VAC	5	10		
	220 VAC	3	6		
	380 VAC	2	3		
10	440 VAC	1	2		
	24 VDC			1.5	10
	110 VDC			0.5	2
	220 VDC			0.2	0.6
	380 VDC			0.1	0.2

Note: 1. Rated current values are determined according to the testing conditions. The above ratings were obtained by conducting tests under the following conditions.

(1) Ambient temperature: 20×±2°C (2) Ambient humidity: 65±5%

(3) Operating frequency: 20 operations/minute

2. Minimum applicable load: 10 mA at 5 VDC

Contacts (Microload)

Rated applicable load	Minimum applicable load
50 mA at 5 VDC (Resistive load)	1 mA at 5 VDC

LED Indicators without Voltage Reduction Unit

Rated voltage	Rated current	Operating voltage
6 VDC	60 mA	6 VDC±5%
6 VAC	60 mA	6 VAC/VDC±5%
12 VAC/VDC	30 mA	12 VAC/VDC±5%
24 VAC/VDC	15 mA	24 VAC/VDC±5%

Super-bright LED Indicator

Rated voltage	Rated current	Operating voltage
24 VAC/VDC	15 mA	24 VAC/VDC ±5%

Incandescent Lamp

Rated voltage	Rated current	Operating voltage
6 VAC/VDC	200 mA	5 VAC/VDC
14 VAC/VDC	80 mA	12 VAC/VDC
28 VAC/VDC	40 mA	24 VAC/VDC
130 VAC/VDC	20 mA	100 VAC/VDC

Voltage-reduction Lighting

Rated voltage	Operational voltage	Applicable lamp (BA9S/13□ gold)
110 VAC	95 to 115 VAC	LED Lamp
220 VAC	190 to 230 VAC	(A22-24A□)

Characteristics

Item		Emergency Stop Switches	
		Non-lighted model: A22E	Lighted model: A22EL
Allowable operating	Mechanical	30 operations/minute max.	
frequency	Electrical	30 operations/minute max.	
Insulation resistance		100 MΩ min. (at 500 VDC)	
Dielectric strength		2,500 VAC, 50/60 Hz for 1 min between to 2,500 VAC, 50/60 Hz for 1 min between tended between each terminal and ground	
Vibration resistance		Malfunction (See note 2.): 10 to 55 Hz, 1.	5-mm double amplitude
Shock resistance	Mechanical	1,000 m/s ²	
	Malfunction (See note 2.)	250 m/s ² max.	
Durability	Mechanical	Momentary operation: 300,000 operations min.	
	Electrical	300,000 operations min.	
Ambient temperature (See note 1.)		Operating: -20°C to 70°C Storage: -40°C to 70°C	Operating: -20°C to 55°C Storage: -40°C to 70°C
Ambient humidity		Operating: 35% to 85%	
Degree of protection		IP65 (oil-resistant)	IP65
Electric shock protection of	lass	Class II	
PTI (tracking characteristic)		175	
Degree of contamination		3 (IEC947-5-1)	


Note: 1. With no icing or condensation.

2. Malfunction within 1 ms.

Operating Characteristics (for SPST-NO/SPST-NC)

	Emergency Stop Switches
Item	Push-lock turn-reset system
	A22E, A22EL
Total travel force (TTF) max.	44.1 N
Total travel (TT)	10±1 mm
Releasing force (RF) min.	0.25 N·m max. (See note.)

Note: Rotation torque for Emergency Stop Pushbutton.




(The above figures are examples of the lighted model.)

Safety Lock Mechanism to Prevent Misuse




This Switch can be intentionally used to stop equipment in an emergency. Even if an object or person touches the Pushbutton by mistake, the contact will not be released unless the Pushbutton reaches the lock position.

This Switch uses a finger protection mechanism to prevent electrical shocks. Moreover, it is provided with a mechanism to prevent terminal screws from coming off and also allows connection to either round or forked crimp terminals.




Dimensions







A22E-L Non-lighted models 60-dia. Push-lock, Turn-reset







A22E-MK



Lighted models 40-dia. Push-lock, Turn-reset 0 6.5 13.3 0.5 5.9

AUDIN - 8, avenue de la malle - 51370 Saint Brice Courcelles - Tel : 03.26.04.20.21 - Fax : 03.26.04.28.20 - Web : http: www.audin.fr - Email : info@audin.fr

A22EL-M


Dimensions for Accessories

A22Z-3466-1

Legend Plates For Emergency-stop

Black letters
Yellow
11
STOP
22.2 dia.






A22Z-3476-1

Lamp Extractor A22Z-3901

Tightening Wrench A22Z-3905






Lock Ring A22Z-3360










25-dia. Ring A22Z-R25





Lock Plate A22Z-3380






Control Box (Enclosure)


A22Z-B10□




A22Z-B101 (One Hole) A22Z-B101Y



A22Z-B102 (Two Holes)



A22Z-B103 (Three Holes)




Panel Mounting Hole




Terminal Arrangement

Terminal Arrangement (Bottom View)




Terminal Connection



Note: The above terminal connection diagrams are examples for SPST-NO + SPST-NC.

Panel Cutouts



With Lock Fitting

Without Lock Fitting

Note: 1. When applying coating such as paint to the panel, the dimensions should be those after the application of coating.

- 2. Recommended panel thickness: 1 to 5 mm.
- 3. Use an A22Z-R25 Ring when mounting to a panel with 25-mm holes.

Installation

Mounting to the Panel

Mounting the Operation Unit on the Panel


Insert the Operation Unit (Pushbutton, etc.) from the front surface of the panel, insert the Lock Ring and the mounting nut from the terminal side, then tighten the nut. Before tightening, check that the rubber washer is present between the Pushbutton Unit and the panel.

When using a Legend Plate Frame, put one rubber washer each between the Legend Plate Frame and the panel and between the Operation Unit and the Legend Plate Frame. (One rubber washer will be provided when one Legend Plate Frame is ordered.)


Align the Lock Ring with the groove in the casing, then insert the Lock Ring so that its edge is located on the panel side.

Tighten the mounting nut at a torque of 0.98 to 1.96 N·m.

When using a Lock Ring, replace with the supplied Lock Ring, insert the projecting part into the lock slot, and then tighten the mounting nut




When the panel cutout dimension is 25 dia., remove the supplied rubber washer and mount the 25-dia. Ring as shown below. (Since the A22Z-R25 is not attached to the main body, order separately.)



Mounting the Switch on the Pushbutton Unit


Insert the Pushbutton Unit into the Switch Unit, aligning the arrow mark inscribed on the Case with the lever on the Switch Blocks, then move the lever in the direction indicated by the arrow in the following figure.



Removing the Switch

Move the lever in the direction indicated by the arrow in the following figure, then pull the Pushbutton Unit or the Switch Blocks.

Since the lever has a hole with an inside diameter of 6.5 mm, the lever can be moved in the specified direction by inserting a screw-driver into the hole and then moving the screwdriver.




AUDIN - 8, avenue de la malle - 51370 Saint Brice Courcelles - Tel : 03.26.04.20.21 - Fax : 03.26.04.28.20 - Web : http://www.audin.fr - Email : info@audin.fr

A22E G-317

Assembling the Cap

Emergency Stop Switch


Insert the protrusion of the Tightening Wrench (A22Z-3905) into the Cap slot and then turn to remove the Cap.



Installing/Replacing the Lamp


Installing/Replacing from the Panel Surface

Insert the Lamp Extractor (A22Z-3901) into the lamp, then rotate the Extractor while pressing it.



Installing/Replacing on the Switch


Grip the indicator with your fingers, then rotate the indicator while pressing it against the Switch.



Control Box (Enclosure)


Mounting the Switch

The Standard-size Legend Plate Frame can be mounted. Mount the Frame as shown in the following diagram. Mount the Switch in the same way as for an ordinary panel.




Creating a Cable Port Hole

Place the tip of a screwdriver on the surface where the cable port hole is to be created with the cover attached and strike the screwdriver to punch a hole. Attempts to punch a hole on the other side of the case will damage the Box.



Securing the Connector Cable

- Insert the connector into the cable port hole in the Box and secure with the fixing nut inside the box.
- 2. Open a hole in the thin rubber section of the rubber ring.
- 3. Pass the tightening cap through the cable, insert the cable into the connector, and tighten the hexagonal nut to secure the cable.




Cable diameter	Connector
7 to 9 dia.	A22Z-3500-1
9 to 11 dia.	A22Z-3500-2

Installing/Removing the Switch Blocks

Installing the Switch Blocks


Hook the small protrusion on the Mounting Latch into the groove on the other side of the lever, then push up the Switch Block in the direction indicated by the arrow in the figure below.




Removing the Switch Blocks

Insert a screwdriver between the Mounting Latch and the Switch Block, then push down the screwdriver in the direction indicated by the arrow in the following figure.

Use either of the following screwdrivers.






Wiring

Wiring Round Crimp Terminals

Loosen the terminal screw from the Switch Unit until it completely comes off the groove, insert a screwdriver as shown in the following figure, then push up the washer in the direction indicated by the arrow to temporarily secure it. Now, a round crimp terminal can be connected. After inserting the terminal, tighten the screws to complete wiring.





ALL DIMENSIONS SHOWN ARE IN MILLIMETERS.

To convert millimeters into inches, multiply by 0.03937. To convert grams into ounces, multiply by 0.03527.