LASER SENSORS

PHOTOELECTRIC SENSORS

MICRO PHOTOELECTRIC SENSORS AREA SENSORS SAFETY LIGHT CURTAINS' PRESSURE / FLOW SENSORS INDUCTIVE PROXIMITY SENSORS PARTICULAR USE SENSORS SENSORS

SIMPLE

UNITS

WIRE-SAVING

WIRE-SAVING SYSTEMS

MEASUREMENT SENSORS

> STATIC CONTROL

LASER MARKERS

PLC

ENERGY MANAGEMENT SOLUTIONS

HUMAN MACHINE INTERFACES

FA COMPONENTS

MACHINE VISION SYSTEMS

UV CURING SYSTEMS

Digital Fiber Sensor FX-550 SERIES



	General terms and conditions	F-3
nation	Fiber selection	P.5~
	General precautions	. P.1552~

Selection guide P.3~

CE

sensitivity setting

■ Glossary of terms..... P.1549~





panasonic.net/id/pidsx/global


Significantly improved stability and operation ease thanks to the industry's top* emission power and enhanced versatility! •As of January 2016, in-company survey

Industry's No. 1!* Three times higher emission power and 1.6 times longer sensing range than conventional models! *As of January 2016, in-company survey

Ample sensing distance even with thin fiber

The sensing range of the thin reflective type fiber is about 1.6 times longer than that of a conventional product (the sensing range of the standard reflective type fiber is about 1.4 times longer). This adds extra flexibility to the sensor layout.


	Fiber	Sensing range	e (STD mode)	Rate of increase		_		
-	TIDCI	FX-551	FX-501	in sensing range	FX-551	FD-41 FD-41		
	FT-31	480 mm 18.898 in	315 mm 12.402 in	152 %	STD mode			1.6 times approx.
	FT-42	1,470 mm 57.874 in	1,130 mm 44.488 in	130 %	FX-501	FD-41 FD-41		longer than conventional models!
	FD-41	200 mm 7.874 in	125 mm 4.921 in	160 %	STD mode	>		longer than conventional models.
	FD-61	620 mm 24.409 in	450 mm 17.717 in	138 %		_	·	



Incident light intensity

When the hysteresis is the same, the higher incident light intensity results in more stable detection.

When the hysteresis is the same, the higher incident light intensity results in more stable detection.



Easy adjustment of beam axis

Thanks to the high emission power, a slight deviation of beam axis causes no problem. It is ideal for use in dusty areas* or for detection through an extremely small slit.

* Need to confirm proper operation in installed condition.



Equipped with a mode to minimize the effect of ambient light

When setting to activate the environment resistance mode in the emission frequency setting, the ambient illuminance for LED lights becomes about 2.5 times higher than that in the normal mode. This reduces erroneous detections caused by LED lights.




Simplified functions for improved operation ease

The **FX-500** series and newer models are equipped with only basic functions for improved ease of use. No matter which model you select, they are all easy to use.

MODE NAVI + Direct setting

MODE NAVI uses three indicators and a dual display to show the amplifier's basic operations. The current operation mode can be confirmed at a glance, so even a first-time user can easily operate the amplifier.



Direct setting

during RUN mode.



Direct teaching Press once each for objec "present" and "absent"

Teaching can be done during RUN mode.



FIBER SENSORS

SENSORS PHOTOELECTRIC SENSORS

PHOTOELECTRIC SENSORS

LASER

MICRO

AREA SENSORS

SAFETY LIGHT CURTAINS / SAFETY COMPONENTS

SENSOR OPTIONS SIMPLE WIRE-SAVING UNITS

> WIRE-SAVING SYSTEMS

MEASUREMENT SENSORS

STATIC CONTROL DEVICES

LASER MARKERS

PLC

HUMAN MACHINE INTERFACES

MANAGEMENT SOLUTIONS

MACHINE VISION SYSTEMS

UV CURING SYSTEMS

Selection
Guide
Fibers
Fiber Amplifiers
Other Products

FX-500	
FX-550	
FX-100	
FX-410	

List of functions in PRO mode

threshold value tracking setting.


PRO 1	Response time setting, timer setting, shift amount setting
PRO 2	Teaching lock setting, digital display item setting, digital display turning setting, Eco setting
PRO 3	Display adjustment setting, reset setting, emission frequency setting, threshold value tracking setting


No need to specify a main unit or sub unit

All **FX-500** amplifiers can be used as either a main unit or a sub unit. Just use a main cable or a sub cable to distinguish the two. This reduces the costs of inventory management.

Wire-saving, space-saving

The quick-connection cables enable reduction in wiring. The connections and man-hours required for the relay terminal block setup can be reduced and valuable space is saved.





Note: **FX-550** series is not equipped with a communication function. When connecting to the host communication units **SC-GU3** series and **SC-GU1-485**, please use **FX-500** series.

ORDER GUIDE

Amplifiers Quick-connection cable is not supplied with FX-551(P). Please order it separately.

	Туре	Appearance	Model No.	Emitting element	Output		
-	Connector time	NAVI O OCE	FX-551		NPN open-collector transistor		
	Connector type	All and a second	FX-551P		PNP open-collector transistor		
		NAVI OCCE	FX-551-C2	Red LED	NPN open-collector transistor		
	Cable type		FX-551P-C2		PNP open-collector transistor		

Quick-connection cable is not supplied with the connector type amplifier. Please order it separately. **Quick-connection cables** X Main cable Model No. Туре Description • CN-73-C□ CN-73-C1 Length: 1 m 3.281 ft 0.2 mm² 3-core cabtyre cable, with connector Main cable CN-73-C2 Length: 2 m 6.562 ft on one end (3-core) Cable outer diameter: ø3.3 mm ø0.130 in CN-73-C5 Length: 5 m 16.404 ft Sub cable CN-71-C1 Length: 1 m 3.281 ft 0.2 mm² 1-core cabtyre cable, with connector • CN-71-C Sub cable on one end CN-71-C2 Length: 2 m 6.562 ft (1-core) Cable outer diameter: ø3.3 mm ø0.130 in Length: 5 m 16.404 ft Connectable to a main cable up to 15 cables. CN-71-C5

AN NE ES	End plates	End plates a	are not supplied with	the amplifier. Please order them separately when t	the amplifiers are mounted in cascade.
FA	Appear	ance	Model No.	Description	
NE DN MS JV MS			MS-DIN-E	When amplifiers are mounted in cascade, or when an amplifier moves depending on the way it is installed on a DIN rail, these end plates clamp amplifiers into place on both sides. Make sure to use end plates when cascading multiple amplifiers together. 2 pcs. per set	

OPTIONS

ers			,	
ber ers ner cts	Designation	Model No.	Description	Ampl • MS-I
00	Amplifier mounting bracket	MS-DIN-2	Mounting bracket for amplifier	
50				

Amplifier mounting bracket • MS-DIN-2

LIST OF FIBERS

Refer to "Fiber Selection p.5 ~" for details of each fiber.

LASER SENSORS PHOTO-ELECTRIC SENSORS MICRO PHOTO-ECTRIC ENSORS AREA SENSORS SAFETY LIGH CURTAINS SAFET COMPONENTS PRESSURE / FLOW SENSORS INDUCTIVE PROXIMITY SENSORS PARTICULAR USE SENSORS SENSOR OPTIONS SIMPLE WIRE-SAVING UNITS WIRE-SAVING SYSTEMS MEASURE-MENT SENSORS STATIC CONTROL DEVICES LASER MARKERS PLC HUMAN MACHINE INTERFACES ENERGY MANAGEMENT SOLUTIONS FA COMPONENTS MACHINE VISION SYSTEMS CURING

Fiber Amplifiers Other Products FX-500 FX-550 FX-100

Selection Guide Fibers

SPECIFICATIONS

	Туре	Connector type	Cable type			
ON IN	NPN output	FX-551	FX-551-C2			
Item	PNP output	FX-551P	FX-551P-C2			
CE marking dire	ective compliance	EMC Directive,	RoHS Directive			
Supply voltage	e	12 to 24 V DC ⁺¹⁰ ₋₁₅ % R	pple P-P 10 % or less			
Power consumption		Normal operation: 960 mW or less (current cons ECO mode: 680 mW or less (current consumpti				
Output		<npn output="" type=""> NPN open-collector transistor • Maximum sink current: 100 mA • Applied voltage: 30 V DC or less (between output and 0 V) • Residual voltage: 2 V or less (Note 2) (at maximum sink current)</npn>	<pnp output="" type=""> PNP open-collector transistor • Maximum source current: 100 mA • Applied voltage: 30 V DC or less (between output and +V) • Residual voltage: 2 V or less (Note 2) (at maximum source current)</pnp>			
	Output operation	Switchable either Light-ON	or Dark-ON by L/D mode			
-	Short-circuit protection	Incorp	prated			
Response time	e	FAST: 60 µs or less, STD: 250 µs or less, LONG: 2 ms or less, U-LG: 4 ms or less, HYPR: 24 ms or less, selectable				
Sensitivity sett	ting	2-point teaching / Limit teaching / Full-auto teaching / Manual adjustment				
Incident light s	sensitivity setting	Incorporated, 4 steps				
ncident light inte	ensity display range	FAST / STD: 0 to 4,000, LONG: 0 to 8,000, U-LG / HYPR: 0 to 9,999				
Fimer function		Incorporated with variable OFF-delay / ON-delay / One-shot / switchable either effective or ineffective				
	Timer period	Timer range "ms": 1 to 9,999 ms approx., 1 ms appro Timer range "1/10 ms": 0.1 to 999.9 ms approx., 0.1 r				
Different frequency interference prevention function (Note 4)		Incorporated (up to 4 units). Note that the response time varies depending on the setting. F-1: 0.8 ms or less, F-2: 0.9 ms or less, F-3: 1.0 ms or less, F-4: 1.7 ms or less				
Protection		IP40 (IEC)				
Ambient temperature		-10 to +55 °C +14 to +131 °F (If 4 to 7 units are mounted in cascade: -10 to +50 °C +14 to +122 °F or if 8 to 16 units are mounted in cascade: -10 to +45 °C +14 to +113 °F) (No dew condensation or icing allowed), Storage: -20 to +70 °C -4 to +158 °F				
Emitting element (modulated)		Red LED (Peak emission wavelength: 660 nm 0.026 mil)				
Material		Enclosure, Case cover: Polycarbonate, Switch: Polyacetal				
Cable		0.2 mm ² 3-core cabtyre cable, 2 m 6.562 ft long				
Cable						
Cable Cable extensio	on		Extension up to total 100 m 328.084 ft is possible with 0.3 mm ² , or more, cable. (however, supply voltage 12 V DC or more)			


Notes: 1) Where measurement conditions have not been specified precisely, the conditions used were an ambient temperature of +23 °C +73.4 °F.

2) In case of using the quick-connection cable (cable length 5 m 16.404 ft) (optional).
3) When set to LONG, U-LG, HYPR, IP-F or IP-R, the time range cannot be set to 1/10 ms.

4) This function increases the hysteresis. Check the sensing condition when using the function.

FX-500 FX-100 FX-410

I/O CIRCUIT AND WIRING DIAGRAMS





In case of using sensing devices for

personnel protection, use products which meet laws and standards, such as OSHA, ANSI or IEC etc., for personnel protection applicable in each region or country.

Wiring

Selection Guide

Fibers

Fiber

Other Products

EX-500

FX-550

FX-100

FX-410


- Make sure that the power supply is OFF while adding or removing the amplifiers.
- Note that if a voltage exceeding the reted range is applied, or if an AC power supply is directly connected, the product may get burnt or damaged.
- Note that short-circuit of the load or wrong wiring may burn or damage the product.
- Do not run the wires together with high-voltage lines or power lines, or put them in the same raceway. This can cause malfunction due to induction.
- Verify that the supply voltage variation is within the rating.
- If power is supplied from a commercial switching regulator, ensure that the frame ground (F.G.) terminal of the power supply is connected to an actual ground.
- · In case noise generating equipment (switching regulator, inverter motor, etc.) is used in the vicinity of this product, connect the frame ground (F.G.) terminal of the equipment to an actual ground.

- 0.3 mm² or more, cable. However, in order to reduce
- noise, make the wiring as short as possible. · Make sure that stress by forcible bending or pulling is not applied to the sensor cable joint and fiber cable.

Others

- · This product has been developed / produced for industrial use only.
- The specification may not be satisfied in a strong magnetic field.
- . The ultra long distance (U-LG, HYPR) mode is more likely to be affected by extraneous noise since the sensitivity of that is higher than the other modes. Make sure to check the environment before use.
- Do not use during the initial transient time (FAST, STD: 0.5 sec., U-LG, HYPR: 1 sec.) after the power supply is switched ON.
- These sensors are only for indoor use.
- Avoid dust, dirt, and steam.
- Make sure that the product does not come in contact with oil, grease, organic solvents such as thinner, etc., strong acid or alkaline.
- This product cannot be used in an environment containing inflammable or explosive gases.
- Never disassemble or modify this product.
- This product adopts EEPROM. Settings cannot be done a million times or more because of the EEPROM's lifetime.

116



Contact our office for sensing characteristics that are not contained here.

SENSING CHARACTERISTICS (TYPICAL)

150

-Right

l eft

- Center

Operating point (mm in)

50 0 50

Down

- Center

Operating point { (mm in)

► Up

150

600 23.622

200 7.874

Right

Left - Center

Operating point & (mm in)

600 23.622

600 23.62

200 7.874 0 200 7.874


Down - Center

Operating point { (mm in)

600 23.62

→ Up

Contact our office for sensing characteristics that are not contained here.





118

BER ENSOR


SENSING CHARACTERISTICS (TYPICAL)


Contact our office for sensing characteristics that are not contained here.






CN-73-C






Material: Cold rolled carbon steel (SPCC) (Uni-chrome plated)




CN-71-C

Main cable (Optional)



MS-DIN-E



Material: Polycarbonate

End plate (Optional)

Sub cable (Optional)

Selectior Guide

Fibers

Fiber

Other Product

FX-500

FX-100

FX-410